C172S-G1000 (Ted v1.2) ▶ "Prop Clear!" • Mixture/Throttle ► Mags. - start ▶ Engine Inst. - green Initial ▶ Throttle - 1000 RPM ▶ Vr - 55 kts ▶ Papers - A.R.O.W. ▶ 0il Pressure - 30 secs. Vx - 62 kts₁ Vy - 74 kts ▶ Control Lock - off ▶ Volts/Amps - [>26] [>0] Climb / Cruise ▶ Mags. - key out ▶ Mixture - lean for taxi ▶ Mixture - idle cutoff ▶ Cruise Climb - 75-85 kts Pre-Taxi ▶ Throttle - idle • Flaps - up ▶ Avionics - off ▶ Flaps - up ► Mixture - lean >3000 ▶ Lights - as required ▶ Fuel Shutoff - on ▶ Flow Check (♠15 min) ▶ Avionics - on/set ▶ Fuel - both • Fuel₁ Trim ► GPS - DB date ▶ Master - on Flaps Tingine Inst. ▶ Fuel - note ▶ Fuel Totalizer - enter • Mixture, Throttle ▶ Flaps - down ► ATIS - PFD/backup/AP(?) • Master, Mag, Pump ▶ Lights/Pitot - test ▶ Radio - test Descent ▶ Avionics on/off - fans ▶ Transponder - squawk ▶ Mixture - richen slowly ▶ Master - off ► Check - TC/AI/HSI<->MC ▶ Throttle - as required ► Hobbs Time - note ► Clearance - obtain ▶ Flow Check ▶ Brakes - test Walkaround Pre-Landing Run-Up ► Fuel/0il - dip/sample ► ATIS/Rwys & Patterns ▶ Caps/Drains/Vents ▶ Brakes - set ▶ "CCGUMPSF" ▶ Surfaces/Controls ▶ Seat Belts - check • G: Fuel - on/both ▶ Exhaust/Antennas ▶ Doors/Windows - secure • M: Mixture - rich ▶ Prop/Belt/Air Intake ▶ Flight Controls - correct • S: Seat Belts - secure ▶ Pitot/Static/Stall ▶ Instruments - scan • F: Flaps - as required ▶ Gear/Tires/Brakes ► Alternate Static - check ▶ Trim - as required ▶ Ties/Baggage Door ▶ AP - MET/HDG ▶ Ldg. Light - on ► Final Walkaround ▶ Trim - takeoff ▶ Approach - 80-65 kts Pre-Start ▶ Fuel - on/both Post-Landing ► Hdg./Alt. Bugs ▶ Doors - secure ▶ Throttle - 1000 RPM ► GPS/Status Bar/Ann. Test ▶ Belts/Seat Track ▶ Mixture - lean ▶ MFD Range/Track Up ▶ Brakes - check, set ▶ Flaps - up ▶ Comm/Nav/VOR/FP ► Circuit Brkrs. - check ▶ Pitot Heat - off ▶ Mixture - rich ▶ Passenger - brief ▶ Trim - takeoff ▶ Throttle - 1800 RPM ▶ Beacon - on ► Mags. - 150, 50 ▶ Lights - as required ► Avionics - off ▶ Clearance - obtain ▶ Engine Inst. - check ▶ Fuel - both ▶ Idle Check Shutdown Start ▶ Throttle - 1000 RPM ▶ ELT - check (121.5) ▶ Stby. Battery - test/arm ▶ Mixture - lean ► Avionics - off ▶ Engine Ind. - no Xs ▶ Lights - as required ▶ Lights - off ▶ Volts - [E>24] [M<1.5] ► ADSB Handheld - on Beacon - on ► Amps - S<0/ann on Pre-Takeoff ► Throttle - 1000 RPM ▶ Prime: ▶ Abort Plan/Lost Comm. ▶ Mags. - off then both • Mixture - idle cutoff Fuel - on/both ▶ Mixture - idle cutoff • Brakes - secure ▶ Flaps - U-10° ► Mags. - key out • Master - on ▶ Mixture - rich ▶ Master - off • Throttle - slight ► Aux. Pump - off ▶ Tach Time - note ■ Aux Pump - on ▶ Pitot heat - as required ▶ Stby. Battery - off • Mixture - prime

▶ "Lights: Camera: Action"

Takeoff

▶ Review Airspeeds

▶ Time - note/start

·warm: D-3 sec

· cold: 3-5 sec

Aux. Pump - off

▶ Mixture - 3/4 rich

amera₁ Action" ▶ Pitot Cover

► ADSB Handheld - off
► Tiedowns/Chocks

Post-Flight

- ▶ Fuel switch to L/R
- ▶ Gust Lock
- ► Close Flight Plan
- ▶ Hobbs Time note
- ▶ Check Under Seats
- ► Cabin / Baggage lock
- ▶ Post-Flight Walkaround

Engine Failure

- ▶ Short Flow
- Fuel on/both
- Mixture full/check
- Electrical Pump on
- Alternate Air on
- Mags. check all
- ▶ Glide and Trim
- Speed: La kts
- Ratio: 9, 1.48nm/1000ft
- ▶ Wind and Landing Site
- ▶ Longer Flow• Engine Indicators
- Short Flow Again
- ZHON'C I TOW AGAIN
- ▶ No Restart
- Fuel off
- Mixture idle cut-off
- Prop/Throttle off
- Mags. off
- Master off
- Belt and Seat check
- Unlatch Door

Brace

▶ Approach - 80/70/65 kts