HITACHI SEMICONDUCTOR TECHNICAL UPDATE

DATE	1 February 2000 No. TN -SH7-202A /E	
THEME	SH-4 SH7750 Hardware Manual usage notice	
CLASSIFICATION	☐ Spec. change ☐ Limitation on Use ■ Supplement of Documents	
PRODUCT NAME	HD6417750VF128, HD6417750F167, HD6417750F167I, HD6417750BP200, HD6417750BP200M	
REFERENCE DOCUMENTS	SH7750 Hardware Manual Effective Date: Eternity Lot#: All	
Following hardware manual notification of SH7750 is changed:		
(SH7750 Hardware Manual Rev.1.0, Rev.2.0, Rev.3.0) 22.2 Pin Functions (208-Pin QFP) 22.2.2 Pin Functions Notes 5.		
<current> With the QFP package, VSSQ, VSS, VSS-RTC, VSS-PLL1/2, and VSS-CPG are not connected inside the package.</current>		
<revised> VSSQ, VSS, VSS-RTC, VSS-PLL1/2, and VSS-CPG are connected inside the package.</revised>		
(SH7750 Hardware Manual Rev.3.0) Appendix E Pin Function E.1 Pin States " Table E.1 Pin States in Reset, Power-Down State, and Bus-Released State " Notes: 16. <current> 16. Pulled up. <pre></pre> <pre></pre> <pre></pre> <pre></pre> <pre></pre></current>		

HITACHI SEMICONDUCTOR TECHNICAL UPDATE

DATE	1 February 2000 No. TN -SH7-202A /E	
THEME	SH-4 SH7750 Hardware Manual usage notice	
CLASSIFICATION	☐ Spec. change ☐ Limitation on Use ☐ Supplement of Documents	
PRODUCT NAME	HD6417750VF128, HD6417750F167, HD6417750F167I, HD6417750BP200, HD6417750BP200M	
REFERENCE DOCUMENTS	SH7750 Hardware Manual Effective Date: Eternity Lot#: All	
Following hardware manual notification of SH7750 is changed:		
(SH7750 Hardware Manual Rev.1.0, Rev.2.0, Rev.3.0) 22.2 Pin Functions (208-Pin QFP) 22.2.2 Pin Functions Notes 5.		
<current> With the QFP package, VSSQ, VSS, VSS-RTC, VSS-PLL1/2, and VSS-CPG are not connected inside the package.</current>		
<revised> VSSQ, VSS, VSS-RTC, VSS-PLL1/2, and VSS-CPG are connected inside the package.</revised>		
(SH7750 Hardware Manual Rev.3.0) Appendix E Pin Function E.1 Pin States "Table E.1 Pin States in Reset, Power-Down State, and Bus-Released State " Notes: 16. <current> 16. Pulled up. <revised> 16. Pulled up. Internal pull up can not use for mode setting in power on reset. Should be use pull up or pull down on out of SH-4.</revised></current>		