disable_servo()

dexterindustries.com/GoPiGo/learning-2/python-programming-for-the-raspberry-pi-gopigo/disable_servo/

Sign Out

Docs » Python Programming » disable servo()

Disables the servo

Disables the Servo to be used by the GoPiGo

Syntax

```
disable_servo()
```

Parameter:

None

Return:

None

Example

```
from gopigo import *
import time
enable_servo()
for i in range(180):
    servo(i)
    time.sleep(100)
disable_servo()
```

Specifications

- Difficulty
- Ages 10+
- Tech Raspberry Pi & Windows 10
- Languages Python, Scratch, Java, NodeJS, C/C++

GoPiGo

• Price \$99-\$199

Buy Now

© 2017 Dexter Industries · Built by Nav.

Real-time

15

Visitors right now

Need Technical Help?
Visit our forums