volt()

Sign Out

Read battery voltage in V

Read the voltage of the battery pack connected to the GoPiGo in V

Syntax

```
volt()
```

Parameter:

None

Return:

Voltage in V on success

-1 on failure

Example

```
from gopigo import *
print volt()
```

Specifications

- Difficulty
- Ages 10+
- Tech Raspberry Pi & Windows 10
- Languages Python, Scratch, Java, NodeJS, C/C++
- Price $99-$199

GoPiGo

Buy Now

© 2017 Dexter Industries · Built by Nav.

Real-time

12

Visitors right now

Need Technical Help?
Visit our forums