SERVICE MANUAL

SERVICE MANUAL SECTION

FE 300 Models Built June 11, 2007 and After — ELECTRICAL CIRCUIT DIAGRAMS

Model: FE 300 Start Date: 06/11/2007

S08331

09/12/2007

Table of Contents

1. T	ABLE OF CONTENTS (CHAPTER 1)	1
2. II	NSTRUCTIONS AND CHARTS (CHAPTER 2)	1
	2.1. ABBREVIATIONS, P. 1	
	2.2. ACRONYMS, P. 2	2
	2.3. CIRCUIT DIAGRAM INSTRUCTIONS, P. 3	3
	2.4. CIRCUIT DIAGRAM INSTRUCTIONS, P. 4	4
	2.5. CIRCUIT NUMBER IDENTIFICATION AND COLOR, P. 5	
	2.6. CIRCUIT NUMBER IDENTIFICATION AND COLOR, P. 6	6
	2.7. LAMP BULB CHART, P. 7	7
	2.8. RELAY FUNCTION AND WIRING GUIDE, P. 8	
	2.9. SCHEMATIC SYMBOL CHART, P. 9	
	2.10. SCHEMATIC SYMBOL CHART, P. 10	
	2.11. SCHEMATIC SYMBOL CHART, P. 11	
	2.12. SCHEMATIC SYMBOL CHART, P. 12	
3. P	OWER DISTRIBUTION (CHAPTER 3)	13
	3.1. BATTERY, P. 1	
	3.2. IGNITION KEY SWITCH, P. 2	14
	3.3. GROUND, P. 3	
	3.4. GROUND, P. 4	
	······································	
4. C	CAB ACCESSORIES (CHAPTER 4)	17
	4.1. HORN, P. 1	
	,	
5. E	NGINE SYSTEMS (CHAPTER 5)	18
	5.1. CHARGING SYSTEM / AMMETER, P. 1	
	5.2. CRANKING SYSTEM, P. 2.	
	5.3. HORTON FAN WITH ELECTRIC SOLENOID CONTROL, P. 3	20
	o.c	
6. C	SAUGES (CHAPTER 6)	21
J. U	6.1. FUEL LEVEL GAUGE, P. 1	
	6.2. SPEEDOMETER, TACHOMETER, VOLTMETER, P. 2	
	6.3. TRANSMISSION OIL TEMPERATURE GAUGE, P. 3	
7. W	VARNING LIGHTS (CHAPTER 7)	24
•	7.1. STOP ENGINE AND LOW AIR PRESSURE WITH AIR BRAKES, P. 1	
	7.2. STOP ENGINE AND PARK BRAKE WARNING LIGHT WITH HYDRAULIC BRAKES, P. 2.	
	7.3. DIAGNOSTIC / PROGRAMMABLE CONNECTOR, P. 3	
	7.4. PARKING BRAKE AND WARNING LIGHTS WITH AIR BRAKES, P. 4	
	7.5. ELECTRONIC CONTROL / MSM MODULE CONTROL SYSTEM, P. 5	
	7.6. AFTERTREATMENT / MSM MODULE CONTROL SYSTEM, P. 6	
	7.6. AFTERTREATMENT / MSM MODULE CONTROL SYSTEM, P. 6	
	1.1. AFTEN I REATIVIENT / IVISIVI IVIODULE CONTRUL STSTEW, P. /	30
ο ^	CHASSIS ACCESSORIES (CHAPTER 8)	24
0. U	8.1. HEATED FUEL FILTER, P. 1	
	·	
	8.2. AIR DRYER / DRAIN VALVE, P. 2	32

	0.2 DODY DUIL DED CONNECTIONS D.2	22
	8.3. BODY BUILDER CONNECTIONS, P. 3.	
	8.4. BRAKE SYSTEM HYDRAULIC, P. 4	
	8.5. STOP LIGHT SWITCH WITH AIR BRAKES, P. 5	
	8.6. ANTILOCK BRAKE SYSTEM WITH HYDRAULIC BRAKES, P. 6	
	8.7. ANTILOCK BRAKE SYSTEM WITH HYDRAULIC BRAKES, P. 7	
	8.8. WHEEL CHAIR WITH PARK BRAKE AND LIFT DOOR INTERLOCK, P. 8	
	8.9. ABS6 — BENDIX WITH AIR BRAKES, P. 9	
	8.10. ABS6 — BENDIX WITH AIR BRAKES, P. 10	
	8.11. ABS6 — BENDIX WITH AIR BRAKES, P. 11	
	8.12. ALLISON 1000/2000 WITH LCT GEN IV WITH I6 ENGINE, P. 12	
	8.13. ALLISON 1000/2000 WITH LCT GEN IV WITH I6 ENGINE, P. 12A	
	8.14. ALLISON 1000/2000 WITH LCT GEN IV WITH I6 ENGINE, P. 13	
	8.15. ALLISON 1000/2000 WITH LCT GEN IV WITH I6 ENGINE, P. 14	
	8.16. ALLISON 1000/2000 WITH LCT GEN IV WITH I6 ENGINE, P. 15	
	8.17. ALLISON 3000/4000 WITH WTEC GEN IV, P. 16	
	8.18. ALLISON 3000/4000 WITH WTEC GEN IV WITH I6 ENGINE, P. 17	
	8.19. ALLISON 3000/4000 WITH WTEC GEN IV SPARE INPUT/OUTPUT, P. 18	.49
	8.20. ALLISON 3000/4000 WITH WTEC GEN IV WITH I6 ENGINE, P. 19	.50
	8.21. J1939 DATALINK WITH WTEC GEN IV, P. 20	.51
	8.22. J1939 DATALINK WITH LCT GEN IV, P. 21	.52
	8.23. J1708 DATALINK, P. 22	
	8.24. AIR POWERED PARK BRAKE WITH HYDRAULIC BRAKE, P. 23	
	,	
9. LIG	HT SYSTEMS (CHAPTER 9)	.55
	9.1. BACKUP LIGHT SYSTEM, P. 1	
	9.2. DAYTIME RUNNING LIGHTS (USA), P. 2	
	9.3. HEADLIGHT SYSTEM, P. 3	
	9.4. PANEL LIGHTS, P. 4	
	9.5. TURN SIGNAL SYSTEM, P. 5.	
	9.6. DAYTIME RUNNING LIGHTS WITH ENGINE RUNNING ONLY, P. 6	
	9.7. SPECIAL LIGHTING, P. 7.	
	· · · · · · · · · · · · · · · · · · ·	
10. EL	ECTRONIC CONTROL (CHAPTER 10)	.62
	10.1. ECM POWER / GROUND SYSTEMS WITH I6 ENGINE, P. 1	.62
	10.2. AMBIENT AIR TEMP, APS AND AFTERTREATMENT SYSTEM, P. 2	
	10.3. CRUISE CONTROL / HAND THROTTLE SYSTEM, P. 3	
	10.4. COOLANT SENSOR MODULE, P. 4.	
	10.5. EXHAUST / COMPRESSION BRAKE AND EXHAUST BRAKE ONLY, P. 5	66
	10.0. EXHAGOT / COM RECOICH BRAKE AND EXHAGOT BRAKE CHEI, 110	.00
11 CC	DNNECTOR BODY COMPOSITES (CHAPTER 11)	67
00	11.1. CONNECTOR COMPOSITES (1), P. 1	
	11.2. CONNECTOR COMPOSITE (1), P. 2	
	11.3. CONNECTOR COMPOSITE (1), P. 3.	
	11.4. CONNECTOR COMPOSITE (2), P. 4.	
	11.5. CONNECTOR COMPOSITE (2), P. 5.	
	11.6. CONNECTOR COMPOSITES (2), (2A), (3), (4), P. 6	./ I
	11.7. CONNECTOR COMPOSITES (5), (7), (8), P. 7	
	11.8. CONNECTOR COMPOSITES (9), (10), (11), P. 8	
	11.9. CONNECTOR COMPOSITES (12), (13), P. 9	
	11.10. CONNECTOR COMPOSITES (15), P. 10	
	11.11. CONNECTOR COMPOSITES (20), (22), (23), P. 11	
	11.12. CONNECTOR COMPOSITES (27), (35X3), (37), (38M), P. 12	
	11.13. CONNECTOR COMPOSITES (40), (41), P. 13	.79

11.14.	CONNECTOR COMPOSITES (44M), (49), (50), (53), P. 14	80
11.15.	CONNECTOR COMPOSITES (54), (57), (69) (80), (81), P. 15	81
	CONNECTOR COMPOSITES (82), (83), (83A), (84), P. 16	
11.17.	CONNECTOR COMPOSITES (85), (88A), (88B), P. 17	83
	CONNECTOR COMPOSITES (89), (90), (91), (162), (165), P. 18	
11.19.	CONNECTOR COMPOSITES (168), (168F), P. 19	85
11.20.	CONNECTOR COMPOSITES (169), (170), (200), P. 20	86
11.21.	CONNECTOR COMPOSITES (209), (211), (258), P. 21	87
11.22.	CONNECTOR COMPOSITE (261), P. 22	88
11.23.	CONNECTOR COMPOSITES (279), (288X1), P. 23	89
11.24.	CONNECTOR COMPOSITES (289), (290), (291), (292), (297), P. 24	90
11.25.	CONNECTOR COMPOSITES (303), (323), (329), P. 25	91
	CONNECTOR COMPOSITES (330), (350X2), (351), (352), P. 26	
11.27.	CONNECTOR COMPOSITES (353), (354), (373M), (374M), P. 27	93
11.28.	CONNECTOR COMPOSITES (382M), (384M), (384N), P. 28	94
11.29.	CONNECTOR COMPOSITES (391), (392), P. 29	95
11.30.	CONNECTOR COMPOSITES (396), (397M), (420A), (422), P. 30	96
11.31.	CONNECTOR COMPOSITES (433), (434), P. 31	97
	CONNECTOR COMPOSITES (466), P. 32	
	CONNECTOR COMPOSITES (499), (523), P. 33	
	CONNECTOR COMPOSITES (569), (574), P. 341	
	CONNECTOR COMPOSITES (574), (639), (644F), P. 351	
11.36.	CONNECTOR COMPOSITES (646), (748), (749), P. 361	02
	CONNECTOR COMPOSITES (832), (836), (898), P. 371	
	CONNECTOR COMPOSITES (899), (996M), (1002), P. 381	
11.39.	CONNECTOR COMPOSITES (1004), (1050), (1133), (1152), P. 39	05
11.40.	CONNECTOR COMPOSITES (1272), (3027), (3028), (3029), (3032), P. 40	06
11.41.	CONNECTOR COMPOSITES (3036), P. 411	07
	CONNECTOR COMPOSITES (3043), (3084), P. 421	
11.43.	CONNECTOR COMPOSITES (3084), (3084B), (3084R), P. 431	09
	CONNECTOR COMPOSITES (3111), (3111M), (3112), P. 441	
11.45.	CONNECTOR COMPOSITES (3126), P. 451	11
11.46.	CONNECTOR COMPOSITES (6011), (6012), (6013), P. 461	12
11.47.	CONNECTOR COMPOSITES (6020), P. 471	13
	CONNECTOR COMPOSITES (6260), (6261), (6262), (6263), P. 48	
11.49.	CONNECTOR COMPOSITES (6323), (6334), (6400), (6406), (6703), P. 491	15
	CONNECTOR COMPOSITES (6710), (6741), (7104), P. 501	
	CONNECTOR COMPOSITES (7150), P. 511	
	CONNECTOR COMPOSITES (7203A), P. 521	
	CONNECTOR COMPOSITES (7250), (7350), P. 531	
	CONNECTOR COMPOSITES (9254), (9255), (9258), P. 541	
	CONNECTOR COMPOSITES (9261), (9500), P. 551	
11.56.	CONNECTOR COMPOSITES (9550), (9551), (9553), (9777), P. 56	
11.57.	3LANK PAGE. P. 57	23

iv	FE 300 Models Built June 11, 2007 and After — ELECTRICAL CIRCUIT DIAGRAMS

1. TABLE OF CONTENTS (CHAPTER 1)

2. INSTRUCTIONS AND CHARTS (CHAPTER 2)

2.1. ABBREVIATIONS, P. 1

	Y WAY DETRIMENTAL TO THE L TRUCK AND ENGINE CORPORATIO	N.			BREVIAT			
					,		_	
ABBREVIATI			ABBREVIA	TION		SCRIPTION	ABBREVIATION	DESCRIPTION
ACCESS	ACCESSORY		CRUS		CRUIS		PWR	POWER
ACCUM	ACCUMULATOR		CUR		CURR		PRESS	PRESSURE
AC	AIR CONDITIONING	3	DPNL		DASH		RAD	RADIO
AIR CLNR	AIR CLEANER		DFTR			ECTOR	RLY	RELAY
ALT	ALTERNATOR		DFR			OSTER	RES	RESISTOR
ACCEL	ACCELERATOR		DEG		DEGR		REGEN	REGENERATE
AFTR	AFTERTREATMEN	Г	DIAG		DIAGE		R	RIGHT
AMM	AMMETER		DSL		DIESE		RTR	ROTOR
AMP AMP HR	AMPERE HOUR		DIFF		DIMMI	RENTIAL	SNSR SHLD	SENSOR SHIELD
	AMPERE HOUR							
AMPL ARM	AMPLIFIER ARMATURE		ELEX			TRICAL TRONIC	SHFT SLPR	SHIFTER SLEEPER
ARSR	ARRESTER		ENG		ENGIN		SLV	SLEEPER
ASSY	ASSEMBLY		EXH		EXHA		SPKR	SPEAKER
AUX	AUXILIARY		FL		FLUID		SPR	SPRING
B/U	BACK-UP		FWD		FORW		STD	STANDARD
BTRY	BATTERY		FR		FRON		STRG	STEERING
BM	BENCHMARKING		FREQ			UENCY	STLITE	SATELLITE
BLK	BLOCK		GA		GAUG		SUNSH	SUNSHADE
BOOS	BOOSTER		GEN			RATOR	sw	SWITCH
вот	воттом		GND		GROU		SYS	SYSTEM
вк	BRAKE		HARN		HARN		TACH	TACHOMETER
BRKR	BREAKER		HDLP		HEAD		TEMP	TEMPERATURE
BRTHR	BREATHER		HTD		HEAT		TERM	TERMINAL
BRI	BRIGHT		HT TR		HEAT	TREAT	THROT	THROTTLE
BUZ	BUZZER		HTR		HEATI	ER	THRU	THROUGH
CA	CABLE		HP		HORS	EPOWER	TRAC	TRACTION
CD	CANDELA		HYD		HYDR	AULIC	TRLR	TRAILER
CP	CANDLEPOWER		ID		IDENT	IFICATION	XDCR	TRANSDUCER
CAP	CAPACITOR		IGN		IGNITI	ON	XFER	TRANSFER
CAT	CATERPILLAR		ILLUM		ILLUM	INATION	XFMR	TRANSFORMER
CHAS	CHASSIS		IND		INDIC	ATOR	XSTR	TRANSISTOR
СН	CHOKE		INST		INSTR	UMENT	XMSN	TRANSMISSION
CIRC	CIRCUIT		INT		INTER	MITTENT	XMTR	TRANSMITTER
CLK	CLOCK		<u> </u>		LEFT		TRK	TRUCK
CW	CLOCKWISE		LT		LIGHT		UPR	UPPER
CLSTR	CLUSTER		LTR		LIGHT		VLV	VALVE
CL	CLUTCH		LWR		LOWE		VERT	VERTICAL
COL	COLUMN		MAG		MAGN		VM	VOLTMETER
COMM	COMMUTATOR		MOD			ILATOR	VOL	VOLUME
CMPNT	COMPONENT		MDL		MODU		WSHR	WASHER
CPRSR	COMPRESSOR		MOT		MOTO		WHL	WHEEL
CONT	CONTINUE		MTD		MOUN		WDO	WINDOW WINDSHIELD
CONT	CONTINUE		NEG N/		NEGA NOT V		WSHLD WPR	WINDSHIELD
CONT	CONSOLE		NO.				WPR W/	WITH
CONT	CONTROL		PASS		NUMB	ER ENGER	W/O	WITHOUT
CONV	CONVERTER		POSN		POSIT		1 **/-0	***************************************
							1	
CLR CTSY	COOLER COURTESY		POS POT		POSIT	IVE NTIOMETER		
ATE	CHANGE	REV	REFERENCE	DRAWN		NAME	EE BLIC EL ECTRICAL	
SEP07 REV	/ISED & REDRAWN	- 1	59984K	UOOK	640	CIRCUIT DIAGRAM,	FE BUS ELECTRICAL	

Figure 1 Abbreviations

2.2. ACRONYMS, P. 2

OT TO BE USED IN ANY WAY DETRIMENTAL TO THE ST OF INTERNATIONAL TRUCK AND ENGINE CORPORATION.		ACRONY	MS		
DESCRIPTION	ACRONYI		DES	CRIPTION	ACRONYM
DESCRIPTION ANTILOCK BRAKING SYSTEM	ABS		VY DUTY DIESE	CRIPTION	HDD
ANTENNA COMMUNICATION UNIT	ACU		H PERFORMANO		HPT
ALTERNATING CURRENT	AC	HIG	H SIDE DRIVER		HSD
AXLE TO BACK OF CAB	AC		TING, VENTILAT	TION, AND	HVAC
AXLE TO FRAME	AF		CONDITIONING		
ACCELERATOR PEDAL MODULE	APM	_	ECTOR DRIVE M	ODULE	IDM L/O
ACCELERATOR POSITION SENSOR	APS		UT/OUTPUT EGRATED MOBIL		1/0
AUXILIARY POWER UNIT	APU		MUNICATION T		IMCT
AMERICAN TRUCKING ASSOCIATION	ATA		TRUMENT PANE		I/P
AUTOMATIC TRACTION CONTROL AUDIO VIDEO INTERFACE	ATC AVI	IND	EPENDENT POW	/ER TAKE-OFF	IPTO
BAROMETRIC ATMOSPHERE PRESSURE	BAP		UT SPEED SENS		ISS
BRAKE HORSEPOWER	BHP	LIG	HT COMMERCIA	LTRANSMISSION	LCT
BACK OF CAB	вос		V PRESSURE MO	DDULE	LPM
CITIZEN BAND	СВ		V SIDE DRIVE		LSD
COLD CRANKING AMPERES	CCA		DIUM DUTY MENTARY ENGIN	JE IGNITION	MD
CLEAN POWER ELECTRICAL CONNECTOR	CEC		ERRUPT RELAY	NE IGNITION	MEIIR
CENTRAL PROCESSING UNIT	CPU	MAL	FUNCTION INDI	CATION LAMP	MIL
CAB OVER ENGINE	COE	MUI	TIPLEX SWITCH	MODULE	мѕм
DIRECT CURRENT	DC		PUT SPEED SE		OSS
DRIVER CONTROL MODULE DIGITAL DATA LINK	DDL		OMETER AMME		PAM
DIESEL OXIDATION CATALYST INLET			VER DISTRIBUTI		PDC
TEMPERATURE	DOCT			OGIC CONTROLLER	PLC PTO
DIESEL PARTICULATE FILTER	DPF		VER TAKE-OFF SE WIDTH MODU	II ATION	PWM
DIESEL PARTICULATE FILTER DELTA PRESSURE	DPFDP		R AXLE	22,11011	RA
DIESEL PARTICULATE		_	IO FREQUENCY	,	RF
FILTER TEMPERATURE	DPFT	ROL	L STABILITY PR	OGRAM	RSP
DIESEL TURBOCHARGED	DT	SEV	ERE SERVICE		SS
DAY TIME RUNNING LIGHTS	DTRL			NTROL MODULE	TCM
ELECTRONIC CONTROL MODULE	ECM			MUNICATION UNIT	TCU
ELECTRONIC CONTROL UNIT	ECU		RESTRIAL MOBI		TMCT
EXHAUST GAS RECIRCULATION EXHAUST GAS TEMPERATURE	EGR EGT			ANK PROTECTION	TOCP
ELECTRO MAGNETIC INTEFERENCE	EMI	_	OTTLE POSITIO		TPS
END OF FRAME	EOF	TUF	BINE SPEED SE	NSOR	TSS
ELECTRIC TRAILER BRAKE	ETB	VEH	IICLE SPEED OL	ITPUT	vso
FRONT AXLE	FA	VEH	IICLE SPEED SE	NSOR	VSS
FRONT END	FE		RLD TRANSMISS CTRONIC CONT		WTEC
FRONT OF DASH	FOD		O VOLT REFERI		ZVR
FULL POWER BRAKE	FPB		O VOLI KLI LIK		12414
GLOBAL POSITIONING SYSTEM	GPS	-			
HYDRAULIC CONTROL UNIT HEAVY DUTY	HCU HD	-			
DATE CHANGE R		DRAWN JOOK640	NAME CIRCUIT DIAGRAI	V. FE BUS ELECTRICAL	
05SEP07 REVISED & REDRAWN A	59984K				

Figure 2 Acronyms

2.3. CIRCUIT DIAGRAM INSTRUCTIONS, P. 3




Figure 3 Circuit Diagram Instructions

2.4. CIRCUIT DIAGRAM INSTRUCTIONS, P. 4

	NY WAY DETRIM					CIRCUI	T NUMBER IDE	ENTIFICATION AND COLOR	
INTERNATION	IAL TROCK AND	INGINE COR	FORATION.						
	CIRCUIT								ר
	NUMBER	COLOR				DES	CRIPTION		4
	1	LTBL	ALTERNA						4
	2	RD			- CHARGE				┥
	3	DKBL GY				ICATION J1587 ICATION J1587			1
		DKBL				ICATION J1587			1
	4	GY				ICATION J1922			1
		YL					/11 / J1939/15	(+)]
	5	GN	SERIAL /	DATA	COMMUN	ICATION J1939	/11 / J1939/15	(-)	4
	6	GY					SS THAN 9 VOL	TS)	4
	7	RD	ALTERNA	TOR	- RESISTA	NCE			4
	8	01/	1004110	TAC:	FLEOTOS	AND ODOLLES			┨
	9 10	GY WH			E ELECTRO	NIC GROUND			1
	10	WH			R GROUNE				1
	12	LTBL	ACCESS(]
		PK	IGNITION]
	13	ВK	IGNITION	FEE	O (BODY BI	JILDER CONNE	ECTOR)		_
	14	RD	BATTERY	' FEE	D				4
	15	RD	KEY SWIT	TCH F	EED				4
	16		<u> </u>						4
	17		STARTER						4
	18	PK			PRE-HEAT	ER			1
	19 20	GY LTGN	ENGINE S		ER MODUL				1
	21	TN				(ETHER)			1
	22	TN				RING / CONTR	ROL		1
	23				SHUTTERS]
	24	GY	ENGINE E	XHAI	JST BRAKE				_
	25	TN	PYROME [*]	TER					4
	26	TN	AMMETE						4
	27	TN	VOLTMET		2 4 1 1 2 4 1 1	050			1
	28 29	TN TN			R TEMPER				1
	30				EMPERATU				1
	31	TN				PERATURE			J
	32	TN			PERATURE]
	33	TN	ENGINE C	OIL LE	VEL				4
	34	TN	COOLAN						4
	35	TN	ENGINE C		RESSURE				4
	36		FUEL LEV						┥
	37 38	TN GY	FUEL PUN						1
	39		AIR DRYE		ATER				1
	40				SURE WA	RNING			1
	41		AIR TEMP]
	42				NGAGED]
	43					PDL) WARNING)]
	44	GY	PARK BR	AKE V	VARNING				4
	45	LTGN	ANTI-THE	FT W	ARNING				J
	CH	INGE		REV	REFERENCE	DRAWN	NAME		
	EVISED & REI		1,	-	9984K	U00K640	CIRCUIT DIAGRA	M, FE BUS ELECTRICAL	
						RELEASE NO.	DATE	PART NO.	SHEET

Figure 4 Circuit Diagram Instructions

2.5. CIRCUIT NUMBER IDENTIFICATION AND COLOR, P. 5

IS NOT TO BE USE	ATIONAL TRUCI OVIDED ON A RESTRICTED I ED IN ANY WAY DETRIMENT	BASIS AND TAL TO THE			CIRCUI (CONT)	T NUMBER IDE	NTIFICATION AND COLOR	
TEREST OF INTERN	IATIONAL TRUCK AND ENG	INE CORPOR	ATION.		(00.11)			
	CIRCUIT							
	NUMBER	COLOR			DE	SCRIPTION		
	46	GY	POWER T	TAKE-OFF WA	RNING			
	47	GY	SPEEDON	METER				
	48	GY	ТАСНОМІ	ETER				
	49	GY	DIFFERE	NTIAL LOCK V	WARNING			
	50	YL		/ITCH FEED				7
	51	YL		SWITCH FEEL	D			1
	52	YL	1	HT HI - BEAM				7
	53	YL		HT LO - BEAM	1			_
	54	BN						_
				/ MARKER LI	GHIS			┪
	55	OR		SNAL - FEED				-
	56	OR		SNAL LIGHTS				-
		YL				BUILDER CONN	IECTION)	-
	57	OR		SNAL LIGHTS				-
	<u> </u>	LTGN	TURN SIG	SNAL LIGHTS	- RIGHT (BOD)	BUILDER CON	INECTION)	4
	58	BN	CLEARAN	ICE / IDENTIF	ICATION LIGH	TS		_
	59	GY	SOLENOI	D				_
	60	OR	HAZARD I	LIGHTS				
	61	GY	AIR SUSP	ENSION				
	62	DKBL	PANEL LIC	GHTS				
	63	DKBL	COURTES	SY / DOME LIC	GHTS			
	64	YL		IVING LIGHTS				
	65	OR		R FLOOD LIG				7
	66	YL		RUNNING LIC				7
	67	GY			E / REMOTE S	ENSOB		
	68	BN	TAIL LIGH		L / KLWOTL 3	LINSOR		┪
					-			
	69	BN		PLATE LIGHT				-
	70	OR	STOP LIG					-
		RD	1		BUILDER CONN	IECTION)		-
	71	OR	BACK-UP					-
		LTBL	1		DY BUILDER C			-
	72	OR		<u>AUXILIARY F</u>	EED - BATTER	Y		_
	73	LTGN	PWM					\dashv
	74	LTGN	1	RECIRCULAT				⊢
	75	LTGN	HEATER I	BLOWER MO	TOR			
	76	LTGN	AUXILIAR	Y FAN				_
	77	LTGN	AIR CONE	DITIONER				_
	78	LTGN	MIRRORS	S - HEATED, N	MOTORIZED			_
	79	GY	SEAT BEL					
	80	вк		BOX RELAY	- FEED			
	81	LTGN		OOR LOCKS				
	82	GY		ELD WIPER				
	83	LTGN	POWER V					7
	84	LTGN	CIGAR LI					
	85	GY	HORN	GITTER				┪
	- 83	- 61	HOKIN					_
DATE	CHANGE		REV	REFERENCE	DRAWN	NAME		
					U00K640	CIRCUIT DIAGRAM	M, FE BUS ELECTRICAL	
A1 05SEP07	REVISED & REDRA	AVVN	A	59984K	RELEASE NO.	DATE	PART NO.	SHEET

Figure 5 Circuit Number Identification and Color

2.6. CIRCUIT NUMBER IDENTIFICATION AND COLOR, P. 6

от то в	BE USED IN	OON A RESTRICTED BAS MY WAY DETRIMENTAL MAL TRUCK AND ENGINE	TO THE			CIRCUI (CONT)	T NUMBER IDE	ENTIFICATION AND COLOR	
SIOF	NTERNATIO	NAL TRUCK AND ENGINE	CORPORATION.			(00)			
			I		1				
		CIRCUIT NUMBER	COLOF	₹			DESCRIPTION	1	
		86	LTGN		RADIO - E	NTERTAINME	NT		
		87	GY		WINDSHIE	LD WASHER			
		88	LTGN			HOURMETER			
		90	VT GY		AIR BAG	IC BRAKE PUN	4D		
		91	VT			MMUNICATION			
		92	TN				OLS - ELECTRO	DNIC	
		93	TN		AXLE SHI	FT CONTROL			
		94	GY			BRAKE SYST	EM		
		95	TN			EMISSION	DUIDE COVE	01.0	
		96 97	YL VT		1	OW LIGHTS / C ONTROLS - EI	RUISE CONTR	ULS	
		98	BK			AND DIAGNO			
		99	VT				ON SENSOR (AF	PS)	
		100	GY		AIR HORN	(ELECTRIC S	OLENOID ACTU	JATED)	
		101	TN			PPLICATION AI	R		
		102	YL		FLASH TO	PASS ILDER AUXILIA	DV EEED		
		103 104	LTGN DKBL			START / STOP	IN I FEED		
		105	LTGN		HEATED S				
		106	OR		HIGH VOL	TAGE ALTERN	IATOR AC CHAI	RGE	
		107	GY		1		ELECTRONIC I	FEED (5V)	
		108	GY			AD WEAR SEN	SOR		
		109 110	GY GY		SLACK AD		ELECTRONIC (SPOLIND	
		111	TN				ION TRANSDU		
		112	GY		LIFT GATE				
	PREF	ΊΧ				LOCAT	ION		
	A	CAB - INST	RUMENT PA	NEL	MODULE				
			ER CONTRO						_
			DER / CLEAR		E LIGHTS				
			F / REAR PA F DOOR / DO						
	E		HT DOOR / DO		3				
		CAB - SLEI	EPER					·	
	<u> </u>		H (OUTSIDE)						
	<u> </u>								
		TRANSMIS CHASSIS /		(CAF	DASH PANF	L FORWARD)			
							B REAR CROS	S MEMBER)	
	E	CHASSIS -	WHEEL BASE	SEC	CTION				
	F				EAR AXLE / A				_
	S			I / ST	OP / TAIL / TL	JRN LIGHTS			-
				rs / M	ARKER LIGH	TS			
			ROOF / BACK			10			
	V		BE CABINET W						
				_		DRAWN	NAME		
T									
DATE 05SE		CHANGE EVISED & REDRAW		REV A	59984K	U00K640		M, FE BUS ELECTRICAL	

Figure 6 Circuit Number Identification and Color

2.7. LAMP BULB CHART, P. 7

INT							CHAPT	\ -
IS NOT	TO BE USED IN	ED ON A RESTRICTED BASIS ANY WAY DETRIMENTAL TO DNAL TRUCK AND ENGINE C	O THE		LAMP BULB CHART			
- NEOT	or internet	WILL THOUSENING ENGINE O	<u>om oravnom</u>		•			
		BULB APPLICA	TION		CANDLE POWER OR WATE		B TRADE	٦
	BACK-UP				32 CP		NUMBER GE1156	┪
		CE & IDENTIFICATIO	N SMALL		3 CP		GE168	_
	COURTES				21 CP		1142]
	DOME LIG	HTS			21 CP		1142	4
	FOG LIGH				100 WATT		921 - 1	4
	LOW BEAM				55 WATT		GE9007	┥
	HIGH BEA				60 WATT 1 CP		GE9007 1455	┪
	GAUGE B	ACK LIGHT			2 CP		194	7
	SIDE MAR						2548	_
	STOP & T	URN / TAIL & LICENSI			32/3 CP		3157	4
		NAL / MARKER (FENI			32/3 CP		3157	4
		NAL & MARKER LIGH AND AIR CONDITIONE			3 CP		2356 168	-
	DATE	CHANGE		REV REFERENCE	DRAWN NAME UOOK640 FE BUS E	ELECTRICAL CIRCI	UIT DIAGRAM	

Figure 7 Lamp Bulb Chart

2.8. RELAY FUNCTION AND WIRING GUIDE, P. 8




Figure 8 Relay Function and Wiring Guide

2.9. SCHEMATIC SYMBOL CHART, P. 9




Figure 9 Schematic Symbol Chart

2.10. SCHEMATIC SYMBOL CHART, P. 10




Figure 10 Schematic Symbol Chart

2.11. SCHEMATIC SYMBOL CHART, P. 11




Figure 11 Schematic Symbol Chart

2.12. SCHEMATIC SYMBOL CHART, P. 12




Figure 12 Schematic Symbol Chart

3. POWER DISTRIBUTION (CHAPTER 3)

3.1. BATTERY, P. 1




Figure 13 Battery

3.2. IGNITION KEY SWITCH, P. 2




Figure 14 Ignition Key Switch

3.3. GROUND, P. 3




Figure 15 Ground

3.4. GROUND, P. 4




Figure 16 Ground

4. CAB ACCESSORIES (CHAPTER 4)

4.1. HORN, P. 1




Figure 17 Horn

5. ENGINE SYSTEMS (CHAPTER 5)

5.1. CHARGING SYSTEM / AMMETER, P. 1




Figure 18 Charging System / Ammeter

5.2. CRANKING SYSTEM, P. 2




Figure 19 Cranking System

5.3. HORTON FAN WITH ELECTRIC SOLENOID CONTROL, P. 3




Figure 20 Horton Fan With electric Solenoid Control

6. GAUGES (CHAPTER 6)

6.1. FUEL LEVEL GAUGE, P. 1




Figure 21 Fuel Level Gauge

6.2. SPEEDOMETER, TACHOMETER, VOLTMETER, P. 2




Figure 22 Speedometer, Tachometer, Voltmeter

6.3. TRANSMISSION OIL TEMPERATURE GAUGE, P. 3




Figure 23 Transmission Oil Temperature Gauge

7. WARNING LIGHTS (CHAPTER 7)

7.1. STOP ENGINE AND LOW AIR PRESSURE WITH AIR BRAKES, P. 1




Figure 24 Stop Engine and Low Air Pressure with Air Brakes

7.2. STOP ENGINE AND PARK BRAKE WARNING LIGHT WITH HYDRAULIC BRAKES, P. 2




Figure 25 Stop Engine and Park Brake Warning Light with Hydraulic Brakes

7.3. DIAGNOSTIC / PROGRAMMABLE CONNECTOR, P. 3




Figure 26 Diagnostic / Programmable Connector

7.4. PARKING BRAKE AND WARNING LIGHTS WITH AIR BRAKES, P. 4




Figure 27 Parking Brake and Warning Lights with Air Brakes

7.5. ELECTRONIC CONTROL / MSM MODULE CONTROL SYSTEM, P. 5




Figure 28 Electronic Control / MSM Module Control System

7.6. AFTERTREATMENT / MSM MODULE CONTROL SYSTEM, P. 6




Figure 29 Aftertreatment / MSM Module Control System

7.7. AFTERTREATMENT / MSM MODULE CONTROL SYSTEM, P. 7




Figure 30 Aftertreatment / MSM Module Control System

8. CHASSIS ACCESSORIES (CHAPTER 8)

8.1. HEATED FUEL FILTER, P. 1




Figure 31 Heated Fuel Filter

8.2. AIR DRYER / DRAIN VALVE, P. 2




Figure 32 Air Dryer / Drain Valve

8.3. BODY BUILDER CONNECTIONS, P. 3




Figure 33 Body Builder Connections

8.4. BRAKE SYSTEM HYDRAULIC, P. 4




Figure 34 Brake System Hydraulic

8.5. STOP LIGHT SWITCH WITH AIR BRAKES, P. 5




Figure 35 Stop Light Switch with Air Brakes

8.6. ANTILOCK BRAKE SYSTEM WITH HYDRAULIC BRAKES, P. 6




Figure 36 Antilock Brake System with Hydraulic Brakes

8.7. ANTILOCK BRAKE SYSTEM WITH HYDRAULIC BRAKES, P. 7




Figure 37 Antilock Brake System with Hydraulic Brakes

8.8. WHEEL CHAIR WITH PARK BRAKE AND LIFT DOOR INTERLOCK, P. 8




Figure 38 Wheel Chair with Park Brake and Lift Door Interlock

8.9. ABS6 — BENDIX WITH AIR BRAKES, P. 9




Figure 39 ABS6 — Bendix with Air Brakes

8.10. ABS6 — BENDIX WITH AIR BRAKES, P. 10




Figure 40 ABS6 — Bendix with Air Brakes

8.11. ABS6 — BENDIX WITH AIR BRAKES, P. 11




Figure 41 ABS6 — Bendix with Air Brakes

8.12. ALLISON 1000/2000 WITH LCT GEN IV WITH I6 ENGINE, P. 12




Figure 42 Allison 1000/2000 with LCT Gen IV with I6 Engine

8.13. ALLISON 1000/2000 WITH LCT GEN IV WITH I6 ENGINE, P. 12A




Figure 43 Allison 1000/2000 with LCT Gen IV with I6 Engine

8.14. ALLISON 1000/2000 WITH LCT GEN IV WITH I6 ENGINE, P. 13




Figure 44 Allison 1000/2000 with LCT Gen IV with I6 Engine

8.15. ALLISON 1000/2000 WITH LCT GEN IV WITH I6 ENGINE, P. 14




Figure 45 Allison 1000/2000 with LCT Gen IV with I6 Engine

8.16. ALLISON 1000/2000 WITH LCT GEN IV WITH I6 ENGINE, P. 15




Figure 46 Allison 1000/2000 with LCT Gen IV with I6 Engine

8.17. ALLISON 3000/4000 WITH WTEC GEN IV, P. 16




Figure 47 Allison 3000/4000 with WTEC Gen IV

8.18. ALLISON 3000/4000 WITH WTEC GEN IV WITH I6 ENGINE, P. 17




Figure 48 Allison 3000/4000 with WTEC Gen IV with I6 Engine

8.19. ALLISON 3000/4000 WITH WTEC GEN IV SPARE INPUT/OUTPUT, P. 18




Figure 49 Allison 3000/4000 with WTEC Gen IV Spare Input/Output

8.20. ALLISON 3000/4000 WITH WTEC GEN IV WITH I6 ENGINE, P. 19




Figure 50 Allison 3000/4000 with WTEC Gen IV with I6 Engine

8.21. J1939 DATALINK WITH WTEC GEN IV, P. 20




Figure 51 J1939 Datalink with WTEC Gen IV

8.22. J1939 DATALINK WITH LCT GEN IV, P. 21




Figure 52 J1939 Datalink with LCT Gen IV

8.23. J1708 DATALINK, P. 22




Figure 53 J1708 Datalink

8.24. AIR POWERED PARK BRAKE WITH HYDRAULIC BRAKE, P. 23




Figure 54 Air Powered Park Brake with Hydraulic Brake

9. LIGHT SYSTEMS (CHAPTER 9)

9.1. BACKUP LIGHT SYSTEM, P. 1




Figure 55 Backup Light System

9.2. DAYTIME RUNNING LIGHTS (USA), P. 2




Figure 56 Daytime Running Lights (USA)

9.3. HEADLIGHT SYSTEM, P. 3




Figure 57 Headlight System

9.4. PANEL LIGHTS, P. 4




Figure 58 Panel Lights

9.5. TURN SIGNAL SYSTEM, P. 5




Figure 59 Turn Signal System

9.6. DAYTIME RUNNING LIGHTS WITH ENGINE RUNNING ONLY, P. 6




Figure 60 Daytime Running Lights with Engine Running Only

9.7. SPECIAL LIGHTING, P. 7




Figure 61 Special Lighting

10. ELECTRONIC CONTROL (CHAPTER 10)

10.1. ECM POWER / GROUND SYSTEMS WITH I6 ENGINE, P. 1




Figure 62 ECM Power / Ground Systems with I6 Engine

10.2. AMBIENT AIR TEMP, APS AND AFTERTREATMENT SYSTEM, P. 2




Figure 63 Ambient Air Temp, APS and Aftertreatment System

10.3. CRUISE CONTROL / HAND THROTTLE SYSTEM, P. 3




Figure 64 Cruise Control / Hand Throttle System

10.4. COOLANT SENSOR MODULE, P. 4




Figure 65 Coolant Sensor Module

10.5. EXHAUST / COMPRESSION BRAKE AND EXHAUST BRAKE ONLY, P. 5




Figure 66 Exhaust / Compression Brake and Exhaust Brake Only

11. CONNECTOR BODY COMPOSITES (CHAPTER 11)

11.1. CONNECTOR COMPOSITES (1), P. 1




Figure 67 Connector Composites (1)

11.2. CONNECTOR COMPOSITE (1), P. 2




Figure 68 Connector Composite (1)

11.3. CONNECTOR COMPOSITE (1), P. 3




Figure 69 Connector Composite (1)

11.4. CONNECTOR COMPOSITE (2), P. 4




Figure 70 Connector Composite (2)

11.5. CONNECTOR COMPOSITE (2), P. 5




Figure 71 Connector Composite (2)

11.6. CONNECTOR COMPOSITES (2), (2A), (3), (4), P. 6




Figure 72 Connector Composites (2), (2A), (3), (4)

11.7. CONNECTOR COMPOSITES (5), (7), (8), P. 7




Figure 73 Connector Composites (5), (7), (8)

11.8. CONNECTOR COMPOSITES (9), (10), (11), P. 8




Figure 74 Connector Composites (9), (10), (11)

11.9. CONNECTOR COMPOSITES (12), (13), P. 9




Figure 75 Connector Composites (12), (13)

11.10. CONNECTOR COMPOSITES (15), P. 10




Figure 76 Connector Composites (15)

11.11. CONNECTOR COMPOSITES (20), (22), (23), P. 11




Figure 77 Connector Composites (20), (22), (23)

11.12. CONNECTOR COMPOSITES (27), (35X3), (37), (38M), P. 12




Figure 78 Connector Composites (27), (35x3), (37), (38M)

11.13. CONNECTOR COMPOSITES (40), (41), P. 13




Figure 79 Connector Composites (40), (41)

11.14. CONNECTOR COMPOSITES (44M), (49), (50), (53), P. 14




Figure 80 Connector Composites (44M), (49), (50), (53)

11.15. CONNECTOR COMPOSITES (54), (57), (69) (80), (81), P. 15




Figure 81 Connector Composites (54), (57), (69) (80), (81)

11.16. CONNECTOR COMPOSITES (82), (83), (83A), (84), P. 16




Figure 82 Connector Composites (82), (83), (83A), (84)

11.17. CONNECTOR COMPOSITES (85), (88A), (88B), P. 17




Figure 83 Connector Composites (85), (88A), (88B)

11.18. CONNECTOR COMPOSITES (89), (90), (91), (162), (165), P. 18




Figure 84 Connector Composites (89), (90), (91), (162), (165)

11.19. CONNECTOR COMPOSITES (168), (168F), P. 19




Figure 85 Connector Composites (168), (168F)

11.20. CONNECTOR COMPOSITES (169), (170), (200), P. 20




Figure 86 Connector Composites (169), (170), (200)

11.21. CONNECTOR COMPOSITES (209), (211), (258), P. 21




Figure 87 Connector Composites (209), (211), (258)

11.22. CONNECTOR COMPOSITE (261), P. 22




Figure 88 Connector Composite (261)

11.23. CONNECTOR COMPOSITES (279), (288X1), P. 23




Figure 89 Connector Composites (279), (288x1)

11.24. CONNECTOR COMPOSITES (289), (290), (291), (292), (297), P. 24




Figure 90 Connector Composites (289), (290), (291), (292), (297)

11.25. CONNECTOR COMPOSITES (303), (323), (329), P. 25




Figure 91 Connector Composites (303), (323), (329)

11.26. CONNECTOR COMPOSITES (330), (350X2), (351), (352), P. 26




Figure 92 Connector Composites (330), (350x2), (351), (352)

11.27. CONNECTOR COMPOSITES (353), (354), (373M), (374M), P. 27




Figure 93 Connector Composites (353), (354), (373M), (374M)

11.28. CONNECTOR COMPOSITES (382M), (384M), (384N), P. 28




Figure 94 Connector Composites (382M), (384M), (384N)

11.29. CONNECTOR COMPOSITES (391), (392), P. 29




Figure 95 Connector Composites (391), (392)

11.30. CONNECTOR COMPOSITES (396), (397M), (420A), (422), P. 30




Figure 96 Connector Composites (396), (397M), (420A), (422)

11.31. CONNECTOR COMPOSITES (433), (434), P. 31




Figure 97 Connector Composites (433), (434)

11.32. CONNECTOR COMPOSITES (466), P. 32




Figure 98 Connector Composites (466)

11.33. CONNECTOR COMPOSITES (499), (523), P. 33




Figure 99 Connector Composites (499), (523)

11.34. CONNECTOR COMPOSITES (569), (574), P. 34




Figure 100 Connector Composites (569), (574)

11.35. CONNECTOR COMPOSITES (574), (639), (644F), P. 35




Figure 101 Connector Composites (574), (639), (644F)

11.36. CONNECTOR COMPOSITES (646), (748), (749), P. 36




Figure 102 Connector Composites (646), (748), (749)

11.37. CONNECTOR COMPOSITES (832), (836), (898), P. 37




Figure 103 Connector Composites (832), (836), (898)

11.38. CONNECTOR COMPOSITES (899), (996M), (1002), P. 38




Figure 104 Connector Composites (899), (996M), (1002)

11.39. CONNECTOR COMPOSITES (1004), (1050), (1133), (1152), P. 39




Figure 105 Connector Composites (1004), (1050), (1133), (1152)

11.40. CONNECTOR COMPOSITES (1272), (3027), (3028), (3029), (3032), P. 40




Figure 106 Connector Composites (1272), (3027), (3028), (3029), (3032)

11.41. CONNECTOR COMPOSITES (3036), P. 41




Figure 107 Connector Composites (3036)

11.42. CONNECTOR COMPOSITES (3043), (3084), P. 42




Figure 108 Connector Composites (3043), (3084)

11.43. CONNECTOR COMPOSITES (3084), (3084B), (3084R), P. 43




Figure 109 Connector Composites (3084), (3084B), (3084R)

11.44. CONNECTOR COMPOSITES (3111), (3111M), (3112), P. 44




Figure 110 Connector Composites (3111), (3111M), (3112)

11.45. CONNECTOR COMPOSITES (3126), P. 45




Figure 111 Connector Composites (3126)

11.46. CONNECTOR COMPOSITES (6011), (6012), (6013), P. 46




Figure 112 Connector Composites (6011), (6012), (6013)

11.47. CONNECTOR COMPOSITES (6020), P. 47




Figure 113 Connector Composites (6020)

11.48. CONNECTOR COMPOSITES (6260), (6261), (6262), (6263), P. 48




Figure 114 Connector Composites (6260), (6261), (6262), (6263)

11.49. CONNECTOR COMPOSITES (6323), (6334), (6400), (6406), (6703), P. 49




Figure 115 Connector Composites (6323), (6334), (6400), (6406), (6703)

11.50. CONNECTOR COMPOSITES (6710), (6741), (7104), P. 50




Figure 116 Connector Composites (6710), (6741), (7104)

11.51. CONNECTOR COMPOSITES (7150), P. 51




Figure 117 Connector Composites (7150)

11.52. CONNECTOR COMPOSITES (7203A), P. 52




Figure 118 Connector Composites (7203A)

11.53. CONNECTOR COMPOSITES (7250), (7350), P. 53




Figure 119 Connector Composites (7250), (7350)

11.54. CONNECTOR COMPOSITES (9254), (9255), (9258), P. 54




Figure 120 Connector Composites (9254), (9255), (9258)

11.55. CONNECTOR COMPOSITES (9261), (9500), P. 55




Figure 121 Connector Composites (9261), (9500)

11.56. CONNECTOR COMPOSITES (9550), (9551), (9553), (9777), P. 56




Figure 122 Connector Composites (9550), (9551), (9553), (9777)

11.57. BLANK PAGE, P. 57

	ITERNAT	IONAL TRUCK AND ENGI	INE	CORPORA	TIGNECT	RICAL CIRC	CUIT DIAGRAMUADT	ED 11
THIS	PRINT IS PROVID	DED ON A RESTRICTED BASIS AND N ANY WAY DETRIMENTAL TO THE		00111 011	1		MPOSITES - MATING VIEW SI	
		IONAL TRUCK AND ENGINE CORPORATION.						
				INTENTI	ONALLY			
				LEFT BL	ANK			
СНК	DATE	CHANGE	REV	REFERENCE	DRAWN U00K640	NAME CIRCUIT DIAGRAI	И, FE BUS ELECTRICAL	
CNA1	05SEP07	ADDED CONNECTOR	Α		RELEASE NO.	DATE	PART NO.	SHEET
	LOCATION				59974F	15JAN07	AE08056630	057

Figure 123 Blank Page