SERVICE MANUAL

SERVICE MANUAL SECTION

USPS International® 4400 Master Index

Model: 4400

Start Date: 03/01/2004

Model: USPS

Start Date: 03/01/2004

S10020

06/17/2005

Table of Contents

ii	USPS International® 4400 Master Index

1. MASTER INDEX

This Service Manual is an index of United States Postal Service Model 4400 service information.

Direct links to the ISIS Master Service Manual are provided for International Service Manuals in order to access the latest information.

For unique vendor service information not on ISIS, a pdf is provided plus a link to the vendor site (when applicable) where later versions may be found.

NOTE - These links were accurate at the time of release but are subject to change by the vendor.

GROUP 01 - FRAME

S01001Y - Frame

GROUP 02 - FRONT AXLE

S02001K - Steering General Service Information / Front Wheel Alignment

S02002S – Hubs, Bearings, and Seals (Non-Drive Axles)

S02004T - Front Axles: International by Spicer I-Beam

GROUP 03 - SPRINGS

Hendrickson Suspension (HAS 230) (11 ton only)

http://www.hendrickson-intl.com/pdfs/Truck_PDFs/has/TP_212_C.pdf

S03003X - Suspension Alignment

S03004R – Spring Assemblies and Shock Absorbers

S03012 - International Ride Optimized Suspension (IROS) (7 ton only)

GROUP 04 - BRAKES

Bendix Tu-Flo 550 Compressor

http://bendix.com/enter.do?userType=TruckOEM

Bendix Air Dryer AD-IP

http://bendix.com/enter.do?userType=TruckOEM

Bendix EC-30 ABS Controller Quick Reference

http://bendix.com/enter.do?userType=TruckOEM

S04002R - Brake Components

S04005 - Cam Air Foundation Brakes

S04006 - Automatic Slack Adjusters: Rockwell

S04008 - Split Air Brake System

S04020X - Double Diaphragm MGM Spring Brake

S04043 - EC-30 ABS / ATC Controller

GROUP 05 - STEERING

Sheppard M-Series (M100) Steering Gear

http://www.rhsheppard.com/service.htm

S05016 - Steering Wheel Removal and Installation

GROUP 06 - PROPELLER SHAFT

S06001 - Propeller Shaft

GROUP 08 - ELECTRICAL

S08010 - Test Equipment and Connector Repair

S08022K - Battery

S082504 - Electrical System Troubleshooting Guide

S082854 - Electrical Circuit Diagrams

S082894 - Truck Diagnostic Trouble Codes

GROUP 09 - FRONT END SHEET METAL

S09003 - Hood, Grille, Fenders and Bumper

GROUP 10 - GENERAL

S10008 – Drivetrain Failure Analysis

GROUP 12 - ENGINE

EGES-265-1 DT 466 / DT 570 / HT 570 Service Manual - 2004 Emissions with EGR

Ingersoll-Rand Air Starter P7520

http://www.irtechpubs.com/index.cfm?fuseaction=view.main&type=Assembly&cat=178&sub=855

Ingersoll-Rand SRV125F Air Starter Valve Manual

http://www.irtechpubs.com/index.cfm?fuseaction=view.main&type=Assembly&cat=178&sub=854

Horton Drivemaster 2-Speed Fan Drive for International® Installation, Operation and Maintenance Instructions

http://fulfill.pgicompanies.com/sqlimages/horton/pdf/22845.pdf

Horton Drivemaster Spring-Engaged Fan Drive Repair Kit Installation Instructions

http://fulfill.pgicompanies.com/sqlimages/horton/pdf/22748.pdf

S12003R - Engine Cooling System

S12006 - Air-to-Air Charge Air Cooler

S120083 – Radiator, Remove and Replace

GROUP 13 - TRANSMISSION

Allison Transmission Operator's Manual

Allison Mechanic's Tips

Allison WTECIII Electronic Controls Troubleshooting Manual TS2973EN

GROUP 14 - REAR AXLE

Spicer Single Drive Axles

USPS 4400 Lift Axle System: International Supplement and Hendrickson Owner's Manual (11 ton only)

SFN 04–45R, Description and Operation of Brake, Suspension, and Lift Axle Systems Used in International® 4400 Model USPS (Sales Code MA03500) Trucks http://service.navistar.com/sfns/sfn0445r.htm)

S14001T - Hubs, Bearings, and Seals

GROUP 16 - CAB

S16002 - Paint and Refinishing

S160254 - Heat Ventilation Air Conditioning (HVAC) System

S160263 – Cab International Premium Mirror System

International Premium Mirror System

http://www.lang-mekra.com/pdf/service/international-premium.pdf

GROUP 17 - WHEELS

S17001Y - Wheels, Rims and Tires

INTERNATIONAL OPERATOR'S MANUAL SUPPLEMENT

2645023R1

UTILIMASTER BODY

Utilimaster Body Service Manual / USPS Cargo Vans

Website Information Not Available

INTERLUBE LUBRICATION SYSTEM

AC3 Lubrication System

Website Information Not Available