1. Failed to start ros master, unable to run ros related cases.

- 1) Check whether the system is set for multi-machine communication. If you set up multi-machine communication, please start ros master on the host(master side).
- 2) Check whether the host IP of the .bashrc file is correct.
- 3) Check whether it is connected to the network.