

TARS WIZARD Guide

A comprehensive code guide on how to deal with electronics and technical stuff.




Follow me on socials:

Instagram: <https://www.instagram.com/wizard.py/>

LinkedIn: <https://www.linkedin.com/in/Dhruv-Goswami-24-/>

Raspberry Pi 5 connections



On this Servo Controller shown below only connect servos as follows:

Body servo on channel = 0

Left arm servo on channel = 3

Right arm servo on channel = 4

