



Model DW180E




No.	Part.No	Description	Qty.	No.	Part.No	Description	Qty.	No.	Part.No	Description	Qty.	No.	Part.No	Description	Qty.
1	KM186FG-00000	Air-cooled diesel	1	28	GB/T62-1988	Wing nut	2	55	GB/T5783-2000	Bolt M10×40	6	82			/
2	KM186F-15100	Starting motor	1	29	GB/T95-2000	Washer (1)	4	56	5GF-LDE-03700	Cushion	4	83			
3				30	GB/T95-2000	Washer (2)	12	57	KTW204	Alternator assembly	1	84	KDE6500EW-30000	Fuel tank assembly	1
4				31	KDE6500EW-09004	Insulating cushion (1)	2	58	KT204-00002A	Front cover of alternator	1	85	5GF-LDE-07200	Fuel tank cap unit	1
5	KDE6500EW-03100	Housing weldment assembly	1	32	KDE6500EW-09005	Insulating cushion (2)	2	59	GB5789-2006	Bolt M5*10	3	86	KM168F-10004	Fuel filler screen	1
6				33			2	60	KT204-01004	Fan of alternator	4	87	GB/T819.1-2000	Screw M5 x 12	2
7	5GF-LDE-03600	Truckle	4	34	JK427	Starting key	1	61	KTW204-01000	Rotor assembly	1	88	KDE5000X-32000	Oil mark unit	1
8	CDQ-36	Adjusting regulator	1.	35	CLAD	Oil pressure alarm	. 1	62	GB97.1	Washer Ø10	1	89	KDE5000X-30005	Bushing	4
9	KDE6500EW-03200	Splint weldment	-1	36	MV52.5 0-300V	Voltage meter	1	63	KTW204-00004	Pull-through shaft bolt M10×278	. 1	90	KDE5000X-30004	Cushion	4
10				37	WX111-150A±5%	Adjusting switch of welder and current	1	64	KTW204-02000	Stator assembly	1	91	KDE5000X-31000	Fuel tank weldment	1
11				38	AD11-16/24-6GD	Welder indicating light	1	65	KTW204-00006	Protected plate of alternator	1	92	KM168F-10013	Fuel return pipe hoop	2
12	GB/T62-1988	Wing nut	2	39	RF1004	Welding selective current switch	1	66	KT204-00001A	Rear cover	.1	93	KDE6500EW-300002	Fuel return pipe	1
13	KDE5000T-03003	Accumulator pressure plate	1	40	GB-806-88	Grounding screw cap M6	1	67	KT204-00003	Bolt M6×140	1	94	KM186F-13000	Nozzie	1
14	36AH	Accumulator 12V	1	41	GB/T6177-2000	Nut M6	1	68	SU204-04000	Monopole Diade	1	95	KM186F-10500	High-pressure fuel pipe	1
15	KDE3300E-00002a	Accumulator washer	1	42	JB4110-85	Bolt M6×20	1	69	SU204-04001	Mutual Inductor	2	96	KM186F-12000	Fuel pump	1
16	KDE6500EW-03004	Accumulator pull rod	2	43	D50/1620 16A	Breaker	1	70	SU204-04002	Wiring	1	97	KM168F-30011	Fuel filler pipe hoop	2
17				44	250V-26A	Honda single-phase receptacle	2	7.1	GB5789-2006	Bolt M6*10	4	98	KDE65000EW-11001	Fuel filler pipe	1
18				45	KDE6500EW-13110H	Honda control panel	1	72	KDE6500EW-03020	Air guide plate weldment	1	99	GB/T6177-2000	Nut M6	2
19	KDE6500EW-08001	Decorate plate of coping		46	GB/T818-2000	Screw M6×16	4	73	GB5789-2006	Bolt M5*10	1	100	KM168F-10400	Fuel tank switch assembly	1
20	KDE5000X-30005	Bushing	- 4	47	KDE3500X-40000a	Electromagnet assembly	1	74	SU204-04003	Wiring	4	101	GB/T3452.1-1992	O-ring	1
21	KDE5000X-30004	Cushion	4	48				75	GB5789-2006	Bolt M6*10	- 1	102	GB/T819.1-2000	Screw M5 x 8	3
22				49	DCT-12-C	Electromagnet	1	76	SU204-04004	Wiring	1	103	KDE5000X-31006	Seal plate	1.
23				50	DCT-12-C	Iron-core	1	77	GB5789-2006	Bolt M5*16	1	104	KDE5000X-31007	Seal washer	1
24	7-			51	GB/T818-2000	Screw M5×18	2	78	GB97.1	Washer Ø 5	8	105	KM168F-10007	Seal wsher	1
25				52	KDE3500X-40006a	Electromagnet accumulator	- 1	79	SU204-04005	Wiring	1	106	KM168F-10300	Element assembly	1
26	,			53	KDE3500X-41000a	Flexible shaft unit	1	80	GB5789-2006	Bolt M5*20	1	107			
27				54	KDE6500EW-03400	Housing base weldment assembly	1	81	D104	Carbon brush	2	108			




2 CYLINDER HEAD ASSEMBLY


NO.	CODE	DESCRIPTION	
1	8602014	Air intake Gasket	1
2	8602200	Cylinder Head	1
3	8602003	Intake Valve	1
4	8602004	exhaust valve	1
5	8602015	Silencer Gasket	1
6	9905041	Pin4*8	1
7	8602007	Valve Spring Washer	2
8	8602005	Valve Spring	2
9	8602002	Spring Retainer	2
10	7002105	Valve Screw	2
11	9901060	Nut M6	2
12	8602106	Rocker Arm Bolt	1
13	8602103	Exhaust Valve Rocker Arm	1
14	8602102	Rocker Arm Support	- 1
15	8602101	Rocker Arm Shaft	1
16	8602104	Intake Valve Rocker Arm	1
17	8602016	Valve Adjusting Plate	2
18	8602001	Cotter	4
19	9901061	Nut M6	2
20	7002009	Nozzle Retainer	1
21	7002018	Spacer Washer	1
22	7002011	Spacer	1
23	9909062	Stud AM6*50	2
24	9909064	Stud AM6*55 AM6*75	2
25	9902070	Bolt M6*25	3
26	9909081	Stud AM8*20	2




3 CYLINDER HEAD BONNET ASSEMBLY




4 PISTON & CONNECTING ROD ASSEMBLY




5 CRANK SHAFT & FLYWHEEL ASSEMBLY




6 CAMSHAFT ASSEMBLY



7 AIR CLEANER ASSEMBLY




8 SILENCER ASSEMBLY



N O.	CODE	DESCRIPTION	Qty
1	8608100	Case Assem	1
2	9902061	Bolt M6∗8	10
3	8608200	Silencer Welded Assem	1
4	9903080	Washer8	2
5	9903081	Washer8	2
6	9901080	Nut M8	2
7	9902081	Bolt M8*12	2


9 LUBE OIL SYSTEM

N O.	CODE	DE DESCRIPTION			
1	9902061	Bolt M6*8	3		
2	7009003	Oil Pump Cover	1		
3	9702345	0-Ring34.5*1.8	1		
4	7009103	Outer Rotator	1		
5	700901	Inner Rotator	1		
6	869102	Oil Pump shaft	1		
7	9905031	Pin3*18	1		
8	7809004	Oil Pump Gear	1		
9	7809200	Oil filter Assem	1		
10	9702025	0-Ring25*2.4	1		
11	9902064	Bolt M6*14	1		
12	7809005	Intake Pipe	1		




SU170/SU178/SU186

N 0.	CODE	DESCRIPTION	Qty
1	7011401	Control Handle Shaft	1
2	7011402	Governor Handle Shaft Washer	2
3	7011006	Governorspring	1
4	7011005	Return Sping II	1
5	7011406	High speed Limit Screw	1
6	9901060	Nut M6	1
7	9902064	Bolt M6*14	1
8	9902069	Bolt M6*20	1
9	9901010	Nut M10*1.25	1
10	7011407	Bowl-Shape Cover	1
11	7011405	Spring	1
12	7011404	Handle Bracket	1
13	7011403	Control Handle	1
14	7011110	Governor Lever Welded Part	1
15	9700322	Pin3*22	2
16	8611601	Lever Fork	1
17	7011102	Lever Shaft	1
18	7011003	Governor Lever Washer	3
19	7011008	Seal8 × 14 × 2.5	1
20	7011004	Tappet	1
21	7011001	Fly Block	2
22	7011002	Fly Block Pin	2




11 FUFL INJECTION PUMP ASSEMBLY




NO.	CODE	CODE DESCRIPTION	
1	7012006	Delivery Holder	1
2	7012008	Delivery Spring	1
3	7012009	Delivery Gasket	1
4	7012201	Delivery Valve	1
5	7012202	Delivery Seat	1
6	7012400	Joint	1
7	7012005	0-Ring	1
8	8612101	F.I.prmp Body	1
9	8612100	Plunger	1
10	7012013	Shim Set	
11	9905206	Pin2*6	2
12	7012011	Packing	1
13	7012300	Control lever Assem	1
14	7012004	Snap Ring	1
15	9905308	Pin3*8	1
16	7012012	Spring Seat	2
17	7012016	F.I.Pump Spring	1
18	7012015	Spring Seat	1
19	7012014	Tappet	1


12 FUEL NOZZLE ASSEMBLY

14 COOLING DEVICE ASSEMBLY





13 RECOIL STARTER ASSEMBLY



15 STARTER & GENERATOR ASSEMBLY

