
C-10682 User Manual

size: 127(w) x 89(h) mm


Fosmon Mechanical 2 Outlet Timer



To Program:

There are 48 push buttons around the dial. Each is for a period of 30 minutes. When a push button is pressed down, the appliance connected to

the timer will be on during that period of time. When a push button is lifted up, the appliance plugged into the timer will be off during that period of time.



To Set Time Of Day:

Turn dial clockwise one full revolution then advance until arrow points to the current time. The dark area denotes PM and the white area denotes AM.

To Activate The Timer:

Slide the switch on the top of the timer to the right hand side.

