## Motorcycle Stock Handlebar Measurements - Harley Davidson, Triumph, Victory, Honda, Kawasaki, Suzuki, Yamaha, Buell, Ducati and Indian

Honda Model	Honda Description	Year Ba	r Diamete	r Heiaht	Width	Pullbac	<b>C</b> enter	Clamp Area	Factory #
GL 1500 C	Valkyrie	1997 - 2003	1"	6"	33"	14"	9"	3" x 5"	53100-MZ0-000
VTX 1800 C	Performance Cruiser (Risers 5"H x 3"PI		1"	3"	33"	12"			53100-MCH-000
VTX 1800 N	Neo Retro(Risers 5"H x 2"PB)	2004 - 2008	1"	5-1/2"	33-1/2"	12"	9"		53100-MCV-N10
VTX 1800 R/S/T	Retro / Classic Cruiser	2002 - 2007	1"	8"	33-1/2"	14"	9"		53100-MCV-000
VTX 1800 F	Sport Cruiser (Risers 5"H x 2"PB)	2005 - 2008	1"	4"		10-1/2"	8"	6-1/2" Solid	
VTX 1300 R/S	1300 Retro / Classic Cruiser	2002 - 2009	1"	5"	33"	12"	10"	4" x 6-1/2"	53100-MEA-670
VTX 1300C	1300 Cruiser (Welded Risers)	2004 - 2008	1"	3"	33"	6"			53100-MEM-670
VTX 1300T	1300 Retro Touring Cruiser	2008 - 2009	1"	6-1/2"	33"	13"	9"	4" x 6-1/2"	00.00
VTX 1300	Fury (Welded bars, no risers)	2010-2013	1-1/4"						
VTX 1300	Sabre (Welded Bar, No Risers)	2010 - 2013	1-1/4"						
VTX 1300	Stateline (Welded Bar, No Risers)	2010 - 2013	1-1/4"						
VTX 1300	Interstate (Welded Bar, No Risers)	2010 - 2013	1-1/4"						
CB 1100		2013	7/8"	5-1/2"	30"	10-1/2"	7"	3" x 5"	
VT 1100 T	Shadow 1100 ACE Tourer	1998 - 2001	1"				•	2-3/4" x 5"	50337-MM8-000
VT 1100 C-C2	Shadow 1100 ACE	1998 - 1999	1"						53100-MAH-A40
VT 1100 C3	Shadow Aero 1100	1998 - 2002	1"	6"	32"	12"	10"		50337-MBH-000
VT 1100 C2	Shadow Sabre 1100	2000 - 2007	1"	5-1/2"	33"	12"	6-1/2"	2-3/4" x 5"	53100-MCK-A00
VT 1100 G2 VT 1100 C	Shadow Spirit 1100	1998 - 2007	1"	8-1/2"	32"	11"	8"	2-3/4" x 5"	53100-MAA-A00
VT 750 CDA/B/C/D	Shadow 750 ACE Delux	2002 - 2003	1"	5"	32"	12-1/2"			53100-MBA-610
VT 750 C/CD/CD2	Shadow 750 / 750 Delux	1998 - 2001	1"	5"	32"	12-1/2"			53100-MBA-610
VT 750 C/OB/OB2	Shadow Aero 750 (Welded Risers)	2004 - 2007	1"	7"	32"	13"		Welded Risers	
VT 750	Shadow Aero 750	2008 - 2013	1"	7-1/2"	31-1/2"	13"	10"	2-3/4" x 5"	
VT 750 DC/AB	Shadow Spirit 750 (Risers 5-1/2"H x 3"I		1"	Drag Ba		7"	7-1/2"	2-3/4" x 5"	53100-MCL-000
VT 750 RS	Shadow Spirit 750 (Risers 5-1/2"H x 3"I	,	1"	5"	32"	, 12-1/2"			53100-MCL-000
VT 750 NO	Shadow Phantom (Welded Risers)	2010 - 2013	1"	Drag Ba		12 1/2	10 1/2	2014 70	00100 MOE 000
VF 750 C/C2	Magna 750	1994 - 2003	1"	5-1/2"	" 31"	10"	6-1/2"	2-3/4" x 5"	53100-MZ5-910
V1 730 0/02	Magna 700 / 750 / 1100	1982 - 1986	7/8"	J-1/2	31	10	0-1/2	2-3/4 X 3	33100-WZ3-310
	Nighthawk 750	1991 - 2003	7/8"	5-1/2"	28"	7-1/2"	6-1/2"	3" x 4-3/4"	53100-MW3-670
NV 700 V	Touring	2010 - <b>2013</b>	7/8"	6"	28"	9"	5-1/2"	4" one piece	33100-10100 3-070
DN 01	700cc	2010 - 2011	170	J	20	J	0 1/2	4 one piece	
VT 600 C	Shadow VLX / Delux	1999 - 2007	1"	5-1/2"	31"	11"	9"	3-1/4" x 5-1/2"	53100-MZ8-L50
CMX 250	Rebel 250	2001 - 2013	7/8"	5-1/2"	30"	10-1/2"	7"	3" x 5"	53100-KEN-670
CB 250	Nighthawk 250	1991 - 2008	7/8"	4"	26-1/2"	9"	5-1/2"	3" x 4-3/4"	53100-KBG-700
GL1100/1200	Gold Wing	1979 - 1986	7/8"	7	20 1/2	J	0 1/2	0 7 4 0/4	00100 KBC 700
GE1100/1200	919 Sportbike	2002 - 2007	7/8"	4"	26"	7-1/2"	5-1/2"		
	599 Sportbike	2004 - 2006	7/8"	4"	26"	7-1/2"	5-1/2"		
	ood opensing			•					
Kawasaki Model	Kawasaki Description			_				Clamp Area	
VN 2000	Vulcan 2000 Classic, Classic LT	2004 - 2011	1"		34-1/2"	14"	7-1/2"		46003-0047
VN 1700	Vulcan 1700 Voyager	2009	1"	8"	35"	15"	6-1/2"	2" x 5"	
VN 1700	Vulcan 1700 Voyager	2010 - <mark>2013</mark>	1-1/4"	8"	33-1/2"		6-1/2"	2" x 5"	
VN 1700	Vulcan 1700 Classic LT	2009 - 2010	1"	8"	35"	15"	6-1/2"	2" x 5"	
VN 1700	Vulcan 1700 Nomad	2009 - <mark>2013</mark>	1"	8"	35"	15"	6-1/2"	2" x 5"	
VN 1700	Vulcan 1700 Vaquero	2011 - <mark>2013</mark>	1-1/4"	10"	33-1/2	15"	7-1/2"	2" x 5"	
VN 1600 A1/A2	Vulcan 1600 Classic	2003 - 2005	1"	6"	33"	14"	9"	2" x 5"	46003-0011
VN 1600	Vulcan 1600 Classic	2006 - 2008	1"	8"	34"	14"	8"	2" x 5"	
VN 1600	Vulcan Mean Streak (Weld Risers 7"Hx	(4 <b>219036)</b> - 2008	1"	Drag Ba	ır 29"	6"	8"	Welded Risers	
VN 1600	Vulcan 1600 Nomad	2006 - 2008	1"	8"	34-1/2"	14"	7"	2" x 5"	
VN 1500 L5	Vulcan 1500 Nomad	1999 - 2005	1"	6"	33"	14"	9"	2" x 5"	46003-1544
VN 1500	Vulcan 1500	1999 - 2001	1"	6"	33"	14"	9"	2" x 5"	46003-1551
VN 1500 N1-N3	Vulcan 1500 Classic / Classic Anniversity	sa21902 - 2008	1"	6"	33"	14"	9"	2" x 5"	46003-1479
VN 1500 R1-R4	Vulcan 1500 Drifter	2001 - 2005	1"	5"	33-1/2"	14"	6-1/2"	2" x 5"	46003-1556
VN 1500 P1/P2	Vulcan 1500 Mean Streak	2003 - 2005	1"	Drag Ba		6"		Welded Risers	
ZR 1200 A1-A3	ZRX 1200R	2001 - 2003	7/8"	3-1/2"	27"	7-1/2"		2-3/4" x 4-3/8"	
ZR 1000 A1/A2	Z 1000	2003 - 2007	7/8"	3-1/2"	27"	7-1/2"	5-1/2"	2-3/4" x 4-3/8"	46003-1594

Z 750 S		2005	7/8"	3-1/2"	27"	7-1/2"	5-1/2"	2-3/4" x 4-3/8"	
VN 900	Vulcan 900 Custom (Weld Risers 7"Hx		1"	Drag Bar		6"	8"	Welded Risers	i e
VN 900	Vulcan 900 Classic / Classic LT / SE	2006 - 2013	1"	7"	34"	14"	8"	2" x 5"	10000 1150
VN 800 A1-A11 VN 800 B7-B9	Vulcan 800 Vulcan 800 Classic	1995 - 2005 2001 - 2005	1" 1"		32-1/2" 32-1/2"	12" 12"	7" 7"	2" x 5" 2" x 5"	46003-1459 46003-1458
VN 800 E1-E4	Vulcan 800 Drifter	2001 - 2006	1"		33-1/2"	14"	6-1/2"	2" x 5"	46003-1558
VN 750 A1-A21	Vulcan 750	1994 - 2006	7/8"	8"	31"	11"	5-1/2"	3" x 5"	46003-1179
Suzuki Model	Suzuki Description	Year Ba	r Diamet	er Height V	Width I	Pullbac	<b>K</b> Cente	r Clamp Area	
M109R/RC	Boulevard, Ltd (1800) Risers 8" H x 4"	,	1-1/4"	Drag Bar		8"	8"	4" x 6-1/2"	
C109 R/RT	Boulevard, Cruiser/Touring	2008 - 2009	1"	8"	35"	14"	8"	3-3/4" x 6-1/2"	
M95 M90	Boulevard (1600) Boulevard (1500) (Risers 6"H x 4"PB)	2005 2009 - <mark>2013</mark>	1"	Drag Bar	33"	7-1/2"	9"	T-Bars 4" x 6-1/2"	
VL 1500	Intruder	1998 - 2004	1"	6-1/2"	32"	13"	8-1/2"	3" x 4-3/4"	56111-10F00
C90 / Black / T	Boulevard (1500)	2005 - <mark>2013</mark>	1"		33-1/2"	14"	8-1/2"	2-3/4" x 5"	56111-10FA0
C50 /C / Black /T	Boulevard (800) T & SE	2005 - <mark>2013</mark>	1"	5" 3	33-1/2"	14"	8-1/2"	2-3/4" x 5"	56111-41F00
M50 / Black	M50 Boulevard (800) Risers 5"H x 4" P		1"	4"		10-1/2"	7"	4" x 6"	
VS 1400 / VS 800	Intruder 1400 / 800	1998 - 2004	1"	6-1/2"		10-1/2"	6"	3" x 5"	56111-38E00
S83 / S50 / S40 B-King 1300 /ABS	Boulevard (1300/800/650) Risers 6"H x	47 <b>208</b> 05 - 2009 2008 - 2009	1" 7/8"	Drag Bar 3-1/2" 2		6" 6"	5-1/2" 6"	3-1/4" x 5" 4-3/4" one pied	56111-38E00
DL 1000	1000 V Strom	2004 - 2009	7/8"	3-1/2 2 4"	30"	9-1/2"	6"	2-3/4" x 4-1/2"	, <b>c</b>
GSF 1200/1250	Bandit 1200/1250	2001 - 2008	7/8"	3"	26"	6"		2-3/4" x 4-1/2"	56111-32F00
VL 800	Volusia Intruder	1999 - 2004	1"	6"	34"	13"	8-1/2"	3" x 5"	56111-41F00
SV 1000 S	SV 1000	2003 - 2008	7/8"	3"	26"	6"	5-1/2"	2-3/4" x 4-1/2"	56111-16G10
SV 650	SV 650	2004 - 2010	7/8"	3-1/2"	26"	7-1/2"	5"	3" x 4-3/4"	56111-17G10
DL 650	650 V-Strom	2006 - 2009	7/8"	4" 7" 0	30"	8" 44"	6"	2-3/4" x 4-1/2"	EC140 24D42
LS 650 GSX 650X / F	Savage 650	1996 - 2004 2008 - 2010	1" 7/8"		27-1/2" 27-1/2"	11" 7-1/2"	5-1/2" 6"	3" x 4-3/4" 3" x 4-3/4"	56110-24B43
GSF 600 S	Bandit 600S	1997 - 2003	7/8"		26-1/2"	7-1/2	5-1/2"	2-1/4" x 4"	56111-31F01
GS 500 F	GS 500	2002 - 2010	7/8"		27-1/2"		6"	3" x 4-3/4"	
GZ 250	GZ 250	2002 - 2010	7/8"	7"	28"	10"	6"	2-1/4 x 4"	56111-12FA0
GZ 250 LS	GZ 250 LS	2002	1"	7" 2	27-1/2"	11"	5-1/2"	3 x 4-3/4"	
	Maurader 800	2001 - 2004	1"					Welded T- Bars	
Yamaha Model	Maurader 1600 Yamaha Description	2004 Year Ba	r Diamot	or Hoight V	Nidth I	Dullhac	<b>C</b> onto	Welded T- Bar r Clamp Area	S
	•			•				•	
XV 19 XV 19	Stratoliner, S, Midnight Deluxe (1900) Roadliner, S, Midnight (1900)	2006 - <mark>2013</mark> 2006 - <mark>2013</mark>	1-1/4" 1-1/4"		36-1/2" 36-1/2"	14" 14"	7-1/2" 7-1/2"	6" one piece 6" one piece	
XV19	Raider, S (Risers 5-1/2"H - 4"PB)		1"	3"	32"	7"	7-1/2"	6" one piece	
	Royal Star Venture	2002 - 2013	1"	6"	31"	14"		2-1/2" x 5-3/8"	
	Royal Star Tour Delux	2006 - 2009	1"	8"	33"	16-1/2"	8"	2-1/2" x 5-3/8"	
XV 1600	Road Star, Midnight Star	1999 - 2007	1"	7"	33"	13"	8"		4WM-26111-00-00
XV 1600	Road Star Silverado / Midnight Silverad		1"	8"	32"	13"	7"		5GA-26111-00-00
XV 1600	Road Star S, Silverado S	1999 - <mark>2013</mark>		6"	32"	13"	7"	2-1/2" x 5-3/8"	
	Marriar Midnight (1700)	2004 2010	1" 1"					2 1/2" v 5 2/0"	
	Warrior, Midnight (1700)	2004 - 2010 2002 - 2003	1"	5-1/2"	34"	13"	7"	2-1/2" x 5-3/8"	
	Warrior	2004 - 2010 2002 - 2003 2011 - 2013			34"			2-1/2" x 5-3/8" 2-1/2" x 5-3/8"	
	• • • • • • • • • • • • • • • • • • • •	2002 - 2003	1"	5-1/2"	34"	13"	7"		
XVS 1100	Warrior Stryker (Welded Bars, No Risers)	2002 - 2003 2011 - <mark>2013</mark>	1" 1"	5-1/2" 6"	34" 34"	13" 11-1/2"	7" 7"	2-1/2" x 5-3/8" 3-1/4" x 7"	
XVS 1100	Warrior Stryker (Welded Bars, No Risers) V-Star 1300 / Tourer V-Star 1100 Silverado V-Star 1100 Custom/Classic	2002 - 2003 2011 - 2013 2007 - 2013 2004 - 2009 2002 - 2009	1" 1" 1" 1" 1"	5-1/2" 6" 8" 6-1/2" 7-1/2"	34" 34" 35" 33" 33"	13" 11-1/2" 13" 13" 12"	7" 7" 8" 8" 6-1/2"	2-1/2" x 5-3/8" 3-1/4" x 7" 2-1/2" x 5-3/8" 2-1/2" x 5-3/8	
XVS 1100 XVS950	Warrior Stryker (Welded Bars, No Risers) V-Star 1300 / Tourer V-Star 1100 Silverado V-Star 1100 Custom/Classic V-Star 950 / Tourer	2002 - 2003 2011 - 2013 2007 - 2013 2004 - 2009 2002 - 2009 2009 - 2013	1" 1" 1" 1" 1"	5-1/2" 6" 8" 6-1/2" 7-1/2"	34" 34" 35" 33" 33" 35"	13" 11-1/2" 13" 13" 12" 16"	7" 7" 8" 8" 6-1/2" 7-1/2"	2-1/2" x 5-3/8" 3-1/4" x 7" 2-1/2" x 5-3/8" 2-1/2" x 5-3/8" 2-1/2" x 5-3/8"	5KS-26111-00-00 "5EL-26111-10-00
XVS 1100 XVS950 XVS 650	Warrior Stryker (Welded Bars, No Risers) V-Star 1300 / Tourer V-Star 1100 Silverado V-Star 1100 Custom/Classic V-Star 950 / Tourer V-Star 650 Classic, Silverado	2002 - 2003 2011 - 2013 2007 - 2013 2004 - 2009 2002 - 2009 2009 - 2013 1998 - 2010	1" 1" 1" 1" 1" 1"	5-1/2" 6" 8" 6-1/2" 7-1/2" 7" 5"	34" 34" 35" 33" 33" 35" 31"	13" 11-1/2" 13" 13" 12" 16" 12"	7" 7" 8" 8" 6-1/2" 7-1/2"	2-1/2" x 5-3/8" 3-1/4" x 7" 2-1/2" x 5-3/8" 2-1/2" x 5-3/8" 2-1/2" x 5-3/8" 2-1/2" x 5-3/8	5KS-26111-00-00 "5EL-26111-10-00 "5BN-26111-10-00
XVS 1100 XVS 950 XVS 650 XVS 650	Warrior Stryker (Welded Bars, No Risers) V-Star 1300 / Tourer V-Star 1100 Silverado V-Star 1100 Custom/Classic V-Star 950 / Tourer V-Star 650 Classic, Silverado V-Star 650 Custom	2002 - 2003 2011 - 2013 2007 - 2013 2004 - 2009 2002 - 2009 2009 - 2013 1998 - 2010 1998 - 2010	1" 1" 1" 1" 1" 1" 1"	5-1/2" 6" 8" 6-1/2" 7-1/2" 7" 5" 6-1/2"	34" 34" 35" 33" 33" 35" 31" 30"	13" 11-1/2" 13" 13" 12" 16" 12" 10-1/2"	7" 7" 8" 8" 6-1/2" 7-1/2" 7-1/2"	2-1/2" x 5-3/8" 3-1/4" x 7" 2-1/2" x 5-3/8" 2-1/2" x 5-3/8" 2-1/2" x 5-3/8" 2-1/2" x 5-3/8 2-1/2" x 5-3/8	5KS-26111-00-00 l'5EL-26111-10-00 l'5BN-26111-10-00 l'4VR-26111-10-00
XVS 1100 XVS950 XVS 650	Warrior Stryker (Welded Bars, No Risers) V-Star 1300 / Tourer V-Star 1100 Silverado V-Star 1100 Custom/Classic V-Star 950 / Tourer V-Star 650 Classic, Silverado	2002 - 2003 2011 - 2013 2007 - 2013 2004 - 2009 2002 - 2009 2009 - 2013 1998 - 2010 1998 - 2010 1997 - 2007	1" 1" 1" 1" 1" 1" 1" 1" 7/8"	5-1/2" 6" 8" 6-1/2" 7-1/2" 7" 5" 6-1/2" 3"	34" 34" 35" 33" 33" 35" 31"	13" 11-1/2" 13" 13" 12" 16" 12"	7" 7" 8" 8" 6-1/2" 7-1/2"	2-1/2" x 5-3/8" 3-1/4" x 7" 2-1/2" x 5-3/8" 2-1/2" x 5-3/8" 2-1/2" x 5-3/8" 2-1/2" x 5-3/8 2-1/2" x 5-3/8	5KS-26111-00-00 "5EL-26111-10-00 "5BN-26111-10-00
XVS 1100 XVS 950 XVS 650 XVS 650 VMX 12	Warrior Stryker (Welded Bars, No Risers) V-Star 1300 / Tourer V-Star 1100 Silverado V-Star 1100 Custom/Classic V-Star 950 / Tourer V-Star 650 Classic, Silverado V-Star 650 Custom V-Max	2002 - 2003 2011 - 2013 2007 - 2013 2004 - 2009 2002 - 2009 2009 - 2013 1998 - 2010 1998 - 2010	1" 1" 1" 1" 1" 1" 1" 1" 7/8"	5-1/2" 6" 8" 6-1/2" 7-1/2" 7" 5" 6-1/2" 3"	34" 34" 35" 33" 33" 35" 31" 30"	13" 11-1/2" 13" 13" 12" 16" 12" 10-1/2"	7" 7" 8" 8" 6-1/2" 7-1/2" 7-1/2"	2-1/2" x 5-3/8" 3-1/4" x 7" 2-1/2" x 5-3/8" 2-1/2" x 5-3/8" 2-1/2" x 5-3/8" 2-1/2" x 5-3/8 2-1/2" x 5-3/8	5KS-26111-00-00 l'5EL-26111-10-00 l'5BN-26111-10-00 l'4VR-26111-10-00
XVS 1100 XVS 950 XVS 650 XVS 650 VMX 12 VMX 12 XV 250/XVS250 FZS 1000	Warrior Stryker (Welded Bars, No Risers) V-Star 1300 / Tourer V-Star 1100 Silverado V-Star 1100 Custom/Classic V-Star 950 / Tourer V-Star 650 Classic, Silverado V-Star 650 Custom V-Max V-Max Virago 250/V-Star 250 FZ-1	2002 - 2003 2011 - 2013 2007 - 2013 2004 - 2009 2002 - 2009 2009 - 2013 1998 - 2010 1997 - 2007 2009 - 2010Tal 1997 - 2013 2001 - 2005	1" 1" 1" 1" 1" 1" 1" 7/8" oer Down 7/8" 7/8"	5-1/2" 6" 8" 6-1/2" 7-1/2" 7" 5" 6-1/2" 3" Bar 9-1/2"	34" 34" 35" 33" 35" 31" 30" 27"	13" 11-1/2" 13" 13" 12" 16" 12" 7" 10-1/2" 7"	7" 7" 8" 8" 6-1/2" 7-1/2" 7-1/2" 6-1/2" 6" 6" 5"	2-1/2" x 5-3/8"  3-1/4" x 7"  2-1/2" x 5-3/8"  2-1/2" x 5-3/8"  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5"  3" x 4-3/4"  2-1/2" x 4"	5KS-26111-00-00 l'5EL-26111-10-00 l'5BN-26111-10-00 l'4VR-26111-10-00 1FK-26111-10-00
XVS 1100 XVS 950 XVS 650 XVS 650 VMX 12 VMX 12 XV 250/XVS250 FZS 1000 FZS 1000	Warrior Stryker (Welded Bars, No Risers) V-Star 1300 / Tourer V-Star 1100 Silverado V-Star 1100 Custom/Classic V-Star 950 / Tourer V-Star 650 Classic, Silverado V-Star 650 Custom V-Max V-Max Virago 250/V-Star 250 FZ-1 FZ-1	2002 - 2003 2011 - 2013 2007 - 2013 2004 - 2009 2002 - 2009 2009 - 2013 1998 - 2010 1997 - 2007 2009 - 2010Tal 1997 - 2013 2001 - 2005 2006 - 2010	1" 1" 1" 1" 1" 1" 1" 7/8" oer Down 7/8" 7/8"	5-1/2" 6" 8" 6-1/2" 7-1/2" 7" 5" 6-1/2" 3" Bar 9-1/2" 3" Drag Bar	34" 34" 35" 33" 35" 31" 30" 27" 30" 26" 26"	13" 11-1/2" 13" 12" 16" 12" 10-1/2" 7" 11" 6-1/2" 6"	7" 7" 8" 8" 6-1/2" 7-1/2" 7-1/2" 6-1/2" 6" 6" 5"	2-1/2" x 5-3/8"  3-1/4" x 7"  2-1/2" x 5-3/8"  2-1/2" x 5-3/8"  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5"  3" x 4-3/4"  2-1/2" x 4"  2-1/2" x 4"	5KS-26111-00-00 1"5EL-26111-10-00 1"5BN-26111-10-00 1"4VR-26111-10-00 1FK-26111-10-00 2UJ-26111-00-00 5LV-26111-00-00
XVS 1100 XVS 950 XVS 650 XVS 650 VMX 12 VMX 12 XV 250/XVS250 FZS 1000 FZS 1000 FZ 600	Warrior Stryker (Welded Bars, No Risers) V-Star 1300 / Tourer V-Star 1100 Silverado V-Star 1100 Custom/Classic V-Star 950 / Tourer V-Star 650 Classic, Silverado V-Star 650 Custom V-Max V-Max Virago 250/V-Star 250 FZ-1 FZ-1 FZ-6	2002 - 2003 2011 - 2013 2007 - 2013 2004 - 2009 2002 - 2009 2009 - 2013 1998 - 2010 1997 - 2007 2009 - 2010Tal 1997 - 2013 2001 - 2005 2006 - 2010 2004 - 2010	1" 1" 1" 1" 1" 1" 1" 7/8" 7/8" 7/8" 7/8" 7/8"	5-1/2" 6" 8" 6-1/2" 7-1/2" 7" 5" 6-1/2" 3" Bar 9-1/2" 3" Drag Bar 3"	34" 34" 35" 33" 35" 31" 30" 27" 30" 26" 26" 26"	13" 11-1/2"  13" 12" 16" 12" 10-1/2" 7"  11" 6-1/2" 6" 6-1/2"	7" 7" 8" 8" 6-1/2" 7-1/2" 7-1/2" 6-1/2" 6" 5" 5"	2-1/2" x 5-3/8"  3-1/4" x 7"  2-1/2" x 5-3/8"  2-1/2" x 5-3/8"  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5"  3" x 4-3/4"  2-1/2" x 4"  2-1/2" x 4"  2-1/2" x 4"	5KS-26111-00-00 1"5EL-26111-10-00 1"5BN-26111-10-00 1"4VR-26111-10-00 1FK-26111-10-00
XVS 1100 XVS 950 XVS 650 XVS 650 VMX 12 VMX 12 XV 250/XVS250 FZS 1000 FZS 1000	Warrior Stryker (Welded Bars, No Risers) V-Star 1300 / Tourer V-Star 1100 Silverado V-Star 1100 Custom/Classic V-Star 950 / Tourer V-Star 650 Classic, Silverado V-Star 650 Custom V-Max V-Max Virago 250/V-Star 250 FZ-1 FZ-1 FZ-6 Triumph Description	2002 - 2003 2011 - 2013 2007 - 2013 2004 - 2009 2002 - 2009 2009 - 2013 1998 - 2010 1997 - 2007 2009 - 2010Ta 1997 - 2013 2001 - 2005 2006 - 2010 2004 - 2010 Year Ba	1" 1" 1" 1" 1" 1" 7/8" 7/8" 7/8" 7/8" 7/8" 7/8"	5-1/2" 6" 8" 6-1/2" 7" 5" 6-1/2" 3" Bar 9-1/2" 3" Drag Bar 3" er Height V	34" 34" 35" 33" 35" 31" 30" 27" 30" 26" 26" 26"	13" 11-1/2"  13" 12" 16" 12" 10-1/2" 7"  11" 6-1/2" 6" 6-1/2" Pullbac	7" 7" 8" 8" 6-1/2" 7-1/2" 7-1/2" 6" 6" 5" 5" KCente	2-1/2" x 5-3/8"  3-1/4" x 7"  2-1/2" x 5-3/8"  2-1/2" x 5-3/8"  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5"  3" x 4-3/4"  2-1/2" x 4"  2-1/2" x 4"  2-1/2" x 4"  r Clamp Area	5KS-26111-00-00 1"5EL-26111-10-00 1"5BN-26111-10-00 1"4VR-26111-10-00 1FK-26111-10-00 2UJ-26111-00-00 5LV-26111-00-00
XVS 1100 XVS 950 XVS 650 XVS 650 VMX 12 VMX 12 XV 250/XVS250 FZS 1000 FZS 1000 FZ 600	Warrior Stryker (Welded Bars, No Risers) V-Star 1300 / Tourer V-Star 1100 Silverado V-Star 1100 Custom/Classic V-Star 950 / Tourer V-Star 650 Classic, Silverado V-Star 650 Custom V-Max V-Max Virago 250/V-Star 250 FZ-1 FZ-1 FZ-6	2002 - 2003 2011 - 2013 2007 - 2013 2004 - 2009 2002 - 2009 2009 - 2013 1998 - 2010 1997 - 2007 2009 - 2010Tal 1997 - 2013 2001 - 2005 2006 - 2010 2004 - 2010	1" 1" 1" 1" 1" 1" 1" 7/8" 7/8" 7/8" 7/8" 7/8"	5-1/2" 6" 8" 6-1/2" 7-1/2" 7" 5" 6-1/2" 3" Bar 9-1/2" 3" Drag Bar 3"	34" 34" 35" 33" 35" 31" 30" 27" 30" 26" 26" 26"	13" 11-1/2"  13" 12" 16" 12" 10-1/2" 7"  11" 6-1/2" 6" 6-1/2"	7" 7" 8" 8" 6-1/2" 7-1/2" 7-1/2" 6" 6" 5" 5" KCente	2-1/2" x 5-3/8"  3-1/4" x 7"  2-1/2" x 5-3/8"  2-1/2" x 5-3/8"  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5"  3" x 4-3/4"  2-1/2" x 4"  2-1/2" x 4"  2-1/2" x 4"	5KS-26111-00-00 1"5EL-26111-10-00 1"5BN-26111-10-00 1"4VR-26111-10-00 1FK-26111-10-00 2UJ-26111-00-00 5LV-26111-00-00
XVS 1100 XVS 950 XVS 650 XVS 650 VMX 12 VMX 12 XV 250/XVS250 FZS 1000 FZS 1000 FZ 600	Warrior Stryker (Welded Bars, No Risers) V-Star 1300 / Tourer V-Star 1100 Silverado V-Star 1100 Custom/Classic V-Star 950 / Tourer V-Star 650 Classic, Silverado V-Star 650 Custom V-Max V-Max V-Max Virago 250/V-Star 250 FZ-1 FZ-1 FZ-6 Triumph Description Rocket III Bonneville & T100 Bonneville & T100	2002 - 2003 2011 - 2013 2007 - 2013 2004 - 2009 2002 - 2009 2009 - 2013 1998 - 2010 1997 - 2007 2009 - 2010Tal 1997 - 2013 2001 - 2005 2006 - 2010 2004 - 2010 Year Ba 2005 - 2013	1" 1" 1" 1" 1" 1" 7/8" 7/8" 7/8" 7/8" 7/8" 7/8"	5-1/2" 6" 8" 6-1/2" 7" 5" 6-1/2" 3" Bar 9-1/2" 3" Drag Bar 3" er Height V	34" 34" 35" 33" 35" 31" 30" 27" 30" 26" 26" 26" Width I 35"	13" 11-1/2"  13" 12" 16" 12" 10-1/2" 7"  11" 6-1/2" 6" 6-1/2" Pullbac 14"	7" 7" 8" 8" 6-1/2" 7-1/2" 6-1/2" 6" 5" 5" KCente 6" 5-1/2" 5-1/2"	2-1/2" x 5-3/8"  3-1/4" x 7"  2-1/2" x 5-3/8"  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5"  3" x 4-3/4"  2-1/2" x 4"  2-1/2" x 4"  2-1/2" x 4"  7 Clamp Area  5-1/4"  2-3/4" x 4-1/2"  4-1/4" one picc	5KS-26111-00-00 1"5EL-26111-10-00 1"5BN-26111-10-00 1"4VR-26111-10-00 1FK-26111-10-00 2UJ-26111-00-00 5LV-26111-00-00
XVS 1100 XVS 950 XVS 650 XVS 650 VMX 12 VMX 12 XV 250/XVS250 FZS 1000 FZS 1000 FZ 600	Warrior Stryker (Welded Bars, No Risers) V-Star 1300 / Tourer V-Star 1100 Silverado V-Star 1100 Custom/Classic V-Star 950 / Tourer V-Star 650 Classic, Silverado V-Star 650 Custom V-Max V-Max V-Max Virago 250/V-Star 250 FZ-1 FZ-1 FZ-6 Triumph Description Rocket III Bonneville & T100 Bonneville & T100 Bonneville & T100	2002 - 2003 2011 - 2013 2007 - 2013 2004 - 2009 2002 - 2009 2009 - 2013 1998 - 2010 1997 - 2007 2009 - 2010Tai 1997 - 2013 2001 - 2005 2006 - 2010 2004 - 2010 Year Ba 2005 - 2013 2002 - 2003 2004 - 2005 2011 - 2013	1" 1" 1" 1" 1" 1" 7/8" 7/8" 7/8" 7/8" 7/8" 7/8" 1" 1" 1" 1"	5-1/2" 6" 8" 6-1/2" 7" 5" 6-1/2" 3" Bar 9-1/2" 3" Drag Bar 3" er Height V 9" 6"	34" 34" 35" 33" 35" 31" 30" 27" 30" 26" 26" 26" Width I 35" 28"	13" 11-1/2"  13" 12" 16" 12" 10-1/2" 7"  6-1/2" 6" 6-1/2" Pullbac 14" 8"	7" 7" 8" 8" 6-1/2" 7-1/2" 6-1/2" 6" 5" 5" KCente 6" 5-1/2" 5-1/2"	2-1/2" x 5-3/8"  3-1/4" x 7"  2-1/2" x 5-3/8"  2-1/2" x 5-3/8"  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5"  3" x 4-3/4"  2-1/2" x 4"  4-1/4" one piece  2-3/4" x 4-3/4"	5KS-26111-00-00 1"5EL-26111-10-00 1"5BN-26111-10-00 1"4VR-26111-10-00 1FK-26111-10-00 2UJ-26111-00-00 5LV-26111-00-00
XVS 1100 XVS 950 XVS 650 XVS 650 VMX 12 VMX 12 XV 250/XVS250 FZS 1000 FZS 1000 FZ 600	Warrior Stryker (Welded Bars, No Risers) V-Star 1300 / Tourer V-Star 1100 Silverado V-Star 1100 Custom/Classic V-Star 950 / Tourer V-Star 650 Classic, Silverado V-Star 650 Custom V-Max V-Max V-Max Virago 250/V-Star 250 FZ-1 FZ-6 Triumph Description Rocket III Bonneville & T100 Bonneville & T100 Bonneville & T100 Bonneville	2002 - 2003 2011 - 2013 2007 - 2013 2004 - 2009 2002 - 2009 2009 - 2013 1998 - 2010 1997 - 2007 2009 - 2010Tai 1997 - 2013 2001 - 2005 2006 - 2010 2004 - 2010 Year Ba 2005 - 2013 2004 - 2005 2004 - 2005 2011 - 2013 2001	1" 1" 1" 1" 1" 1" 7/8" 7/8" 7/8" 7/8" 7/8" 1" 1" 1" 1" 1"	5-1/2" 6" 8" 6-1/2" 7" 5" 6-1/2" 3" Bar 9-1/2" 3" Drag Bar 3" er Height V 9" 6" 5" 6-1/2"	34" 34" 35" 33" 35" 31" 30" 27" 30" 26" 26" 26" 28" 28" 28" 29"	13" 11-1/2"  13" 12" 16" 12" 10-1/2" 7" 6-1/2" 6" 6-1/2" Pullbac 14" 8" 8" 10"	7" 7" 8" 8" 6-1/2" 7-1/2" 6-1/2" 6" 6" 5" 5" Keente 6" 5-1/2" 5-1/2"	2-1/2" x 5-3/8"  3-1/4" x 7"  2-1/2" x 5-3/8"  2-1/2" x 5-3/8"  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5"  3" x 4-3/4"  2-1/2" x 4"  2-1/2" x 4"  2-1/2" x 4"  2-1/2" x 4"  2-1/4" x 4-1/2"  4-1/4" one piecc  2-3/4" x 4-3/4"  2-3/4" x 4-1/2"	5KS-26111-00-00 "5EL-26111-10-00 "5BN-26111-10-00 "4VR-26111-10-00 1FK-26111-00-00 5LV-26111-00-00 5VX-26111-00-00
XVS 1100 XVS 950 XVS 650 XVS 650 VMX 12 VMX 12 XV 250/XVS250 FZS 1000 FZS 1000 FZ 600	Warrior Stryker (Welded Bars, No Risers) V-Star 1300 / Tourer V-Star 1100 Silverado V-Star 1100 Custom/Classic V-Star 950 / Tourer V-Star 650 Classic, Silverado V-Star 650 Custom V-Max V-Max V-Max Virago 250/V-Star 250 FZ-1 FZ-6 Triumph Description Rocket III Bonneville & T100 Bonneville & T100 Bonneville Bonneville America	2002 - 2003 2011 - 2013 2007 - 2013 2004 - 2009 2002 - 2009 2009 - 2013 1998 - 2010 1997 - 2007 2009 - 2010Tai 1997 - 2013 2001 - 2005 2006 - 2010 2004 - 2010 Year Ba 2005 - 2013 2004 - 2005 2004 - 2005 2011 - 2013 2001 2001 2001	1" 1" 1" 1" 1" 1" 7/8" oer Down 7/8" 7/8" 7/8" 7/8" 1" 1" 1" 1" 1" 1"	5-1/2" 6" 8" 6-1/2" 7-1/2" 7" 5" 6-1/2" 3" Bar 9-1/2" 3" Drag Bar 3" er Height V 9" 6" 5" 6-1/2"	34" 34" 35" 33" 35" 31" 30" 27" 30" 26" 26" 26" 28" 28" 28" 29"	13" 11-1/2"  13" 12" 16" 12" 10-1/2" 7"  11" 6-1/2" 6" 6-1/2" 8" 8" 10" 11"	7" 7" 8" 8" 6-1/2" 7-1/2" 6-1/2" 6" 6" 5" 5" Kente 6" 5-1/2" 5-1/2"	2-1/2" x 5-3/8"  3-1/4" x 7"  2-1/2" x 5-3/8"  2-1/2" x 5-3/8"  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5"  3" x 4-3/4"  2-1/2" x 4"  2-1/4" x 4-1/2"  4-1/4" one piece  2-3/4" x 4-1/2"  2-3/4" x 4-1/2"  2-3/4" x 4-1/2"	5KS-26111-00-00 "5EL-26111-10-00 "5BN-26111-10-00 "4VR-26111-10-00 1FK-26111-00-00 5LV-26111-00-00 5VX-26111-00-00
XVS 1100 XVS 950 XVS 650 XVS 650 VMX 12 VMX 12 XV 250/XVS250 FZS 1000 FZS 1000 FZ 600	Warrior Stryker (Welded Bars, No Risers) V-Star 1300 / Tourer V-Star 1100 Silverado V-Star 1100 Custom/Classic V-Star 950 / Tourer V-Star 650 Classic, Silverado V-Star 650 Custom V-Max V-Max V-Max Virago 250/V-Star 250 FZ-1 FZ-1 FZ-6 Triumph Description Rocket III Bonneville & T100 Bonneville & T100 Bonneville Bonneville America Bonneville America	2002 - 2003 2011 - 2013 2007 - 2013 2004 - 2009 2002 - 2009 2009 - 2013 1998 - 2010 1997 - 2007 2009 - 2010Τα  1997 - 2013 2001 - 2005 2006 - 2010 2004 - 2010 Year Ba 2005 - 2013 2004 - 2005 2011 - 2013 2001 2001 - 2013 2001 2001 - 2013	1" 1" 1" 1" 1" 1" 7/8" DET DOWN 7/8" 7/8" 7/8" 7/8" 1" 1" 1" 1" 1" 1" 1"	5-1/2" 6" 8" 6-1/2" 7" 5" 6-1/2" 3" Bar 9-1/2" 3" Drag Bar 3" er Height V 9" 6" 5" 6-1/2"	34" 34" 35" 33" 35" 31" 30" 27" 30" 26" 26" 26" 28" 28" 28" 29" 34" 32"	13" 11-1/2"  13" 12" 16" 12" 10-1/2" 7"  11" 6-1/2" 6" 6-1/2" 8" 8" 10"  11" 15"	7" 7" 8" 8" 6-1/2" 7-1/2" 6-1/2" 6" 5" 5" Kente 6" 5-1/2" 5-1/2" 5-1/2" 6-1/2"	2-1/2" x 5-3/8"  3-1/4" x 7"  2-1/2" x 5-3/8"  2-1/2" x 5-3/8"  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5"  3" x 4-3/4"  2-1/2" x 4"  2-1/2" x 4"  2-1/2" x 4"  2-1/2" x 4"  2-1/4" x 4-1/2"  4-1/4" one piecc  2-3/4" x 4-3/4"  2-3/4" x 4-1/2"  2-3/4" x 4-1/2"  2-3/4" x 4-1/2"  2" x 4-3/4"	5KS-26111-00-00 "5EL-26111-10-00 "5BN-26111-10-00 "4VR-26111-10-00 1FK-26111-00-00 5LV-26111-00-00 5VX-26111-00-00
XVS 1100 XVS 950 XVS 650 XVS 650 VMX 12 VMX 12 XV 250/XVS250 FZS 1000 FZS 1000 FZ 600	Warrior Stryker (Welded Bars, No Risers) V-Star 1300 / Tourer V-Star 1100 Silverado V-Star 1100 Custom/Classic V-Star 950 / Tourer V-Star 650 Classic, Silverado V-Star 650 Custom V-Max V-Max V-Max Virago 250/V-Star 250 FZ-1 FZ-6 Triumph Description Rocket III Bonneville & T100 Bonneville & T100 Bonneville Bonneville America	2002 - 2003 2011 - 2013 2007 - 2013 2004 - 2009 2002 - 2009 2009 - 2013 1998 - 2010 1997 - 2007 2009 - 2010Tai 1997 - 2013 2001 - 2005 2006 - 2010 2004 - 2010 Year Ba 2005 - 2013 2004 - 2005 2004 - 2005 2011 - 2013 2001 2001 2001	1" 1" 1" 1" 1" 1" 7/8" oer Down 7/8" 7/8" 7/8" 7/8" 1" 1" 1" 1" 1" 1"	5-1/2" 6" 8" 6-1/2" 7-1/2" 7" 5" 6-1/2" 3" Bar 9-1/2" 3" Drag Bar 3" er Height V 9" 6" 5" 6-1/2"	34" 34" 35" 33" 35" 31" 30" 27" 30" 26" 26" 26" 28" 28" 28" 29"	13" 11-1/2"  13" 12" 16" 12" 10-1/2" 7"  11" 6-1/2" 6" 6-1/2" 8" 8" 10" 11"	7" 7" 8" 8" 6-1/2" 7-1/2" 6-1/2" 6" 5" 5" Keente 6" 5-1/2" 5-1/2" 5-1/2" 5-1/2" 5-1/2"	2-1/2" x 5-3/8"  3-1/4" x 7"  2-1/2" x 5-3/8"  2-1/2" x 5-3/8"  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5"  3" x 4-3/4"  2-1/2" x 4"  2-1/4" x 4-1/2"  4-1/4" one piece  2-3/4" x 4-1/2"  2-3/4" x 4-1/2"  2-3/4" x 4-1/2"	5KS-26111-00-00 "5EL-26111-10-00 "5BN-26111-10-00 "4VR-26111-10-00 1FK-26111-00-00 5LV-26111-00-00 5VX-26111-00-00
XVS 1100 XVS 950 XVS 650 XVS 650 VMX 12 VMX 12 XV 250/XVS250 FZS 1000 FZS 1000 FZ 600	Warrior Stryker (Welded Bars, No Risers) V-Star 1300 / Tourer V-Star 1100 Silverado V-Star 1100 Custom/Classic V-Star 950 / Tourer V-Star 650 Classic, Silverado V-Star 650 Custom V-Max V-Max V-Max Virago 250/V-Star 250 FZ-1 FZ-6 Triumph Description Rocket III Bonneville & T100 Bonneville & T100 Bonneville Bonneville America Bonneville America Bonneville SE	2002 - 2003 2011 - 2013 2007 - 2013 2004 - 2009 2002 - 2009 2009 - 2013 1998 - 2010 1997 - 2007 2009 - 2010Tai 1997 - 2013 2001 - 2005 2006 - 2010 2004 - 2010 Year Ba 2005 - 2013 2004 - 2005 2011 - 2013 2001 2002 - 2005 2011 - 2013 2001 2002 - 2005 2011 - 2013 2001 2002 - 2005 2011 - 2013 2001	1" 1" 1" 1" 1" 1" 7/8"  Der Down 7/8" 7/8" 7/8" 7/8" 1" 1" 1" 1" 1" 1" 1" 1" 1" 7/8"	5-1/2" 6" 8" 6-1/2" 7" 5" 6-1/2" 3" Bar 9-1/2" 3" Drag Bar 3" er Height V 9" 6" 5" 6-1/2" 6" 8-1/2"	34" 34" 35" 33" 35" 31" 30" 27" 30" 26" 26" 28" 28" 28" 29" 34" 32" 29"	13" 11-1/2"  13" 12" 16" 12" 10-1/2" 7"  11" 6-1/2" 6" 6-1/2" 8" 8" 10"  11" 15" 10"	7" 7" 8" 8" 6-1/2" 7-1/2" 6-1/2" 6" 5" 5" Keente 6" 5-1/2" 5-1/2" 5-1/2" 5-1/2" 5-1/2"	2-1/2" x 5-3/8"  3-1/4" x 7"  2-1/2" x 5-3/8"  2-1/2" x 5-3/8"  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5"  3" x 4-3/4"  2-1/2" x 4"  2-1/2" x 4"  2-1/2" x 4"  2-1/2" x 4"  2-1/4" x 4-1/2"  4-1/4" one piecc  2-3/4" x 4-1/2"  2-3/4" x 4-1/2"  2-3/4" x 4-1/2"  2" x 4-3/4"  2-3/4" x 4-3/4"	5KS-26111-00-00 "5EL-26111-10-00 "5BN-26111-10-00 "4VR-26111-10-00 1FK-26111-00-00 5LV-26111-00-00 5VX-26111-00-00
XVS 1100 XVS 950 XVS 650 XVS 650 VMX 12 VMX 12 XV 250/XVS250 FZS 1000 FZS 1000 FZ 600	Warrior Stryker (Welded Bars, No Risers) V-Star 1300 / Tourer V-Star 1100 Silverado V-Star 1100 Custom/Classic V-Star 950 / Tourer V-Star 650 Classic, Silverado V-Star 650 Custom V-Max V-Max V-Max Virago 250/V-Star 250 FZ-1 FZ-6 Triumph Description Rocket Ill Bonneville & T100 Bonneville & T100 Bonneville Bonneville America Bonneville SE Scrambler	2002 - 2003 2011 - 2013 2007 - 2013 2004 - 2009 2002 - 2009 2009 - 2013 1998 - 2010 1997 - 2007 2009 - 2010Τα  1997 - 2013 2001 - 2005 2006 - 2010 2004 - 2010 Year Ba 2005 - 2013 2004 - 2005 2011 - 2013 2001 2002 - 2005 2011 - 2013 2001 2002 - 2005 2011 - 2013 2001 2011 - 2013 2011 - 2013 2011 - 2013	1" 1" 1" 1" 1" 1" 7/8" oer Down 7/8" 7/8" 7/8" r Diamete 1" 1" 1" 1" 1" 1" 1" 1" 7/8"	5-1/2" 6" 8" 6-1/2" 7" 5" 6-1/2" 3" Bar 9-1/2" 3" Drag Bar 3" er Height V 9" 6" 5" 6-1/2" 6" 8-1/2" 6-1/2"	34" 34" 35" 33" 35" 31" 30" 27" 30" 26" 26" 28" 28" 28" 29" 34" 32" 29"	13" 11-1/2"  13" 12" 16" 12" 10-1/2" 7"  11" 6-1/2" 6" 6-1/2" Pullbac 14" 8" 8" 10"  11" 15" 10" 10"	7" 7" 8" 8" 6-1/2" 7-1/2" 6-1/2" 6" 6" 5" 5" Kente 6" 5-1/2" 5-1/2" 5-1/2" 5-1/2" 5-1/2" 5-1/2"	2-1/2" x 5-3/8"  3-1/4" x 7"  2-1/2" x 5-3/8"  2-1/2" x 5-3/8"  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5"  3" x 4-3/4"  2-1/2" x 4"  2-1/4" x 4-1/2"  4-1/4" one piecc  2-3/4" x 4-1/2"  2-3/4" x 4-1/2"  2" x 4-3/4"  2-3/4" x 4-3/4"  2-3/4" x 4-3/4"  2-3/4" x 4-3/4"	5KS-26111-00-00 "5EL-26111-10-00 "5BN-26111-10-00 "4VR-26111-10-00 1FK-26111-10-00 2UJ-26111-00-00 5LV-26111-00-00
XVS 1100 XVS 950 XVS 650 XVS 650 VMX 12 VMX 12 XV 250/XVS250 FZS 1000 FZS 1000 FZ 600	Warrior Stryker (Welded Bars, No Risers) V-Star 1300 / Tourer V-Star 1100 Silverado V-Star 1100 Custom/Classic V-Star 950 / Tourer V-Star 650 Classic, Silverado V-Star 650 Custom V-Max V-Max V-Max Virago 250/V-Star 250 FZ-1 FZ-6 Triumph Description Rocket Ill Bonneville & T100 Bonneville & T100 Bonneville & T100 Bonneville America Bonneville America Bonneville SE Scrambler Speedmaster (Risers 4"H) Adventurer Legend	2002 - 2003 2011 - 2013 2007 - 2013 2004 - 2009 2002 - 2009 2009 - 2013 1998 - 2010 1997 - 2007 2009 - 2010Tal 1997 - 2013 2001 - 2005 2006 - 2010 2004 - 2010 Year Ba 2005 - 2013 2002 - 2003 2004 - 2005 2011 - 2013 2001 2002 - 2005 2011 - 2013 2001 2002 - 2005 2011 - 2013 2011 - 2013 2011 - 2013 2011 - 2013 2011 - 2013 2001 - 2005 2001 2003 - 2005 2001 2001	1" 1" 1" 1" 1" 1" 7/8" oer Down 7/8" 7/8" 7/8" 7/8" 1" 1" 1" 1" 1" 1" 1" 1" 1" 1" 7/8" 7/8" 7/8" 7/8"	5-1/2" 6" 8" 6-1/2" 7-1/2" 7" 5" 6-1/2" 3" Bar 9-1/2" 3" Drag Bar 3" 6" 5" 6-1/2" 6-1/2" 6-1/2" Drag Bar	34" 34" 34" 35" 33" 35" 31" 30" 27" 30" 26" 26" 26" 28" 29" 34" 32" 29" 29" 29"	13" 11-1/2"  13" 12" 16" 12" 10-1/2" 7"  11" 6-1/2" 6" 6-1/2" 8" 8" 10"  11" 15" 10" 7-1/2"	7" 7" 8" 8" 6-1/2" 7-1/2" 6-1/2" 6" 6" 5" 5" <b>KCente</b> 6" 5-1/2" 5-1/2" 5-1/2" 5-1/2" 5-1/2" 11"	2-1/2" x 5-3/8"  3-1/4" x 7"  2-1/2" x 5-3/8"  2-1/2" x 5-3/8"  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5"  3" x 4-3/4"  2-1/2" x 4"  2-1/2" x 4"  2-1/2" x 4"  1-1/2" x 4"  2-1/4" x 4-1/2"  2-3/4" x 4-1/2"  2-3/4" x 4-3/4"  2-3/4" x 4-1/2"  2-3/4" x 4-1/2"	5KS-26111-00-00 "5EL-26111-10-00 "5EN-26111-10-00 "4VR-26111-10-00 1FK-26111-00-00 5LV-26111-00-00 5VX-26111-00-00
XVS 1100 XVS 950 XVS 650 XVS 650 VMX 12 VMX 12 XV 250/XVS250 FZS 1000 FZS 1000 FZ 600	Warrior Stryker (Welded Bars, No Risers) V-Star 1300 / Tourer V-Star 1100 Silverado V-Star 1100 Custom/Classic V-Star 950 / Tourer V-Star 650 Classic, Silverado V-Star 650 Custom V-Max V-Max V-Max Virago 250/V-Star 250 FZ-1 FZ-6 Triumph Description Rocket Ill Bonneville & T100 Bonneville & T100 Bonneville & T100 Bonneville America Bonneville America Bonneville SE Scrambler Speedmaster (Risers 4"H) Adventurer	2002 - 2003 2011 - 2013 2007 - 2013 2004 - 2009 2002 - 2009 2009 - 2013 1998 - 2010 1997 - 2007 2009 - 2013 2001 - 2005 2006 - 2010 2004 - 2010 Year Ba 2005 - 2013 2004 - 2005 2011 - 2013 2001 2002 - 2005 2011 - 2013 2001 2002 - 2005 2011 - 2013 2001 2001 - 2013 2001 2002 - 2005 2011 - 2013 2011 - 2013 2011 - 2013 2011 - 2013 2011 - 2013 2003 - 2005 2001	1" 1" 1" 1" 1" 1" 7/8" oer Down 7/8" 7/8" 7/8" 7/8" 1" 1" 1" 1" 1" 1" 1" 1" 7/8" 7/8" 1" 7/8"	5-1/2" 6" 8" 6-1/2" 7" 5" 6-1/2" 3" Bar 9-1/2" 3" Drag Bar 3" er Height V 9" 6" 5" 6-1/2" 6" 8-1/2" 6-1/2"	34" 34" 34" 35" 33" 35" 31" 30" 27" 30" 26" 26" 26" 28" 29" 34" 32" 29" 29" 29"	13" 11-1/2"  13" 12" 16" 12" 10-1/2" 7"  11" 6-1/2" 6" 6-1/2" Pullbac 14" 8" 8" 10"  11" 15" 10" 10"	7" 7" 8" 8" 6-1/2" 7-1/2" 6-1/2" 6" 6" 5" 5" Kente 6" 5-1/2" 5-1/2" 5-1/2" 5-1/2" 5-1/2" 5-1/2"	2-1/2" x 5-3/8"  3-1/4" x 7"  2-1/2" x 5-3/8"  2-1/2" x 5-3/8"  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5-3/8  2-1/2" x 5"  3" x 4-3/4"  2-1/2" x 4"  2-1/2" x 4"  2-1/2" x 4"  2-1/2" x 4"  2-1/4" x 4-1/2"  4-1/4" one piece  2-3/4" x 4-1/2"  2-3/4" x 4-1/2"  2" x 4-3/4"  2-3/4" x 4-3/4"  2-3/4" x 4-3/4"  2-1/4" x 5"  2-3/4" x 4-3/4"  2-1/4" x 5"  2-3/4" x 4-1/2"	5KS-26111-00-00 "5EL-26111-10-00 "5BN-26111-10-00 "4VR-26111-10-00 1FK-26111-10-00 2UJ-26111-00-00 5LV-26111-00-00

	Thunderbird	2002 - 2003	7/8"	7"	28"	9-1/2"	6"	2-3/4" x 4-1/2"
	Thunderbird / SE	2011 - <mark>2013</mark>	1"	5"	34"	11"	7"	3-1/4" x 6"
	Thunderbird Storm	2011 - <mark>2013</mark>	1"	Drag Ba	ar33-1/2"	11"	7"	3-1/4" x 6"
	Thunderbird Sport	2004	7/8"	2-1/2"	27-1/2"	5"	5-1/2"	2-3/4" x 4-1/2"
	Tiger	2002 - 2005	7/8"	6"	31"	6-1/2"	5-1/2"	2-3/4" x 4-1/2"
	Tiger (Tapered Down Bar)	2011						2-3/4" x 4-1/2"
Ducati Model	Ducati Description	Year Ba	r Diamet	er Height	Width	Pullbac	:KCenter	r Clamp Area
Ducati Model M 695/696	Ducati Description  Monster	<b>Year Ba</b> 2001 - 2008	r Diamet 7/8"	er Height 3"	29"	<b>Pullbac</b> 5-1/2"	<b>اد: Cente</b> "4-1/4	2-1/2" x 4"
	•			•				•
	Monster	2001 - 2008	7/8"	3"	29"	5-1/2"	4-1/4"	2-1/2" x 4"
M 695/696	Monster 1000 DS	2001 - 2008 2003	7/8" 7/8"	3" 4-1/2"	29" 30"	5-1/2" 5"	4-1/4" 4-1/2"	2-1/2" x 4" 2-1/2" x 4"
M 695/696 MT620	Monster 1000 DS Monster 620 Dark	2001 - 2008 2003 2006	7/8" 7/8" 7/8"	3" 4-1/2" 4-1/2"	29" 30" 31"	5-1/2" 5" 5"	4-1/4" 4-1/2" 5"	2-1/2" x 4" 2-1/2" x 4" 2-1/4" x 4"

additions or chages for 2013 are in red

Harley Davidson M XL883	additions or chages for 2013 are in red lodearley Davidson Description Sportster 883	<b>Year B</b> 2002 - 2008	ar Diamete 1"	r Height Width 4-1/2" 27"			r Clamp Area Factory # 2-1/2" x 4-1/2" 56082-83
XLH883	Sportster 883 Hugger	2002 - 2003	1"	10" 26-1/2	' 9-1/2"	6-1/2"	2-1/2" x 4-1/2"
XL883C	Sportster 883 Custom (Risers 6")	2002 - 2003	1"	Drag Bar 27"	5-1/2"	8"	2-1/2" x 4-1/2"
XL883C	Sportster 883 Custom (Risers+Speedo	<b>620</b> ,04 - 2009	1"	4-1/2" 27"	7-1/2"	4-3/4"	2-1/2" x 5-1/2" 56082-83
XL883R	Sportster	2002 - 2003	1" Blk	7" 31"	9"	5-1/2"	2-1/2" x 4-1/2"
XL883R	Sportster 883R	2006 - 2007	1" Blk	5" 31"	9"	6"	2-1/2" x 4-1/2"
XL883L	Sportster 883 Low/SuperLow	2005 - <mark>2013</mark>	1"	6" 28"	10"	6-1/2"	2-1/2" x 4-1/2"
XL883N	Sportster Iron 883	2010 - <mark>2013</mark>	1"	4-1/2" 27"	7-1/2"		2-1/2" x 5-1/2"
XL1200C	Sportster 1200 Custom (Risers 6")	2002 - 2003	1"	Drag Bar 27"	5-1/2"	8"	2-1/2" x 4-1/2"
XL1200C	Sportster 1200 Custom (Risers+Speed	•	1"	4-1/2" 27"	7-1/2"		2-1/2" x 5-1/2"
XL1200R	Sportster 1200 Roadster	2002 - 2008	1"	5" 31"	9"	6"	2-1/2" x 4-1/2"
XL1200S	Sportster 1200 Sport	2002 - 2003	1"	4-1/2" 27"	7-1/2"		2-1/2" x 4-1/2"
XLH1200	Sportster 1200	2002 - 2003	1"	10" 26-1/2			2-1/2" x 4-1/2"
XL1200L/SL	Sportster 1200 Low	2006 - 2011	1"	6" 28"	10"		2-1/2" x 4-1/2"
XL50	Sportster 50th Anniversary	2007	1"	5-1/2" 32"	10"	6"	2-1/2" x 4-1/2"
XL1200X	Sportster 48	2011 - 2013	1" 4"	4-1/2" 27"	7-1/2"		2-1/2" x 5-1/2"
XL1200V	Sportster 72	2012 - 2013	1"	13" 32"	10"	7"	2-1/2" x 5-1/2"
XL1200N	Sportster 1200 Nightster	2008 - 2012	1" 1"	6" 32" 6" 32"	10"	6" 6"	2-1/2" x 4-1/2"
XR1200/X FXDXT	Sportster XR1200  Dyna Super Gld T Sport	2009 - 2012 2002 - 2003	1"	7" 31"	10" 9"		2-1/2" x 4-1/2" 2-1/2" x 4-1/2"
FXDL/I	Dyna Low Rider (Risers 4-1/2"H x 2"P		1"	7 31 5" 31"	9 9"		2-1/2
FXDX	Dyna Super Glide Sport	2003	ı 1" Blk	6" 32"	9"		2-1/2" x 4-1/2"
FXDX	Dyna Super Glide Sport	2003	1 BIK 1"	7" 31"	9"		2-1/2" x 4-1/2"
FXD/I	Dyna Super Glide	2002	1"	6" 29"	10"		2-1/2" x 4-1/2"
FXD	Dyna Super Glide	2002	1"	4-1/2" 31"	7-1/2"		2-1/2" x 4-1/2"
FXDC/I	Dyna Super Glide Custom	2006 - <mark>2013</mark>	1"	6-1/2" 30-1/2			2-1/2" x 4-1/2"
FXDI35	Dyna 35th Anniversary Super Glide	2006	1"	6-1/2" 30-1/2			2-1/2" x 4-1/2"
FXDB/I	Dyna Street Bob	2006 - 2008	1"	10" 34-1/4		8"	2-1/2" x 4-1/2" 56079-93
FXDB	Dyna Street Bob	2009 - <mark>2013</mark>	1"	12-12" 34-1/4		8"	2-1/2" x 4-1/2"
FXDWG/I	Dyna Wide Glide	2002 - 2005	1"	10" 34-1/4		8"	2-1/2" x 4-1/2" 56079-93
FXDWG	Dyna Wide Glide	2006 - 2008	1-1/4"	10" 34"	10"	6"	2" x 5"
FXDWG	Dyna Wide Glide (Risers 5")	2010 - <mark>2013</mark>	1-1/4"	3" 30"	9"	7"	2" x 5"
FXDFSDEI	CVO Fat Bob	2010	1-1/4"	7-1/2" 33"	12"	6-1/2"	5" one piece
FXDF	Dyna Fat Bob	2008 - <mark>2013</mark>	1-1/4'	Drag Bar 27"	5-1/2"	7-1/2"	2-1/2" x 4-1/2"
FLD	Dyna Switchback	2012 - <mark>2013</mark>	1"	8" 32"	10"	7"	2-1/2" x 4-1/2"
FLST/I	Heritage Softail	2006	1"	7" 31"	11"	8-1/2"	2-1/2" x 4-1/2"
FXSTD/I	Softail Deuce (Risers 5"H x 4"PB)	2002 - 2007	1"	5" 31"	9"	6"	2-1/2" x 4-1/2"
FLSTN/I	Softail Delux (Risers 6"H x 2"PB)	2005 - <mark>2013</mark>	1"	5" 32"	11-1/2"	8"	2-3/4" x 6-1/2"
FXSTB/I	Night Train (Risers 6"H)	2003 - 2009	1"	Drag Bar 27"	5-1/2"	7-1/2"	2-1/2" x 4-1/2"
FLSTS/I	Heritage Springer	2002 - 2003	1"	7" 32"	11"	10"	4-1/2" x 6-1/8"
FXSTS/I	Springer Softail	2002 - 2003	1"	9" 27"	10-1/2"	8"	4-1/2" x 6-1/8"
FXSTS/I	Springer Softail	2004 - 2006	1"	4-1/2" 32"	8"		4-1/2" x 6-1/8"
FXSTSC/I	Springer Softail Classic	2005 - 2007	1"	3-1/2" 32"	11-1/2"	8"	2-3/4" x 6-1/2"
FLSTC/I	Heritage Classic	2002 - 2005	1"	7" 32"	13"	7"	2-1/2" x 4-1/2" 56569-86
FLSTC/I	Heritage Softail Classic	2006 - 2008	1"	7" 32"	13"	7"	2-1/2" x 4-1/2"
FLSTC	Heritage Softail Classic	2009 - 2013	1"	13" 35"	12"	10"	2-1/2" x 4-1/2"
FLS	Softail Slim	2013	1"	3-1/2" 32"	12"	8"	2-1/2" x 4-1/2"
FXS	Blackline (2 piece bars, no risers )	2012 - 2013	1" 1"	7" 00"	44"	44"	5-1/2" centers
FLSTF/I	Fat Boy	2002 - 2005 2006 - 2011		7" 32" 7" 32-1/2	11" ' 11"	11" 10"	2-1/2" x 4-1/2"
FLSTF FLSTF / B	Fat Boy	2006 - 2011 2010 - <mark>2013</mark>	1-1/4" 1 1/4"	7" 32-1/2 <sup>°</sup> 3" 30"	' 11" 9"	10" 7"	2" x 5" 2" x 5"
FXST/I	Fat Boy / Lo Softail Standard (Risers 6"H x 2"PB)	2010 - 2013	1-1/4" 1"	3 30 7" 31"	9 11"		2 x 5 2-1/2" x 4-1/2"
FXSTC	Softail Custom	2002 - 2007	1"	7 31 10" 34-1/4		6-1/2 8"	2-1/2" x 4-1/2"
FXSTC	Softail Custom	2007 - 2008	1"	12-1/2" 34-1/4		8"	2-1/2" x 4-1/2"
FLSTSE	CVO Softail Convertible	2010 - 2011	1-1/4"	7-1/2" 33"	12"	6-1/2"	
FXSBSE	CVO Breakout	2013	1-1/4"	7-1/2" 33"	12"	6-1/2"	
. /WDUL	5 TO DIGUNOUL	2010	. 1/7	1 112 33	14	U-1/2	o one piece

FLSTSB	Cross Bones Springer	2009 - <mark>2011</mark>	1"	12-1/2"	34-1/4"	10"	8"	4-1/2" x 6-1/8"
FXCW/C	Rocker/C	2008 - <mark>2011</mark>	1"	10/8"	32"	9/11"	"V"	"V"
FXSDSE	Screaming Eagle Dyna (elevated m/c's)	2008	1-1/4"	3-1/2"	33-1/2"	8"	7-1/2"	2" x 5"
FXSTSSE	Screaming Eagle Springer(elevated m/c	:'s2)008 - 2009	1-1/4"	3-1/2"	33-1/2"	8"	7-1/2"	3" x 6-1/2"
VRSCA	V-Rod A	2003 - 2004	1"	5"	28"	10"	5"	Welded Risers
VRSCB	V-Rod B	2004 - 2005	1"	6-1/2"	29-1/2"	8"	5"	4" one piece
VRSCD	V-Rod Night Rod	2006 - 2008	1"	6-1/2"	29-1/2"	8"	5"	4" one piece
VRSCR	V-Rod Street Rod	2006 - 2007	1"	3"	28"	4"	5"	4" one piece
VSRCDX	V-Rod Night Rod Special	2007 - 2011	1"	3"	28"	4"	5"	4" one piece
VSRCDX	V-Rod Night Rod Special	2013	1"	6"	32"	10"	6"	2-1/2" x 4-1/2"
VSRCX	V-Rod	2007	1"	3"	28"	4"	5"	4" one piece
VSRCAW	V-Rod	2007 - 2010	1"	8"	30"	11"	5"	4" one piece
VSRCF	V-Rod Muscle(cast aluminum bar no ris	se <b>29</b> )09 - <mark>2013</mark>						
FLHRC/I	Road King Classic	2002 - 2008	1"	7"	32"	11"	11"	2-1/2" x 4-1/2"
FLHRC	Road King Classic	2009 - <mark>2013</mark>	1"	7-1/2"	31"	12-1/2"	11-1/2	' 2-1/2" x 4-1/2"
FLHRS/I	Road King Custom	2004 - 2007	1"	6"	31-1/2"	14-1/2"	8"	2-1/2" x 4-1/2" 55947-00
FLHR/I	Road King	2002 - 2008	1"	7"	32"	11"	11"	2-1/2" x 4-1/2"
FLHR	Road King	2009 - <mark>2013</mark>	1"	7-1/2"	31"	12-1/2"	11-1/2	' 2-1/2" x 4-1/2" 55947-08
FLTR/I	Road Glide	2002	1"	7"	32-1/2"	12"	6-1/2"	2-1/2" x 4-1/2" 55947-00
FLTR/I/X/u	Road Glide / Custom / Ultra	2003 - <mark>2013</mark>	1"	8-1/2"	32"	11"	7"	2-1/2" x 4-1/2" 55947-00
FLHX/I/SE	Street Glide / CVO	2006 - <mark>2013</mark>	1"	7-1/2"	31"	12-1/2"	11-1/2	' 2-1/2" x 4-1/2"
FLHT/I	Electra Glide Standard	2002 - 2007	1"	7-1/2"	31"	12-1/2"	11-1/2	' 2-1/2" x 4-1/2"
FLHTC/I/K	Electra Glide Classic	2002 - <mark>2013</mark>	1"	7-1/2"	31"	12-1/2"	11-1/2	' 2-1/2" x 4-1/2"
FLHTCU/I/SE	Ultra Classic	2002 - 2007	1"	7-1/2"	31"	12-1/2"	11-1/2	' 2-1/2" x 4-1/2"
FLHT/I	Electra Glide Standard	2008 - 2009	1"	7-1/2"	31"	12-1/2"	11-1/2	' 2-1/2" x 4-1/2" 55947-08
FLHTC/I/K	Electra Glide Classic / Ultra Limited	2008 - <mark>2013</mark>	1"	7-1/2"	31"	12-1/2"	11-1/2	' 2-1/2" x 4-1/2" 55947-08
FLHTCU/I/SE	Ultra Classic / Limited / CVO / Electra	GI <b>20</b> 08 - 2013	1"	7-1/2"	31"	12-1/2"	11-1/2	' 2-1/2" x 4-1/2" 55947-08
FLHXXX	Street Glide Trike	2009 - 2011	1"	7-1/2"	31"	12-1/2"	11-1/2	' 2-1/2" x 4-1/2" 55947-08
FLHTUCG	Tri Glide Ultra Classic	2009 - <mark>2013</mark>	1"	7-1/2"	31"	12-1/2"	11-1/2	' 2-1/2" x 4-1/2" 55947-08
FLHRSE	CVO Road King	2013	1-1/4"	8"	32"	15"	8"	5" one piece
FLTRXSE	CVO Road Glide Custom	2013	1-1/4"	8"	32"	15"	8"	5" one piece
	Standard Knurls including V-Rod	1983 - 2011	1"					2-1/2" x 4-1/2"
	Springer Knurls	1983 - 2011	1"					4-1/2" x 6-1/8"
Buell Model	Buell Description	Year Ba	ar Diameter	Height	Width	Pullbac	<b>K</b> ente	r Clamp Area
	Cyclone	2001 - 2003	7/8"	4"	28"	6-1/2"	5"	3-1/2" x 4-3/4"
XB9S/125	Lightning (XB9S)	2001 - 2007	7/8"	4"	28"	6-1/2"	5"	3-1/2" x 4-3/4"
	Thunderbolt	2001 - 2003	7/8"	6"	26"	8-1/2"	6"	3-1/2" x 4-3/4"
XB12X	Ulysses	2006 - 2007	7/8"	6-1/2"	30"	9"	5"	3-1/2" x 4-3/4"
	Blast	2001 - 2007	7/8"	6"	27"	7-1/2"	6"	2-1/2" x 4-1/2"
Victory Model	Victory Description	Year B	ar Diameter	Height	Width	Pullbac	<b>K</b> Cente	r Clamp Area
V92C	V92C Standard	2002 - 2003	1"	7"	35"	11-1/2"	8"	3-3/4" x 5-1/2"
V92C	V92C Tour Delux & Touring Cruiser	2002 - 2006	1"	8"	33"	11"	8-1/2"	3-3/4" x 5-1/2"
	Vegas Pullback Bar	2003 - 2004	1"	5"	34"	13"	7-1/2"	3-3/4" x 5-1/2"
	Kingpin & Vegas Std Bad	2004 - 2006	1"	5-1/2"	35"	10"	7-1/2"	3-3/4" x 6"
	Hammer (Welded Bar)	2005 - 2007	1-1/4"	6"	34"	10"		Welded Risers
	Ness Signature (Welded Bar)	2007	1-1/4"					Welded Risers
	Vegas / Vegas Jackpot / Vegas 8 Ball	2007 - 2011	1"	6"	35"	15"	8"	4" x 5"
	King Pin / King Pin 8 Ball / Hammer	2007 - <mark>2013</mark>	1"	5"	34"	14"	8"	4" x 6"
	Cross Country/Roads/Tour	2009 - <mark>2013</mark>	1"	5"	34"	18"	8"	4" x 6"
	Cross Road	2011	1"	5"	32"	15"	8"	4" x 6"
Indian Model	Indian Description	Year B	ar Diameter	Height	Width	Pullbac	<b>K</b> Cente	r Clamp Area
	Scout / Spirit	2002 - 2003	1"	6"	34"	11"	7"	2-1/2" x 4-1/2"
	Chief-Delux, Roadmaster	2003	1"	7-1/2"	35"	15"	7"	2-1/2" x 4-1/2"
	Chief Vintage	2013	1"	8"	32"	15"	8"	2-1/2" x 4-1/2"
	-							

## **Handlebar Measurements**

All measurements are made in normal riding position.

**Height or Rise:** Total height measured in a level plane.

**Pull Back:** Vertical lines from the furthest forward to rear in a level plane.

**Center Width:** Straight flat section before the start of the bends.

**Width:** Total overall tip to tip width, no grips or bar end weights.