


## **Block Number (Type) Parameter** B003(Message texts): Prio = 2Quit = off (Screen Info) Text1: enabled Text2: disabled Ticker setting B003 - Current date - CBC Ε .... August15,2025 - Line1: N B003 - Current time - Line2: N ..... 9:41:34 AM CA - Line3: N - Line4: N - Line5: N - Line6: N Message Destination 0 - LOGO! Display TROL MODE E D Line1.1 B003-Date Line2.1 B003-Time Prio = 3 B004(Message texts): (Screen Quit = off Text1: enabled Info) Text2: disabled Ticker setting B004 - Current date B004 - Current ti... - CBC .. .. 9:41:34 AM .. .... August15,2025 - Line1: N - Line2: N - Line3: N - Line4: N B017 - Cou... - Line5: N - Line6: N

+/-0 B015 - Cou... B019 - Cou... 0 3 +/-0 +/-0 B020 - Cou... B016 - Cou... +/-0

Message Destination - LOGO! TD

Line1.1 B004-Date Line1.13 B004-Time Line3.4 B013-Cnt Line3.15 B017-Cnt Line4.4 B014-Cnt Line4.15 B018-Cnt Line5.4 B015-Cnt Line5.15 B019-Cnt Line6.4 B016-Cnt Line6.15 B020-Cnt

Creator:	Admin		Project:	Basic_IO_Control	Customer:	TVET
Checked:		Compuscan Manufacturing	Installation:		Diagram No.:	
Date:	7/25/25 9:58 AM/8/15/25 11:37 AM		File:	LOGO! FBD.lsc	Page:	5 / 12



Block Numb	er (Type)				Parameter		
B012(OR): (OR)							
B013(Up/Dov (Up/Down Counter)	vn counter) :				Rem = off On=0+ Off=0 Start=0		
B014(Up/Dov (Up/Down Counter)	vn counter) :				Rem = off On=0+ Off=0 Start=0		
B015(Up/Dov (Up/Down Counter)	vn counter) :				Rem = off On=0+ Off=0 Start=0		
B016(Up/Dov (Up/Down Counter)	vn counter) :				Rem = off On=0+ Off=0 Start=0		
B017(Up/Dow (Up/Down Counter)	vn counter) :				Rem = off On=0+ Off=0 Start=0		
B018(Up/Dov (Up/Down Counter)	vn counter) :				Rem = off On=0+ Off=0 Start=0		
B019(Up/Dov (Up/Down Counter)	vn counter) :				Rem = off On=0+ Off=0 Start=0		
B020(Up/Dov (Up/Down Counter)	wn counter) :				Rem = off On=0+ Off=0 Start=0		
B021(Up/Dov (Up/Down Counter)	vn counter) :				Rem = off On=0+ Off=0 Start=0		
B022(Up/Dov (Up/Down Counter)	vn counter) :				Rem = off On=0+ Off=0 Start=0		
B023(Up/Dov (Up/Down Counter)	vn counter) :				Rem = off On=0+ Off=0 Start=0		
B024(Up/Dov (Up/Down Counter)	wn counter) :				Rem = off On=0+ Off=0 Start=0		
ator:	Admin		Project:	Basic_IO_Cor	ntrol	Customer:	TVET
ecked: e:	7/25/25 9:58 AM/8/15/25 11:37 AM	Compuscan Manufacturing	Installation: File:	LOGO! FBD.Is	er .	Diagram No.: Page:	7 / 12

Creator:	Admin	L	Project:	Basic_IO_Control	Customer:	TVET
Checked:		Compuscan Manufacturing	Installation:		Diagram No.:	
Date:	7/25/25 9:58 AM/8/15/25 11:37 AM		File:	LOGO! FBD.lsc	Page:	7   12

Block Numbe	r (Type)				Parameter		
B025(AND) : (AND)							
B026(AND): (AND)							
B027(AND) : (AND)							
B028(AND) : (AND)							
B029(AND): (AND)							
B030(AND): (AND)							
B031(AND) : (AND)							
B032(AND) : (AND)							
B033(Analog / (Analog Amplifier)	Amplifier) :				Gain =1.0+ Offset=0 Point =0		
B034(Analog / (Analog Amplifier)	Amplifier) :				Gain =1.0+ Offset=0 Point =0		
B035(Analog / (Analog Amplifier)	Amplifier) :				Gain =1.0+ Offset=0 Point =0		
B036(Analog <i>i</i> (Analog Amplifier)	Amplifier) :				Gain =1.0+ Offset=0 Point =0		
B037(Analog t (Analog Thres Trigger)	chreshold trigger) : hold				Gain=1.0+ Offset=0 On=0 Off=0 Point=0		
B038(Analog t (Analog Thres Trigger)	threshold trigger) : hold				Gain=1.0+ Offset=0 On=0 Off=0 Point=0		
B039(Analog 1 (Analog Thres Trigger)	threshold trigger) : hold				Gain=1.0+ Offset=0 On=0 Off=0 Point=0		
Creator:	Admin		Project:	Basic_IO_Co	ontrol	Customer:	TVET
Checked:		Compuscan Manufacturing	Installation:			Diagram No.:	
ate:	7/25/25 9:58 AM/8/15/25 11:37 AM		File:	LOGO! FBD.	ISC	Page:	8 / 12

Creator:	Admin		Project:	Basic_IO_Control	Customer:	TVET
Checked:		Compuscan Manufacturing	Installation:		Diagram No.:	
Date:	7/25/25 9:58 AM/8/15/25 11:37 AM		File:	LOGO! FBD.lsc	Page:	8 / 12

Block Numbe	er (Type)				Parameter		
B040(Analog (Analog Thres Trigger)	threshold trigger) : shold				Gain=1.0+ Offset=0 On=0 Off=0 Point=0		
B041(AND) : (AND)							
B042(Latching (Latching Relay)	g Relay) :				Rem = off		
B043(Messag (Screen Info)  B043 - Curre August1  D I G I T / Line1.1 B043- Line1.13 B043 Line3.9 B021- Line4.9 B022- Line6.9 B024-	ent date     B043 - Current time     B05,2025     B043 - Current time     B044 - Current time     B044 - Current time     B043 - Current time     B044 - Current time				Prio = 6 Quit = off Text1: enabled Text2: disabled  > Ticker setting - CBC - Line1: N - Line2: N - Line4: N - Line5: N - Line6: N Message Destin - LOGO! TD	ation	
B044(AND) : (AND)							
BO45(AND): (AND)							
B046(AND) : (AND)							
B047(AND): (AND)							
B048(AND) : (AND)							
B049(OR): (OR)							
B050(OR):							
B051(OR):							
					<u> </u>		
Creator:	Admin		Project:	Basic_IO_Co	ontrol	Customer:	TVET
Checked:		Compuscan Manufacturing	Installation:			Diagram No.:	
Date:	7/25/25 9:58 AM/8/15/25 11:37 AM	I	File:	LOGO! FBD	.isc	Page:	9 / 12

Block Numbe	r (Type)				Parameter			
B052(OR) : (OR)								
B053(AND) : (AND)								
B054(AND) : (AND)								
B055(AND) : (AND)								
F1(LOGO! TD I (TD F-Key)	Function key) :							
				•				
Creator:	Admin		Project:	Basic_IO_Cor	ntrol	Customer:	TVET	
Creator: Checked: Date:	7/25/25 9:58 AM/8/15/25 11:37 AM	Compuscan Manufacturing	Installation:	LOGO! FBD.Is	sc	Diagram No.: Page:	10 / 12	

Connection	Label					
Al1						
AI2						
AI3						
Al4						
C3 <b>∢</b>						
C4 <b>►</b>						
F1						
F2						
F3						
l1	AI0.2/DI0.0					
12	AI0.3/DI0.1					
13	DI0.2					
14	DI0.3					
I5	DI0.4					
16	DI0.5					
17	AI0.0/DI0.6					
18	AI0.1/DI0.7					
19	DI1.0					
l10	DI1.1					
I11	DI1.2					
I12	DI1.3					
M8	Initialization Flag					
M25	LOGO! displays white backli	ght				
M26	LOGO! TD white backlight					
Q1	DQ0.0					
Q2	DQ0.1					
Q3	DQ0.2					
Q4	DQ0.3					
Q5	DQ1.0					
Q6	DQ1.1					
Q7	DQ1.2					
Q8	DQ1.3					
X1						
X2						
Х3						
Creator: Admin		Compuscan Manufacturing	Project: Installation:	Basic_IO_Control	Customer: Diagram No.:	TVET
Date: 7/25/25	9:58 AM/8/15/25 11:37 AM		File:	LOGO! FBD.lsc	Page:	11 / 12

Creator: Admin		Project:	Basic_IO_Control	Customer:	TVET
Checked:	Compuscan Manufacturing	Installation:		Diagram No.:	
Date: 7/25/25 9:58 AM/8/15/25 11:3	AM	File:	LOGO! FBD.lsc	Page:	11 / 12

Connection	Label					
X4						
X5						
X6						
X7						
X8						
Х9						
X10						
X11						
Creator: Checked:	Admin	Compuscan Manufacturing	Project: Installation:	Basic_IO_Control	Customer: Diagram No.:	TVET
ate:	7/25/25 9:58 AM/8/15/25 11:37 AM	ĺ	File:	LOGO! FBD.lsc	Page:	12 / 12