1. Hardware Setup


- Connect the GSM module -SIM99A to the Arduino.
 - **GND** of the GSM module to **GND** of the Arduino.
 - VCC of the GSM module to 5V on the Arduino (confirm the voltage requirements for your module).
 - **TX** of the GSM module to (pin 10, for example) on the Arduino.
 - **RX** of the GSM module to (pin 11) on the Arduino.

• Connect the Buzzer


- o One pin for **GND**
- Second pin for pin 13

• Connect the **Push Button**

- One pin for GND
- Second pin for pin 2



2. Flow Chart of Programing



படிகள் விளக்கம்:

- 1. தொடக்கம்
 - திட்டம் ஆரம்பமாகும் இடம்.
- 2. கூறுகளை ஆரம்பிக்கவும்
 - ் புஷ் பட்டன், பசர் மற்றும் GSM மொடியூலை (SMS மொத்தம் அமைப்பில்) ஆரம்பிக்கிறது.
 - ் புஷ் பட்டனை (Input) ஆக தயார் செய்தல்
 - ் பசரை (Output) ஆக தயார் செய்தல்.
 - o GSM மொடியூலை SMS Mode இற்க்கு தயார் செய்தல்
- 3. பட்டன் நிலையை சரிபார்க்கவும் (Edge Detection)
 - புஷ் பட்டன் அழுத்தப்பட்டதா என்று சரிபார்க்கிறது.
 (HIGH இருந்து LOW க்கு மாறிய நிலையை மட்டுமே கண்டறிவது)
 - புஷ் பட்டன் அழுத்தப்பட்டிருந்தால், அடுத்தடுத்த படிகளுக்கு நகர்கிறது. இல்லையெனில், மீண்டும் சரிபார்க்கிறது.
- 4. பசரை இயக்கவும்
 - ் பசரை குறுகிய நேரத்திற்கு ஆன் செய்து, பிறகு ஆஃப் செய்கிறது.
- 5. **SMS** அனுப்பவும்
 - முதல் தொலைபேசி எண்ணிற்கு SMS அனுப்புகிறது.
 - இரண்டாவது தொலைபேசி எண்ணிற்கு SMS அனுப்புகிறது.
- 6. முடிவு
 - செயல்முறை முடிந்துவிடுகிறது.