*Synthetic manual for learning*

# Wireless Bluetooth Headphones User Manual

## How to Use

Press and hold the power button for three seconds until the LED flashes blue to enter pairing mode. Select 'SimpleAudio Pro' in your device Bluetooth settings. Use the volume rocker to adjust audio levels and press the multi-function button once to play or pause. Charge with the provided USB-C cable for two hours.

## Troubleshooting

If audio drops or Bluetooth disconnects, ensure the headphones are within ten meters of the paired device. To reset, hold the power and volume down buttons simultaneously for seven seconds until the LED turns red. If the microphone sounds muffled during phone calls, verify the mic hole is free of dust and debris.

## Warranty

Includes a one-year limited hardware warranty against manufacturing defects, internal battery failure, and driver malfunction. Liquid damage, physical drops, and unauthorized disassembly void all coverage. Submit warranty claims with your original order receipt through customer support.