ARPES viewer — User Guide

中文版 / Chinese version · *Version française*

Last updated: 10 November 2026 — for ARPES viewer v1.3.3

The version and its date are in the main window's title bar and on its last line. Bug reports, questions and the latest version: https://github.com/DingPei1995/ARPES-viewer (please give the version number when reporting a bug).

The guide follows the program as it appears on screen:

- **Part 1** gets you started: installing, the demo data, the files the program reads, setting up an AI agent, and how the code is organised.
- **Part 2** is the main panel: the list of datasets and what is around it.
- **Part 3** is the data viewers: cuts, maps, kz maps, k-maps, curves, spin and spatially resolved scans.
- **Parts 4, 5 and 6** are the three tabs of the tool panel (**Basic**, **Advanced**, **Figure**). Part 6 ends with an example that goes from loading data to a finished figure.
- **Part 7** is AI agents: how they drive the program, how to start and watch one, and an example from set-up to figure.
- **Part 8** is housekeeping: autosave and recovery, saving work, error logs, versions, and troubleshooting.

Every screenshot was taken from the running program on the synthetic data of `devtools/demo_data.py`, so you can follow along without a beamtime (§1.3). **These are not real experimental data.** The technical background of each step (formulas, tests, design choices) is in the references beside the code: reading data, the windows, analysis, and the CHANGELOG.

Contents

Part 1 — Getting started

- 1.1 What ARPES viewer is
- 1.2 Installing and starting
- 1.3 Trying it with demo data
- 1.4 Facilities and file formats
- 1.5 Data kinds
- 1.6 Setting up an AI agent
- 1.7 How the code is organised
- 1.8 Where the program keeps its files

Part 2 — The main panel

- 2.1 The main window at a glance
- 2.2 Loading data
- 2.3 The experiment log
- 2.4 Combining datasets: stacking, joining and summing
- 2.5 Step-by-step windows

Part 3 — The data viewers

- 3.1 What the viewers have in common
- 3.2 Maps: the contour and its two cuts

- 3.3 Arbitrary cuts and Fermi-surface correction
- 3.4 kz maps and k-maps
- 3.5 Curves: EDCs, MDCs and the curve fit
- 3.6 Spin-resolved data
- 3.7 Spatially resolved scans (nano-ARPES)
- 3.8 Exporting a panel and saving data

Part 4 — The tool panel: Basic tab

- 4.1 How the tool buttons work
- 4.2 Fermi edge fit
- 4.3 Removing the detector grid
- 4.4 Detector corrections
- 4.5 Background subtraction
- 4.6 Converting a cut to momentum
- 4.7 Core-level check
- 4.8 Converting a map to momentum
- 4.9 Aligning the Fermi levels of a kz map
- 4.10 Converting a kz map to momentum
- 4.11 Brillouin zone

Part 5 — The tool panel: Advanced tab

- 5.1 Smoothing, derivatives, curvature and symmetrising
- 5.2 Ridge detection
- 5.3 Stack plots
- 5.4 MDC fit and EDC fit
- 5.5 Cut arithmetic: dichroism and reference division
- 5.6 Slice series figure
- 5.7 The 3-D views
- 5.8 Fermi pocket (quasi-2D, under test)

Part 6 — The tool panel: Figure tab

- 6.1 The figure composer
- 6.2 Crystal structure
- 6.3 3D BZ: the Brillouin zone in three dimensions
- 6.4 Tight-binding fit
- 6.5 Calculated bands
- 6.6 Worked example: from loading data to a figure
- 6.7 Worked example: two figures in the figure composer

Part 7 — AI agents

- 7.1 How it works, and what leaves your computer
- 7.2 Architecture: operations, reference, routes
- 7.3 Starting from the AI assistant panel
- 7.4 Watching and stepping in
- 7.5 Other ways to start
- 7.6 The working rules the agent follows
- 7.7 Worked example: an agent from set-up to figure
- 7.8 Limitations and good practice

Part 8 — Housekeeping

- 8.1 Autosave, memory and recovery
- 8.2 Saving and reopening work
- 8.3 Error logs and bug reports
- 8.4 Versions and updates
- 8.5 Tips and troubleshooting

Part 1 — Getting started

What the program is, how to install and start it, the demo data that every screenshot is made from, the files it reads, how to connect an AI agent, and where things are in the code and on disk.

1.1 What ARPES viewer is

ARPES viewer is a Python/PyQt5 program for angle-resolved photoemission data. It browses the measurements of a beamtime, opens each in its own window, converts to momentum, cuts, fits and processes, compares with band-structure calculations, and lays the results out as a publication figure. Every step is also plain Python that a script or an AI agent can run.

It is free for **non-commercial use** (academic research and teaching), under the PolyForm Noncommercial License 1.0.0. If you use it for a paper, please cite it: Ding Pei, *ARPES viewer*, Zenodo, https://doi.org/10.5281/zenodo.23771647.

It is not an acquisition program and does not change your data files: every result is a new dataset in the list or a new file you choose.

1.2 Installing and starting

You need Python 3.9 or newer and five packages:

```
pip install PyQt5 pyqtgraph numpy h5py scipy
```

Then, from the `ARPES_viewer` folder:

```
python ARPES_viewer.py
```

On Windows, double-click `ARPES viewer.pyw` in the program's folder, not `ARPES_viewer.py`: Windows runs a `.pyw` with `pythonw`, which opens no black console window -- closing that window by mistake used to close the program with it. (A `.py` double-clicked all the same now hides the console it was given; one started from a command prompt keeps its console.) The program's messages go to `~/.arpes_viewer/launcher.log`; if it stops with an error, a message box shows the end of that log.

Errors are kept as a text file. Whatever the console would show when something goes wrong -- the error and its traceback -- is saved by itself in **`error_logs/errors_<date>_<time>.txt` in the program's folder** (in `~/.arpes_viewer/error_logs` if that folder cannot be written), only when an error happens. A message says so, and the program **keeps running** instead of closing. With a bug report, **upload that file** (on GitHub Issues: drag it into the text box) **or paste its text** — the main panel's foot has **Copy the newest error log** (its text to the clipboard) and **Open the error logs** (the folder).

Long operations show a progress bar. Anything that can take more than a moment on a big dataset or a slow computer — reading a whole map, k conversion, FS correction, arbitrary cuts, data operations, joining datasets, saving, ridge detection, the fits, and in Calculated bands reading a calculation, the plane's bands and the 3-D Fermi surface — shows a progress window after 0.4 s: a bar that moves, the seconds taken, and Cancel where the step can stop. The program is working, not frozen.

On a Mac you do not need Terminal to start it: double-click `ARPES viewer.app` in the program's folder (drag it to the Dock to keep it there). It finds the Python that has the packages above -- the same one as `python3` in Terminal, conda environments included -- and remembers it. If no Python has them, a dialog gives the `pip install` command (already copied to the clipboard: paste it into Terminal once) or lets you choose a Python yourself.

- If macOS says the app *cannot be opened because it is from an unidentified developer* (the program was downloaded as a ZIP): open **System Settings → Privacy & Security** and click **Open Anyway** (older macOS: right-click the app → **Open**). Only the first time.
- A copy of the app moved out of the program's folder (to Applications, say) asks once where the folder is.
- If the program stops with an error, the dialog shows the end of `~/.arpes_viewer/launcher.log`; please send that file with a bug report.

The files it reads are listed in §1.4.

1.3 Trying it with demo data

```
python devtools/demo_data.py            # writes ./demo_data/
```

This writes synthetic data that opens exactly like measured data:

- the original set -- a Fermi-surface map, a pair of cuts in LH and LV polarisation, a photon-energy scan, a spin-resolved EDC, a small real-space scan and a map with a detector mesh printed on it -- from a toy band structure (a hexagonal electron pocket and a hole band at Γ, hole pockets at K);
- **a layered crystal in three dimensions** (`demo_bulk_bands.nxs`): maps at the photon energies of the Γ plane (59.3 eV) and of the zone top (77 eV), cuts along Γ-M (LH and LV) and Γ-K, and a photon-energy scan along Γ-M through a whole period of k_z. Two of its bands cross along a line through the zone, whose energy changes with k_z;
- **a calculation of that crystal**, as a theory group would send it: a Wannier90 Hamiltonian (`demo_calc_hr.dat` with `demo_calc.win`) and the same bands on a grid (`demo_calc.bxsf`). It is the crystal before renormalisation -- its bands 1/0.8 times wider and 50 meV higher -- which is what fitting it to the data recovers (§6.5);
- two crystal structures as CIF files (`demo_crystal.cif`, a 1T layered hexagonal crystal; `demo_tetragonal_crystal.cif`, a ZrSiS-type one) and an EDS spectrum (`demo_eds.nxs`).

All come with a Fermi cut-off, the analyser resolution and Poisson noise.

To re-take every screenshot in this guide after changing a window:

```
python devtools/guide_screenshots.py    # writes docs/images/*.png
```

The two example figures of §6.7 are rebuilt, from the demo data and with the program's own windows, by

```
python devtools/figure_tests.py docs/images [folder for the .afig files]
```

1.4 Facilities and file formats

The reader for a file is detected automatically (§2.2).

Facility / beamline	Files	Data
SOLEIL **ANTARES**	NeXus `*.nxs`	cuts, deflector maps, photon-energy (PhD) scans, spatial scans
SOLEIL **CASSIOPEE**	Scienta text `*.txt`	single spectra; numbered folders assembled into a map or a photon-energy scan
CASSIOPEE **spin end station** (MBS A-1)	`*.krx`, `*.txt`	cuts, deflector maps, spin-resolved EDCs
ALS **MAESTRO**	`*.h5`, `*.hdf5`	cuts, maps, photon-energy and spatial scans
ALBA **LOREA**	`*.nxs`	cuts, maps
Diamond **I05** (HR-ARPES) and **I05-1** (nano-ARPES)	`*.nxs`	cuts, maps, photon-energy scans, spatial scans
MAX IV **Bloch** (and any Scienta SES file no other reader claims)	`*.ibw`, `*.zip`, `*.txt`	cuts, deflector maps, photon-energy and manipulator scans
Elettra **APE**, BESSY **One Cube / One Square**, SOLARIS **URANOS**	`*.ibw`, `*.zip`, `*.txt`	as SES writes them
ASTRID2 **SGM4**	`*.h5`, `*.hdf5`	cuts, maps, knife-edge scans
This program	its own `*.nxs`	anything it saved, several datasets per file

Datasets are written back as the program's own `.nxs` (which it opens again) or as Igor Pro text (`.itx`). How each facility's files are read, and the assumptions their formats force, is in the loaders' reference; adding a beamline is explained there too.

A map whose scan was stopped before its end -- by hand, a beam loss, a crash of the control software -- opens as far as it went, from every facility. The steps never measured (no counts, or no value of the scanned axis) and a last step clearly weaker than the ones before it (below half of them: stopped part-way through its sweeps) are left out; the status bar and the Information panel (`incomplete.note`) say how many and why. Weak steps in the middle of a scan are the sample and are never touched.

1.5 Data kinds

Kind	Axes	What it is
`cut`	angle (or k) × E	one spectrum
`map`	angle × angle × E	a deflector or polar-angle scan
`k_map`	kx × ky × E	a map converted to momentum
`kz_map`	hν × angle × E	a photon-energy scan
`kz_map_k`	k_z × k∥ × E	that scan converted to momentum
`spem_4d`, `spem_1d`	x (× y) × angle × E	real-space scans
`edc`, `mdc`, `spin_edc`	E (or k) × channels	curves, with optional σ channels

Names of processed data

Every result is a new row named after its source, with one tag in square brackets added per step, oldest first: `Map80eV [norm] [E-E_F] [k]` is Map80eV, normalised, referred to E_F, then converted to momentum. The tags, in the order a processing usually runs (`arpes_viewer/tools/runtime/naming.py`):

Tag	Made by	What was done
`[combined …]`	Combine…, sum of repeated scans	datasets joined, stacked or summed into one
`[degrid] / [grid]`	Remove detector grid…	the detector's grid removed / the grid itself
`[det]`	Detector correction	keystone and region corrections
`[crop]`	Truncate…, `L.crop`	cut to a range of its axes
`[bin]`	Compress…, `L.bin`	points summed in blocks
`[despike]`	Smooth… (spike removal)	spikes removed
`[norm]`	Self-normalise…, `L.normalise`	each spectrum or plane divided by its own total or peak
`[bg]`	Background subtraction…	background subtracted
`[E-E_F]`	Fermi edge fit (offset), `L.shift_energy`	energy referred to the Fermi level
`[dFD]`	Fermi edge fit (divide)	divided by the Fermi–Dirac function
`[FS corr]`	Straighten bands (FS correction)	bands straightened along the slit
`[sm]`	Smooth…	smoothed
`[symm]`	Symmetrise…	mirrored or rotated
`[k]`	k conversion (cut / map)	converted to momentum
`[kz]`	kz conversion	photon-energy scan converted to k_z
`[d2] / [grad] / [cur]`	Second derivative… / Minimum gradient… / Curvature…	second derivative, minimum gradient, curvature
`[ridge]`	Ridge detection	band positions
`[arb cut]`	Arbitrary cut in a map	a cut along a line of one's own
`[slice …]`	Save slice to list (a viewer)	a plane or cut taken out of a viewer
`[EDC …] / [MDC …]`	a viewer's EDC / MDC to the list	a curve taken out, with where
`[shifted] / [sigma]`	the curve viewer	a shifted curve / its Poisson uncertainty
`[fit]`	the curve fit	a fit result
`[LD] [CD] [diff] [asym] [ratio] [sum]`	Cut arithmetic…	two cuts combined
`[calc]`	Calculated bands	a calculation, not a measurement

Sorting. Right-click the list → **Sort by data type** groups the rows by their **last** tag -- what was done to them last -- in the order of this table: measurements as read first, then `[crop]`, `[norm]`, `[E-E_F]`, `[k]` …; a tag not in the table comes after. Inside a group the rows are ordered by kind (cut, map …), then by

name, numbers compared as numbers. **Sort by name** ignores the tags' order. Names from older versions are read the same way: `_s_nor` counts as `[norm]`, `_tk` as `[crop]`, `_comb` as `[bin]`, `_sm`, `_d2`, `_cur` as `[sm]`, `[d2]`, `[cur]`, and `[E-Ef]` as `[E-E_F]`. A row renamed by hand keeps its place only if it keeps its tags. An AI agent follows the same rule, also for names of its own (§7.6); `L.naming()` gives it the table.

1.6 Setting up an AI agent

An AI agent can drive the program for you (Part 7). There is nothing extra to install for the usual route:

1. Have an AI app that can read and write files on your computer: the Claude desktop app, Claude Code, or a similar agent.
2. In ARPES viewer, press **AI assistant...** at the top of the tool panel, choose the data and results folders, and press **Copy the prompt and start** (§7.3).
3. Paste the prompt into the AI app and allow it to read the data folder and to read and write the results folder.

An app that uses MCP tools instead needs the program's MCP server added once; the prompt says how (§7.5). Before you start, read what leaves your computer (§7.1).

1.7 How the code is organised

Folder	What is in it
`arpes_viewer/loader/`	the readers: one per facility (`beamlines/`), shared formats (`formats/`), the program's own `.nxs`, the session's autosave
`arpes_viewer/tools/`	the computations, without any window: spectra (Fermi edge, fits, core levels, spin), momentum (k and kz conversion), processing (smoothing, derivatives, cut arithmetic ...), crystal (lattices, Brillouin zones, calculated bands), output (figures, export)
`arpes_viewer/ui/`	the windows: the main panel (`launcher/`), the viewers (`viewers/`), the tool windows (`panels/`), shared pieces (`common/`), including the agent's operations `L` (`common/live.py`)
`arpes_viewer/agent/`	the MCP server, the agent bridge, and `API.md`, the agent's reference generated from the program
`agentic/`	examples and recipes for agents and scripts
`devtools/`	the demo data, the screenshots, the figure tests, the guide's build
`test/`	the tests (`python -m pytest`)

Because the computations in `tools/` need no window, a script can call them directly, for example `arpes_viewer.tools.momentum.kspace.convert_map(...)`. Each folder has a README with the formulas and tests behind it; the layout and conventions are in the developer notes.

1.8 Where the program keeps its files

Where	What
`~/.arpes_viewer/`	settings remembered between sessions, the launcher's log, the agent bridge's token while it runs, the AI assistant's last folders

Where	What
`~/.arpes_viewer/sessions/`	the autosaved copies of computed datasets, one folder per session, and `operations.log` (§8.1)
`error_logs/` in the program's folder (else `~/.arpes_viewer/error_logs/`)	one text file per session in which an error happened (§8.3)
`<results>/_agent/`	an agent's command files, their output and pictures, when started from the AI assistant (§7.3)

Your data folders are only read; the program writes into them only when you save a file there yourself.

Part 2 — The main panel

The main window is a browser of datasets. This part covers the list and everything around it except the tool panel (Parts 4–6) and the AI assistant (Part 7).

2.1 The main window at a glance



The main window is a **browser**: one row per *dataset*, not per file (one `.nxs` file often holds several measurements, and each gets its own row). The kind is written after the name: `[Cut]`, `[Map]`, `[kz map]`, `[k-map]`, `[SPEM]`, `[EDC]`, `[Spin EDC]` …

It has three parts:

- **The tool panel** (left): the **AI assistant...** button at the top (Part 7), then every analysis and processing tool as a button, in three tabs: **Basic**, **Advanced** and **Figure** (Parts 4–6). Below the tabs, the **Datasets** box.
- **The list** (right), with its buttons.
- **The Memory box** (bottom left) and the version line (bottom right).

Action	How
Open a dataset in its own window	**double-click** the row (or right-click → **Open**)
Run a tool on the selected rows	its button in the **tool panel**
Stack several cuts into one map, or join a map / kz map measured in segments	**Combine...** under the list
Crop to a range, bin points, normalise each spectrum to itself	**Truncate...**, **Compress...**, **Self-normalise...** under the list
Open a map's slit or scan-axis cut	**right-click** the row (or a selection of rows)
Read the metadata, write the experiment log, rename, save, remove	the **Datasets** box of the tool panel, above Memory
See and free memory, close every viewer, open the autosave folder	the **Memory** box, bottom left
See which version you are running, report a bug, get the latest version	the title bar and the last line of the window (link to GitHub)

The four buttons under the list act on the rows selected above them, and each makes new rows — the originals are never changed.


The right-click menu holds only the ways of opening the rows: **Open**, **Open slit cut** and **Open scan-axis cut** (for a map). An entry that does not fit the selection is greyed, with the reason in its tooltip.

The Datasets box (tool panel, between the tools and Memory) holds the rest of what is done to the rows: **Experiment info**, **Log format...** and **Auto Exp. log** side by side (see the experiment log), **Rename**, **Save** and **Remove** on one row, and **Session log...**. Its buttons grey out when they do not fit the selection.

Finding and ordering rows. The **search box** above the list shows only the rows whose name or kind holds every word typed (`map 80K`); clear it to see them all. Hidden rows are deselected, so nothing out of sight is acted on. Right-click the list → **Sort by name** (`Cut_9` before `Cut_10`) or **Sort by data type** (grouped by the last processing tag of the name -- `[norm]`, `[E-E_F]`, `[k]` ... -- in processing order, then by kind and name; see §1.5).

2.2 Loading data

Load data... opens the loader. **Quick add...** skips it and adds the chosen files with everything detected automatically.




1. **Files** — pick one or many (*Select file(s)...*). The file filter is built from what the installed readers can open.
2. **Reader** — detected automatically, and the result is shown (*Detected: 3 × This program's own format*). Override it only if a file is being misread.
3. **Datasets found** — what is inside each file, read from its *structure* only. This is instant even for a multi-GB scan; nothing is read until you open a row.
4. **Axes** — *Axis order* reorders the array's dimensions once, at the door. *First axis of a map is* says what was scanned: a deflector angle (the default), a **photon energy**, a temperature, a gate voltage, a delay... This keeps the right unit everywhere afterwards, and stops a k conversion being offered for an axis that is not an angle.

CASSIOPEE folders. Select any file of a numbered series (`name_1_ROI1_.txt`, `name_2_ROI1_.txt`, ...) and the whole folder is listed once, as one assembled cube. Whether it becomes an angle map or a kz map is read from the `_i` parameter files next to the spectra. The row is named with the photon energy and polarisation read from those files — `FineMap 117eV LH`, or `KzScan 40-120eV LH` for a photon-energy scan — so repeats of the same scan at another energy or polarisation can be told apart.

ANTARES photon-energy (PhD) files. A PhD `.nxs` file (one `Phd_NNNN` entry per photon energy) is listed as one `kz map`: the frames are sorted by photon energy and each kinetic-energy axis is referred to E_F with its own hν (work function 4.5 eV, which the k_z conversion then uses). Each frame still opens on its own as a cut.

2.3 The experiment log

Two buttons side by side in the **Datasets** box write the beamtime's log -- a CSV file, one row per measurement -- from the files' own metadata: **Log format...** (left) sets it up once, **Auto Exp. log** (right) adds the selected datasets to it with one click.



Log format...

1. **Log file.** Choose the folder and type the file name. If a log of that name already exists, the window shows **that log's own format**, ready to adjust.

2. **Format.** *Separator* and *Decimal mark* are by default what Excel uses on this computer. Excel splits a CSV at the system's list separator -- a **semicolon** wherever the decimal mark is a comma (French, German, Italian... settings) -- so a comma-separated file opens there with everything in the first column. Leave them on *auto* unless the log is for a computer set up differently. *Ranges as:* writes a range `start/stop/step` or `start:step:stop`.

3. **Columns.** *Fields of:* picks a dataset of the main list -- choose one of the kind you log most -- and **Read fields** lists everything it has, with its value: the file name, data type, start time and scanned ranges worked out from the data, then every metadata field and motor. **Tick** a field to add it as a column. In the table on the right, double-click a heading to rename it (`hν/Δ`, `Polar/Δ`, `Epass`...), and use **Top** / **Up** / **Down** / **Bottom** to put the columns in any order. **Add empty column** gives one to fill in by hand (comments). **Save format as...** / **Load format...** keep one format per beamline.

4. **If scanned.** What a position or angle column says depends on the measurement:

   - a **cut**: the sample stood still -- the motor's value;
   - a **SPEM** scan: the scanned stage axis as `start/stop/step` (choose *SPEM: scanned X* / *Y* for the stage columns);
   - a **map** taken with the manipulator rather than the deflector: the angle as `start/stop/step` (*map: scanned angle*), and a sample position the beamline corrected along with the angle as `first..last`;
   - a **kz map**: the photon energy range (*kz map: photon energy*).

auto (the default) recognises the scanned motor by name, and a position that moved by its values. Any other measurement gets the field's own value.

5. **Save format.** If the log already holds records and you changed its format, it is **rewritten under the new header**: each record moves with its columns (renamed or moved columns are followed), new columns are empty for the old records, and columns you took out are named first, since what they hold goes. The header stays the only first row.

Skip datasets already in the log leaves out files whose name is already in the log's file-name column. **Keep recording** logs every file you add to the list from then on, until the program is closed: during a beamtime, add each file as it is measured and the log keeps itself.

Auto Exp. log adds the selected rows to the log, after its last record, without opening anything; the status bar says how many were added. The very first time, it opens *Log format...* first.

If the log is open in Excel, Windows will not let it be written: close it there and click again.

2.4 Combining datasets: stacking, joining and summing


Combine... (under the list) does two different things, and asks which:

- **Stack** — *cuts only*. Each cut becomes one slice of a new map, along an axis you name: a temperature series, a gate-voltage series, one cut per photon energy. The result is looked at like any map — sliced at constant energy, or along the new axis.
- **Join** — *cuts, maps, kz maps or k-maps, all of one kind*. The pieces of one measurement that was taken in segments are put back end to end along one of their own axes: a map whose deflector range was scanned in two parts, a kz map whose photon-energy range was split over several runs, a cut whose energy window was taken in two halves.

Stacking cuts


1. Select the cuts in the list (Ctrl/Shift-click) and press **Combine...**. Stacking needs one axis the same point for point (same number of points, same values, same units). If the **other** axis differs — typically energy windows a little apart between the cuts — the cuts are still stacked: that axis is **truncated** to the range all of them cover and each cut resampled onto the first cut's points there (the dialog says so, with the range). If both axes differ, or the ranges do not overlap, *Stack* is greyed with the reason, and *Join* is offered instead.
2. It asks whether to combine them **in the list's order**. *Yes* keeps that order; *No* lets you choose it.
3. Choose **Stack**, then set the new axis: **New axis is** (temperature, gate voltage, photon energy, delay, position, other — this fills in *Name* and *Unit*, which you can change), **Start** and **Step**. Each cut is listed with the value it gets. If you chose to reorder, **drag** the rows (or use **Move up** / **Move down** / **Reverse**). Press **Combine**.

A photon-energy series of angle cuts becomes a `kz map`, so *Align Fermi levels (kz map)* and *Convert to momentum (kz, k∥)* take it (see §4.9); any other axis gives a `map` whose first axis is marked as not an angle, so no k conversion is offered for it.



Joining pieces of a measurement

1. Select the pieces (all maps, or all kz maps, or all cuts …) and press **Combine…**. Maps and kz maps go straight to *Join*.
2. **Join along**: the axis the measurement was split along. It starts on the axis whose range differs between the pieces — a map's deflector axis, a kz map's photon energy, or the energy of cuts taken in two energy windows — so it is usually right already.
3. **Where pieces overlap**: *Average them*, or keep the earlier / later piece in the order shown (drag the rows to change it).
4. The dialog lists each piece's range and shows the **Result** — the joined range and the number of points — with notes on anything it had to do. Press **Combine**.



How the axes are handled:

- Pieces on one common grid (same step, ranges that meet or overlap by whole points — the usual case) are **copied as measured**, nothing interpolated.

- A piece with a different step or a half-step offset is **interpolated** onto the common axis (the first piece's step), and the dialog says so.
- If the **other axes** differ — an energy window a few meV different between runs, a different number of slit channels — every piece is resampled onto the range they **all** cover, and the dialog says so.
- A stretch that no piece covers is a **gap**, left at zero and reported.
- A joined kz map is still a `kz map`: run *Align Fermi levels (kz map)* on the joined result rather than on the pieces (per-photon-energy fit results of the pieces are not carried over).

Summing repeated scans

For a fine cut or map taken as many short scans so that an ageing sample can be caught. Select the scans (two or more of one kind) → **Combine...** → **Sum repeated scans** → **Combine**, which opens the repeated-scans window:

1. **Are these repeats?** Each scan's grid and recorded conditions (photon energy, polarisation, angles, position, temperature, pass energy, lens mode); orange marks a value that differs from the first scan.
2. **Has the sample changed?** Press **Compare the scans**. Each scan is compared with the sum of the others: χ^2 */ point* is about the same for scans that differ only by counting noise and grows when the spectrum changed; scans well above the rest are marked **changed**. The energy shift of each scan's EDC and its count rate are listed; click a row to see its EDC against the rest.
3. **Sum.** Tick the scans to keep (changed ones start unticked), choose whether to undo the energy shifts, **Sum** or **Mean**, and **Sum to list**.

2.5 Step-by-step windows


The tools that take several decisions open as **numbered steps** (sum repeated scans, detector corrections, tight-binding fit, crystal structure, calculated bands): the title says *Step 2 of 4: …*, a blue box says what the step is for and what to do, **Next →** stays greyed (with the reason beside it) until the step is done, and **← Back** or the list of steps on the left goes back.

Part 3 — The data viewers

Each dataset opens in a viewer window of its own. This part covers what all viewers share, then each kind of data in turn.

3.1 What the viewers have in common

Each dataset opens in its own window, so you can put a map, its cuts and another file side by side.



- **The top row**: the **Functions** menu (everything the window can do), **Plot tools** (guide lines and labels on this plot — see below), the colormap (per window) with **Flip**, and the view controls — axis ranges, **Auto**, **Inv** (invert), **Reset**, **Grid**.
- **Above each image**: the **Levels** bar (drag the two handles, or type **Min%/Max%** percentiles; **Clip** applies them) and **Gamma**. A min/max you set is kept while you move the slice (the energy of a contour, the angle of a cut, the cursor of a spatial map), so every position is on the same colour scale; drag the handles back to both ends, or set 0%–100%, to follow each frame's own range again.
- **Under each image**: **Smooth** (display only, does not change the data) and **Lock x/y** (aspect ratio).
- **Readout cursor** — right-click the image → *Readout cursor*. It reports the value under it and, on a cut, draws the **EDC** (right) and **MDC** (below) through that point. **EDC ±** / **MDC ±** integrate over a window, shown as a shaded band on the image. Type a position into the **Cursor** row and press Enter to put it exactly there.
- **EDC → list** / **MDC → list** put the curve on screen in the main list as a dataset of its own (see §3.5).
- **Right-click the image → Export** saves what the panel shows — data (`.nxs`), an image, or vector axes (`.eps`); see §6.1.
- **Functions → Slice → Save slice to the main list / Freeze slice in a new window** keeps a copy of the slice on screen. The frozen window (and *Open this position in a new window* on a spatial map) opens with the panel's min/max and gamma, so the two can be compared directly. It has its own **Plot tools**, and a **Figure composer...** button to make a figure of it (§6.1).

The **Functions** menu now holds only what works on the window itself — the tools that take a dataset are in the launcher's tool panel (§2.1):


Viewer	Functions
map / kz map / k-map (contour)	Arbitrary cut; Slice: save / freeze the slice
cut	Straighten bands (FS correction); Slice: save / freeze
a map's slit cut	Straighten bands (FS correction) for the whole cube; Show the map
curve	Curve fit, Spin analysis; Crop, Bin, Normalise, Background, Shift axis, Add √N errors


An entry that applies but cannot run yet is greyed, with the reason in its tooltip.

Brillouin zone tick box. A k-map or converted kz map on which a zone has been plotted (§4.11) keeps it: its viewer has a **Brillouin zone** tick box on the top row that shows or hides it.

Plot tools: guide lines and labels on the plot

Plot tools on the top row of every viewer (cuts, maps, spatial scans, curves, frozen slices) opens a small window that draws **on the plot in front of you**:






- **Type**: *Vertical line*, *Horizontal line*, *Line at an angle* (through a point; the angle is in the plot's own units, i.e. the slope is tan(angle) y-units per x-unit), or *Text label*.
- **Position** (x, y), **Angle**, an optional **Label** (shown on the line, e.g. `E_F`, `Γ`), a **Colour** (nine one-click colours, or **More...**), **Width**, **Style** (solid, dashed, dotted, dash-dot) and **Text size**.
- **Add** draws it at the position typed (**Centre of view** fills that in); **Place by clicking** draws one wherever you click on the plot.
- **Drag** a line on the plot to move it; the window follows. Select a guide in the list to **edit** it — every change shows at once — or **Remove** it; **New guide** stops editing; **Remove all** clears the plot.
- In a window with more than one panel, **Draw on** chooses which.
- Guides stay while the slice moves (an E_F line stays at E_F as you scroll through a map) and while the Plot tools window is closed. The panel's **Export → Image** draws them too (*Include the Plot tools guides*).


Plot tools are for looking at the data. To make a figure for a paper, use the **figure composer** and its **Figure tools** (§6.1).

3.2 Maps: the contour and its two cuts


A map opens on its **constant-energy contour**. The slider at the top picks the energy (**Pos** in eV, or **Ind** as an index; **±** integrates over a window, **mean** or **sum**). **Scan-axis cut** and **Slit cut** open the two orthogonal cuts, each in its own window. (The scan axis is whatever was scanned to make the map — usually the deflector angle, but a manipulator rotation or, for a kz map, the photon energy — so the button is named for that.)



Slit cut (slit angle vs energy)



Scan-axis cut (deflector angle vs energy)





One cursor for all three windows. Switching the readout cursor on in any of them switches it on in the others, and moving it anywhere re-slices the others through the new point. The axes keep one colour each everywhere: **deflector red, slit green, energy blue**. A cursor line has the colour of the axis it holds constant, and the EDC or MDC it feeds is drawn in the same colour. Integration widths (the ± boxes) belong to each window and are never shared.

From the list you can also open a map's cut straight away (right-click → **Open slit cut** / **Open scan-axis cut**); the contour then stays hidden until you ask for it (*Functions* → *Show the map*).


3.3 Arbitrary cuts and Fermi-surface correction

Arbitrary cut

Functions → Arbitrary cut… on any contour: click up to six points (or type them) and the cut runs through them in order — here Γ → M → K → Γ on the k-map. **One dataset per segment** lists each leg separately.


Path on the contour	Points
	

The result is a cut against the distance along the path; the corners of the path are marked with dashed green lines, so a kink there is not mistaken for physics.




Fermi-surface (FS) correction

Functions → Straighten bands (FS correction)... on a cut (or a map's slit cut) straightens a feature that should be flat — usually the Fermi edge, which curves across the analyser angle. Click along the feature; a polynomial (order 2 by default) is fitted and every angle column is shifted in energy. **From a reference (Au)...** takes the curve from a gold spectrum in the list instead. On a map's slit cut the same shift is applied to the whole cube.




3.4 kz maps and k-maps

A **kz map** (photon-energy scan) opens like an angle map: its contour shows photon energy against the analyser angle at the energy chosen by the slider, and its two cuts are the spectrum at one photon energy and the photon-energy dispersion at one angle. Align its Fermi levels and convert it to (k_z, k∥) from the Basic tab (§4.9, §4.10).




A **k-map** (a map converted to momentum, §4.8) and a **converted kz map** open in the same contour viewer, on momentum axes. When a Brillouin zone has been drawn on them (§4.11), they keep it, and a **Brillouin zone** tick box on the top row shows or hides it. Slice series (§5.6) and exports draw it too.



3.5 Curves: EDCs, MDCs and the curve fit


EDC → list / **MDC → list** under any image, or a spin-resolved file, give a curve dataset, which opens in the **curve viewer**:



Channels can be hidden, offset into a waterfall (**Offset**), shown with **Error bars** (from a σ channel), and **Range** marks an x window used by the operations. *Functions → Transform* gives **Crop**, **Bin**, **Normalise**, **Subtract a background** (constant, linear, Shirley), **Shift the axis** and **Add counting errors (√N)**; each makes a new dataset and propagates σ correctly.

Curve fit


Functions → Curve fit…: **Peaks on a background** (Lorentzian, Gaussian or Voigt peaks placed by clicking or **Find peaks**; none / constant / linear / Shirley background; instrumental resolution; optional **× Fermi edge**), or the **Fermi edge** itself. Weighting is the channel's own σ, √N, or uniform. Every parameter comes with its error; the residual is shown in units of σ.




Fit to list keeps data, fit, residual and components; **Copy results** copies a tab-separated table. A Fermi-edge fit can **List a copy with E_F = 0**.

3.6 Spin-resolved data

A spin EDC opens with one curve per spin channel:



Functions → Spin analysis…:



- The table reads each channel's label (manipulator setting, target magnetisation, axis and sign counted as "up"); **Axis** and **Counts as** can be overridden.

- **Cross ratio** (default when the channels allow it) cancels both the transmission and the target reflectivity exactly; **one pair** is available but carries the instrumental asymmetry, which is measured and reported (ε).
- **S_eff** (Sherman function, default 0.2), **Bin**, optional **Zero reference** window.
- Plots: raw channels, P with its error bars, and I↑ / I↓ with errors.
- **P to list**, **I↑ / I↓ to list**, **As a figure** (opens the figure composer).

3.7 Spatially resolved scans (nano-ARPES)


A real-space scan opens in **two windows**: the **spatial map** (the total intensity at each position) and, beside it, the **E vs k spectrum at the cursor** in the cut viewer — with the cut viewer's own tools (Functions, the readout cursor with EDC/MDC, Export). On the map, the **readout cursor** (on from the start) picks the point: drag it, or type a position in the **Cursor** row under the map. Closing either window closes both.


Selection box — in the row above each picture. Tick it, drag the box (or type its corners **x0 y0 x1 y1**), then press **Refresh** (or Enter); nothing is computed until then, so a large scan is read only when you ask. Unticking the box hides it but keeps its corners — tick it again and it is back where it was — and keeps the **result**: the integration stays on screen until you press **Reset** (beside Refresh).

- on the map, the spectrum window shows the spectra **summed over the box**. The spectrum stays the box's sum, ticked or not, until **Reset**; then it follows the cursor again;
- on the spectrum, the map shows the intensity of the chosen **(k, E) window** across the sample — how a domain or a flake edge is found. **Reset** gives the full map back.

E vs position / k vs position — two tick boxes on the row under the selection box (one at a time). They draw, **beside and under the map**, the spectrum through the cursor against each spatial axis: energy (or k) against position, sharing the map's axes. Two **dashed lines** appear on the spectrum: the band of k (for E vs position) or of energy (for k vs position) the picture is integrated over. Drag the lines (the shaded band between them does not take the mouse, so a selection box under it can still be dragged), or type **from / to** in the **Band** boxes above the spectrum. The window grows to make room for the pictures beside and under the map, so the map keeps its size, and shrinks back when they go.


Line cursor — right-click the picture beside or under the map → *Line cursor*. A line at one energy (or k) appears on that picture, and the intensity along it is plotted against position **further right** (for the picture beside the map) or **further down** (for the one under it). Drag the line to move it; untick the entry to remove it.


Functions
Plot tools
Colormap
gray
Flip
View
X: -1.0000
59.0000
Auto
Inv
Y: -1.0000
49.0000
Selection box
x0 0.0000
y0 0.0000
x1 0.0000
y1 0.0000
Refresh
Reset
Spectrum vs position
E vs position
k vs position
Spatial overview
Levels 1.846e+04
4.783e+04
Clip
Min% 0.00
Max% 100.00
Gamma 1.00
x=30
y=24
value=33755
y (µm)
x (µm)
E - E_F (eV)
Intensity
Cursor x (µm) 30
y (µm) 24
value 33755
Smooth
blur 0.0
Lock x/y 1.000
Line cursor at E - E_F (eV) = -0.3


Functions
Plot tools
Colormap
gray
Flip
View
X: -12.1905
12.1905
Auto
Selection box
x0 0.0000
y0 0.0000
x1 0.0000
y1 0.0000
Refresh
Reset
E - E_F (eV) vs Angle, slit (deg) — x=30, y=24
Levels
0
59
Clip
Min% 0.00
Max% 100.00
Gamma 1.00
E - E_F (eV)
Angle, slit (deg)
Smooth
blur 0.0
Lock x/y 1.000
The spectrum at the map's cursor. Selection box: drag, then Refresh to integrate the map over it.

3.8 Exporting a panel and saving data

Right-click any image → **Export** → **Data (.nxs, Igor)...**, **Image...** or **Axes only (.eps)...**. It always exports exactly what the panel shows (range and all): the data as a dataset this program reads back, or for Igor Pro (`.itx` text or `.ibw` binary wave, with the axes scaled, the units set and the metadata in the wave note); an image with the colormap applied (PNG, TIFF or JPEG, at a chosen size and dpi, with or without the axes, with the Plot tools guides if there are any, and with the Brillouin zone if the dataset has one); or the frame, ticks and labels as vector PostScript to place the image in, in Illustrator (optionally with the Brillouin zone drawn in the box — see §4.11).



Save (tool panel, Datasets box) writes the selected datasets to a `.nxs` file of your own -- several selected rows go into one file -- or, by choosing the file type, for Igor Pro: one `.itx` holding them all, or one `.ibw` per dataset. An Igor file is a copy; the rows stay as they were.

Part 4 — The tool panel: Basic tab

The **Basic** tab holds the steps nearly every dataset goes through: the Fermi level, the detector, the background, the conversions to momentum, the core levels and the Brillouin zone.

4.1 How the tool buttons work

Each tab groups its tools by the data they take: *2D & 3D — cuts, maps*, *2D only — cuts*, *3D only — maps*. **A button lights up only when the rows selected in the list are what it takes**: a k conversion (cut) needs one angle cut, cut arithmetic exactly two cuts, a 3-D view a map. Hover over a greyed button to

see why it is greyed.




A tool never changes the rows it was given: its result is a new row in the list, named after the original with what was done (`cut1 [k]`), and its history records the step and its parameters (*Experiment info* shows it). Tools that take several decisions open as numbered steps (§2.5).


4.2 Fermi edge fit

The usual order for a single cut is: **Fermi edge fit → offset the energy axis → convert to momentum → MDC/EDC fit**. Each step is a button of the tool panel: select the cut in the list and press it.

Tool panel → Basic → **Fermi edge fit...** fits a Fermi edge (Fermi–Dirac × linear DOS, convolved with a Gaussian resolution) to the EDC summed over a box. It opens the cut's viewer together with the fit window; the two belong together, and closing either closes the other.

1. Press **Show the selection box** and drag the box on the cut over the edge (or type the angle and energy ranges). The angle range says which channels are summed; the energy range is the fit window.






2. **Estimate**, then **Fit**. Tick **Hold** to keep a parameter fixed (the temperature is held at the recorded value by default). Every parameter is reported with its uncertainty.

3. **Offset energy axis** lists a copy of the cut on **E − E_F**.

The *Advanced* corner divides the Fermi cut-off out (for gaps and reference samples) or fits E_F channel by channel.


On a map. Select a map (angle map or k-map) and press the same button: the map's **slit cut** opens with the fit window, and the slit cut's slider picks which cut is fitted. After a fit, **Offset energy axis** asks whether to shift **the whole map by this cut's E_F** (*Yes*) or to fit **one E_F per cut** (*No*). With one per cut, the **Fitted cuts** list on the right fills as you go: move the slider, press **Fit**, repeat. A second fit at the same place replaces the first, and every E_F in the list can be edited by hand. Cuts between two fitted ones are shifted by a straight line between their neighbours (beyond the first and the last, by the nearest fit), shown in the plot under the list. **Offset energy axis by these fits** lists the corrected map.



4.3 Removing the detector grid

MCP (hexagonal) and mesh (square) patterns print on every image. **Do it first**: only data still on the detector's pixels can be de-gridded, so the button refuses anything already converted, corrected or smoothed, and says why.

Select a map (or kz map) or a cut and press tool panel → Basic → **Remove detector grid...**. For a map, no reference is needed — the grid stays on the same pixels in every slice while the photoemission moves. **Find and remove the grid**:



- **Before / After** a chosen slice on one colour scale (tick **Show −∂²I/∂E²** to make any grid obvious).
- **The grid found**, its **k-space regions** (in red), and the **contrast and shift** fitted for every slice.
- The power left in the grid regions (1 = no grid left).
- **Also list the grid pattern** keeps a `[grid]` dataset, which a cut taken later with the same lens mode and pass energy will find and use.

4.4 Detector corrections

On a cut, map or kz map as measured:


1. **Keystone** -- tick *Correct a trapezoidal image* and drag the four yellow corners onto the lit area; the right picture shows it made rectangular, each line's counts kept.
2. **Bad regions** -- **Add a region** and drag it over a dead or hot spot, or **Find bad pixels**; fill *smooth* (best for a spot) or *linear along* an axis (for a stripe).
3. **Apply** -- **Apply to list**. Do the grid removal, Fermi level and k conversion on the result.

4.5 Background subtraction


Tool panel → Basic → **Background subtraction...** (cuts) removes the intensity that is not the bands: a **Shirley** or **Tougaard** inelastic background, a floor common to every angle (a percentile of each energy row), a smooth **polynomial** — or it divides out the **Fermi cut-off** (Fermi–Dirac at the temperature and resolution the file records, starting at the E_F it records or else at the steepest fall of the angle-integrated EDC). The window is the same as the Advanced tab's processing windows — source and result side by side, live preview, **Apply** lists the result — described in §5.1.


4.6 Converting a cut to momentum

Tool panel → Basic → **k conversion (cut)...** converts the angle axis to k∥ (Å^{-1}). A **vertical line** is drawn on the cut: drag it to the slit angle of Γ. The cut is then taken to run through Γ — not exact if it misses Γ, but the only choice when only this cut was measured.



- **Advanced: Γ off this cut** is for a cut that does not run through Γ: type the deflector and slit angles of Γ, or **From a converted map...** to inherit them from a map of the same sample already converted.
- **Output energy — Energy axis as E − E_F** (off by default): tick it and type where E_F is on the cut's own energy axis; the result's energy axis is then E − E_F. The momenta do not change — the conversion still uses kinetic energies.
- **Energy offset** (a tick box, off by default) is *not* the Fermi level: ticked, its value is added to the energy axis before converting, for an axis that is not a true kinetic energy. If the cut is already on E − E_F, it is ticked and filled in with the E_F that was subtracted (the note under it says so): the conversion uses true kinetic energies, and the result stays on E − E_F.
- **Remembered settings.** The dialog starts from the last conversion of a cut of the same size (same number of points on each axis) — the usual case for a series of cuts of one sample. The map and kz conversions do the same.







4.7 Core-level check

A wide scan of the core levels is listed as a cut too. Select it and press tool panel → Basic → **Core-level check…** to find out what its peaks are.


1. Type the sample's elements — `NbSCl` or `Nb, S, Cl` — and press **Next**. *Match within* (0.5 eV) is how close a peak must be to a tabulated level to count as the sample's.



2. Check the energy reference. E_F is fitted when the window holds the Fermi edge, otherwise put at hν − W. Change the photon energy, the work function or E_F if they are wrong (the green line can be dragged); a hν − E_F far from 4–5 eV means the photon energy is off. Press **Analyse**.



3. The results: the EDC on a binding-energy axis, each peak marked — green *sample* (orbital named), orange *uncertain* (a level of the sample within 2 eV: chemical shift or charging — your call), red *not the sample* (common elements that could explain it: contamination, higher-order light, Auger lines). Click a row for the full list of candidates. Type your own assignment in the *Assignment* column.





Weak lines and peaks by hand. Tick **Log counts** to see weak lines next to a strong one; **Min height** (default 0.2 % of the strongest) sets how small a found peak may be. To add a peak the search missed, press **Click to add peak** and click the plot (a double-click always works), or type its binding energy after *or at* and press **Add**: its position is refined by a local fit, it is marked ◆, and it is named with every tabulated level within ±2 eV. **Remove selected** drops peaks; **Reset peaks** brings back the found ones and forgets those added by hand. Assignments you typed survive a **Re-analyse**.

Peak table... lists every tabulated level, filtered by element and binding-energy range: look a peak up, show a level on the plot, or add it as a peak with that level as its assignment. **Select range** shows a band you drag over a region; **Zoom window...** opens it (or the current view) in a window of its own with a cursor, a Gaussian fit at the cursor, and the negative second derivative divided by the intensity — which shows a shoulder or a weak line beside a strong one as clearly as the strong one.


If every peak is off by the same amount, the notes say so and **Apply suggested shift** corrects it (a charged sample, or a wrong E_F). **Add EDC to list** lists the EDC on the binding-energy scale; **Copy report** copies the whole result as text. Measuring at a second photon energy settles what stays doubtful: core levels stay put in binding energy, Auger lines and higher-order light move.

4.8 Converting a map to momentum

Select an angle map and press tool panel → Basic → **k conversion (map)...**. The map opens on a bare constant-energy contour — no cuts, no other functions, just the picture — next to the conversion window; the two close together. Drag the readout cursor to the point that should become **k = (0, 0)** — the dialog follows it — then **Convert**. The result is a new `k-map` row in the list.


The contour for picking Γ	The conversion
	

- **Γ deflector angle / Γ slit angle**: the angles of the point that becomes k = (0, 0), filled in from the cursor.
- **Sample rotation** turns the map about the surface normal; **Set rotation from contour...** reads it off a direction you click on the contour (two points along a mirror line, say).
- **Output grid**: number of points, or resolution (Å⁻¹, meV). The numbers of points start at the measured ones — as many kx points as deflector angles, ky points as slit angles, E points as energies.
- **Output energy — Energy axis as E − E_F** (off by default): tick it and type E_F as it is on the map's energy axis; the k-map then comes out on E − E_F. The momenta are the same either way.
- **Energy offset** (a tick box, off by default) is not the Fermi level: ticked, it is added to the energy axis before converting, for an axis that is not a true kinetic energy (ticked and filled in automatically for a map on E − E_F).
- The settings start from the last conversion of a map of the same size, so a second map of a series needs no retyping.




4.9 Aligning the Fermi levels of a kz map

A photon-energy scan is listed as a `kz map`; its contour is photon energy against angle at one energy.




Nothing in the files says where each spectrum's Fermi level really is. Tool panel → Basic → **Align Fermi levels (kz)...** measures it from the spectra themselves; the kz map's slit cut opens with it, and the two close together.

1. The slit cut opens with a box on it. Drag the box over a Fermi edge — the angle range sets the channels summed, the energy range the fit window.




2. **Fit and assemble**: the same box (by detector index) is used for every spectrum; each is shifted to put its own edge at zero; the cube is cropped to the range they all cover; and, by default, each spectrum is **normalised by its total intensity**, which divides out the photon flux.



E_F against photon energy is plotted. A smooth curve means the fits are sound; points whose fit is not believed are marked and filled in from their neighbours.


4.10 Converting a kz map to momentum

Tool panel → Basic → **kz conversion...** converts the scan to (k_z, k∥). It starts from the last conversion of a scan of the same size.



- **Inner potential V0** is the unknown: the preview reconverts one energy slice as you change it, in milliseconds. It may be negative (down to −30 eV; the report then says so). **Γ at hν → Set V0** gives the V0 that puts Γ at normal emission at the photon energy you name (the zone order nearest the present V0 is shown).
- **Manipulator theta** is off by default: a kz map is taken with the slit through Γ. Tick *Correct a manipulator theta offset from Γ* only to correct an offset, and type it **relative to normal emission** — the motor's absolute reading in the file is shown in the tooltip, not used.
- **Output grid**: by default k∥ gets one point per analyser angle channel and k_z the number that makes its step the same (*Match the measurement* sets it again); the steps are in the report.
- The energy of the preview is the **slider** beside it; above it are the data viewers' colour controls: colour map, *Flip*, and the level bar (levels, *Clip*, percentages, *Gamma*).
- **Calibrate hν from each fitted E_F** (optional, off by default): after the Fermi level has been fitted per photon energy (kz map → align E_F), uses hν − E_kin(E_F) measured at each photon energy instead of the single work function — for a monochromator whose hν is off. The default is the single work function, with E_F already flattened.
- With the **lattice** (space group, a, b, c), the **surface normal** and **Rotate k// by** (the slit direction as a turn about the normal from a*, or the first reciprocal axis not along the normal — any angle, since the slit need not run along a high-symmetry direction), the zone boundaries are drawn over the preview.


- **Measure a k_z period...**: click two points that are the same feature one zone apart; the matching reciprocal-lattice planes are listed.
- **Show the k_z plane in the 3D BZ...**: the BZ overlap tool's turnable cut-plane view, with the plane this map measures (surface normal and k∥ direction, through Γ), the high-symmetry points it holds, and the measured k_z range in zone periods; it follows the settings as they change.
- The yellow banner warns when the Fermi edge still bends across the analyser angle — correct it first (Straighten bands (FS correction) on the slit cut). The bend is a parabola fitted through the edge of blocks of neighbouring channels, the weak channels at the slit ends left out, so one noisy channel or a band crossing E_F does not set it.
- **Convert the whole cube** lists a `kz map (k)`.



4.11 Brillouin zone


Select a k-map (or a converted kz map) and press tool panel → Basic → **BZ overlap...**. Like the map conversion, it opens a contour of its own with the zone window, and the two close together.

1. **Space group** first (1–230); the lattice parameters it fixes are greyed and follow the free ones. Or switch to **2D layer** for a surface lattice.
2. **Cut plane**: the surface normal (hkl) and an offset along it — the cut of the 3-D zone by that plane is drawn, for any surface, not only (001). **Through point** lists the offsets at which the plane passes through a high-symmetry point (Γ, Z, L, F ... for a rhombohedral crystal); choose one rather than working the number out. **Show cut plane in 3D...** previews it, with the named points marked and the ones in the plane ringed; **Label high-symmetry points** writes them on the contour, which is the quickest way to set the azimuth. The dialog opens on the last crystal you used, so a second map of the same sample needs no retyping.
3. **Conventional** or **Irreducible** zone; **Azimuth** (or **Pick direction from contour...**); **Repeat across the field of view**.
4. **Moiré** adds a second, twisted or mismatched layer and its moiré zone.
5. **Plot**.




The window is tall; it scrolls, and can be resized like every other window.

The zone stays with the dataset. Once plotted, it is a property of the k-map: it is saved with it into a `.nxs` file, and its viewer shows it with the **Brillouin zone** tick box on the top row. **Clear overlay** removes it.



Its exports can draw it too: **Export → Image...** has **Include the Brillouin zone**, and **Axes only (.eps)...** has **Draw the Brillouin zone in the box**, so the zone comes out as vector lines over the image in Illustrator.



Part 5 — The tool panel: Advanced tab


The **Advanced** tab holds the analysis that follows: band-sharpening filters and symmetrising, ridge detection, stack plots, MDC and EDC fits with the self-energy, cut arithmetic, the slice series figure, the 3-D views, and the Fermi-pocket analysis for quasi-two-dimensional samples (under test).

5.1 Smoothing, derivatives, curvature and symmetrising

Each filter has a window of its own, opened from the tool panel with one or more cuts (or maps) selected:

Tab	Button	What it does
Basic	**Background subtraction...**	removes the intensity that is not the bands: Shirley or Tougaard inelastic background, a floor common to every angle, a smooth polynomial — or divides out the Fermi cut-off
Advanced	**Smooth...**	Gaussian, Savitzky–Golay or moving average, with optional spike removal
Advanced	**Second derivative...**	$-d^2I/dE^2$ or $-d^2I/dk^2$ after a pre-smooth, to sharpen the bands
Advanced	**Curvature...**	1-D or 2-D curvature (Zhang et al.), which follows the band better than a second derivative
Advanced	**Minimum gradient...**	$I/\|\nabla I\|$: bands as the valleys of the intensity's gradient — first derivatives only, so less noise; shoulders show
Advanced	**Symmetrise...**	mirror a cut about a line; for a map, mirror or rotate its constant-energy planes

Every result is a new dataset carrying the steps that made it.




Minimum gradient. Along a band's crest the intensity is flat, so the modulus of its gradient |∇I| is smallest there (He, Wang and Shen, Rev. Sci. Instrum. 88, 073903 (2017)). The window shows that valley in one of three ways: **I / |∇I|** (the one to use: an intensity that varies slowly along the band cancels, and empty regions stay dark), **1 / |∇I|**, or **|∇I|** itself (bands as dark lines; nothing is divided, so it is the check on the other two). It needs first derivatives only, so it is less noisy than a second derivative or the curvature; it favours neither axis, so a band is followed through its turning point; and a shoulder shows. **Floor** caps how bright a perfectly flat patch can get (lower it on smoothed data for a sharper line). It marks *every* flat place — also the floor between two bands — so read it beside the data, and take numbers from a fit.

- **Source** and **Result** are shown side by side on the same scale, so you can see when a setting has eaten the band. They pan and zoom together.
- **Smooth first.** The second-derivative and curvature windows open with a tip: both amplify noise, so they usually work better on data smoothed first — run **Smooth...**, select its result in the list, and open the filter on that, or raise the pre-smooth widths in the window itself. A smoothed result carries the tag **‹smoothed›** in the list (and so does anything made from it); on such data the tip is replaced by a short "already smoothed" line and the pre-smooth widths start at 0.
- **Shape**: *Square pixels* (one data point is square — undistorted for an angle-vs-energy cut), *Equal axes* (one unit is the same length on both axes — right for angle-vs-angle or k-vs-k; chosen automatically when both axes have the same unit), or *Fill the box*.
- **Live preview** re-computes as you change a value; **Apply** lists the result.
- Starting values: **Symmetrise** mirrors about a vertical line through angle (or k) = 0, i.e. k → −k; the **Fermi cut-off** under *Background subtraction* starts at the E_F the file records, or else at the steepest fall of the angle-integrated EDC, with the file's temperature and resolution.

For a map the window works plane by plane, and asks **which planes** first — constant-energy maps or dispersions — since the curvature of a contour and the curvature of a cut are different quantities. **Preview at** picks the plane shown; **Apply to the whole cube** runs it on every plane. The operations


and widths are named after the chosen plane's own axes (*Second derivative along Kinetic energy*…), and the smoothing widths start at 1/100 of each axis.



Truncate…, **Compress…** and **Self-normalise…** (under the list) change the grid or the scale of one or several datasets at once — as long as they have the same kind and the same number of points on every axis: **Truncate** crops to a range, **Compress** bins points together, **Self-normalise** divides each spectrum by its own total.

Self-normalise divides each piece of the data by its own total (or peak):

- **Normalise** picks the piece in ARPES terms, and starts on the usual one: *each EDC* for a cut, *each cut (slit × energy at one scan step)* for a map, k-map or kz map — this takes a flux or beam-current drift along the scan out. Other choices: each MDC, each EDC of a map, each constant-energy map, or *custom*.
- **Summed over** shows the axes this sums over; the ticks can be changed by hand, and the sentence under them says what the current ticks do ("Each plane over Angle, slit × Kinetic energy is divided by its own total — one factor for every Angle, deflector").
- **Sum only over** restricts the sum to a window on one of the summed axes — the energy by default — for example the energies of a core level.




5.2 Ridge detection

Tool panel → Advanced → **Ridge detection...** (cuts or maps) traces bands as ridges of the intensity, each point to a fraction of a pixel, which is sharper than a second derivative and draws no false double lines.

- **Smoothing** along each axis, in its own unit — about the band's width.
- **Threshold**: raise it until only the bands are left (yellow points on the source).
- **Result to list** — the ridge image (a map plane by plane, on the planes chosen); **Save ridge points...** — a CSV that the tight-binding fit (§6.4) reads.

5.3 Stack plots


Stack plot (EDC / MDC)... (tool panel → Advanced, with a cut selected): a waterfall of EDCs or MDCs, with the number of curves, binning, normalisation, offset, shear and colouring controls; **Send to figure composer** makes it a figure panel.



5.4 MDC fit and EDC fit

Two tools of the tool panel's Advanced tab fit peaks line by line:

- **MDC fit (k-cut only)...** fits the momentum distribution curves and reads the band off the fitted centres: Fermi velocity, effective mass, self-energy. It only takes a cut whose axis is already in $Å^{-1}$ — a velocity in eV·deg would be meaningless — and its button is greyed otherwise.
- **EDC fit...** fits the energy distribution curves, on any cut, optionally with the Fermi cut-off in the model. v_F and m* from the fitted band need a cut in momentum.




Guided fit (step by step), at the top of the panel, walks through the whole fit beside the controls, one step at a time, saying what each step is for and outlining the part of the panel it uses: what an MDC (EDC) fit does, the line shape, the range (*Start here* / *End here* at the blue line), the bands, the seeds (the guide moves the line to five places in the range — click the band's peak on the curve at each), one test line, the series, and the result. *Next* waits until a step has what the fit needs.

The pictures and the controls share the window with a handle between them, so the settings are always in sight; the mouse wheel over a picture scrolls the window when it is too short for everything (Ctrl + wheel zooms the picture).

By hand:

1. **Bands** tab: **Add band** for each branch; select a band, press **Place a seed** and click the peak on the curve (right). Four or five seeds down a band are enough; **Line at** moves the line being looked at.
2. **Try this line** shows the fit of the current line (dashed: the guess).
3. **Fit settings** tab: peak shape (Lorentzian, Gaussian, Voigt), background, step, then **Fit the series**. Fitted positions are drawn on the image, sized by amplitude.
4. **Dispersion...** fits the band: **v_F** (straight line), **m*** (parabola) — and checks how far out the fit is stable. **Self-energy...** opens the window described below.




Save table... writes every fitted line; **Band to list** puts a band in the main list.

Where two straight branches cross. In the **Dispersion...** window, with *v_F* (a straight line) chosen, each other fitted band is fitted the same way and the point where the two lines meet is given with its uncertainty (propagated from both fits): the Dirac point of a cone fitted as its two sides, or any crossing of two bands. A single fitted line whose error collapsed (a peak fit that went to zero width) no longer takes the whole weight of the dispersion fit: no point counts for more than ten typical ones.

Self-energy


Self-energy... (Dispersion window, MDC fits only) turns one fitted band into **Re Σ** and **|Im Σ|** against energy: Re Σ is the distance of the measured band from a *bare band*, and |Im Σ| half the fitted width times the bare band's slope.



- **Bare band** — the one assumption everything rests on, so it is chosen here and written into the result: a **straight line through the band at two energies** (E_F and the deepest fitted energy to start with), a **straight line of a given velocity** through the measured k_F (from a calculation, say), or **the Dispersion window's fit**.
- **Suggest (Kramers-Kronig)** finds the bare velocity for which Re Σ and the Kramers-Kronig transform of |Im Σ| agree best. Both depend on that one number, so requiring them to be a pair fixes it without a calculation. Trust it only when the fitted range reaches well past the kink, to where |Im Σ| has levelled off.
- **E_F at** and **Momentum resolution to remove** (from the widths, in quadrature; leave 0 if the fit had the resolution in its line shape).
- **Dashed line**: Re Σ worked out from |Im Σ| by the Kramers-Kronig relation, taking |Im Σ| as the same above E_F as below and constant beyond the fitted range. No constant is fitted, so the comparison tests the bare band: one chosen to enlarge a kink fails it.
- **Under the plots**: the measured k_F and v_F, v_bare/v_F − 1, the coupling λ = −dRe Σ/dE at E_F, the energy where |Re Σ| is largest (the kink), |Im Σ| at E_F with the lifetime and the mean free path.
- **Self-energy to list** adds the curves to the main list; **Save table...** writes them as CSV with the bare band in the header.

5.5 Cut arithmetic: dichroism and reference division

Two cuts combined into a third: linear dichroism (LH − LV), circular dichroism, dividing by a gold reference, or plain differences, ratios and sums. Select two cuts in the list and press tool panel → Advanced → **Cut arithmetic (two cuts)...** (the first selected is A; the window can swap them). The button is greyed until exactly two cuts are selected.





- **The table at the top** compares what the two measurements recorded (polarisation, photon energy, angles, sample position, temperature, pass energy, lens mode). Rows in orange differ beyond a tolerance — a dichroism map between two spots on the sample is a map of *that* difference.
- **Purpose** presets: *Linear dichroism* (A − B, B scaled to the same total intensity), *Circular dichroism* ((A − B)/(A + B)), *Divide by a reference*, *Custom*. Warnings appear if the polarisations look swapped (**Swap A ↔ B**).
- **Scale B to A** by total intensity or by a region; **Hide where A+B below** blanks the background.
- A and B are drawn on one colour scale; the result on a red-white-blue scale symmetric about zero. With raw counts on both, the Poisson uncertainty is propagated and summarised under the plot.
- **Result to list**, **Uncertainty to list**, **All three as a figure**.

5.6 Slice series figure

Select a map → tool panel → Advanced → **Slice series figure...** lays out a page of flat 2-D slices through the cube as one figure for a paper — constant-energy contours at a series of energies, or cuts at a series of angles or momenta — evenly spaced or at chosen values, with integration, one shared colour scale, and labels on the outer edges only. (Not to be confused with **3D slices**, which draws three planes in a 3-D view.)

- Panels are titled with the value asked for (−0.2 eV), not the recorded plane's own (−0.2022 eV); the plane used and the window are kept in each panel's information.
- The colour map, its inversion, the levels (as percentiles) and the gamma are set in the dialog, for every panel at once.
- **Draw the Brillouin zone, as on the map** puts the zone drawn with BZ overlap on every constant-energy panel, each edge once.



- From a script or an agent, `contour.slice_figure(values=[0, -0.1, -0.2], half_width=0.02)` (or `A.open_slice_series(values=...)` on the selected row) makes the figure without the dialog.

Settings	Result
	


5.7 The 3-D views

Four tools of the Advanced tab show a map in 3-D, each in a window of its own — drag the picture to turn it:

- **3D slices...** — the three orthogonal planes through the cube, each placed where you choose (tick box, slider or typed position per axis).
- For a **k-map**, the 3-D views start at the first k_x and k_y planes that are filled with data: the converted cube is the box around a light cone that narrows away from E_F, and its outermost planes drew as blank faces. *Change sampling... → Whole range* shows everything again.
- **Notched cube...** — the cube with one corner cut away: a constant-energy map and two dispersions in one picture.
- **Volume projection...** — the whole volume projected along the view: maximum intensity, sum, alpha composite, or a shaded isosurface.
- **Stacked slices...** — parallel slices stacked in 3-D (below).

3D slices	Notched cube
	


- **Sampling.** Every frame resamples the cube, so each window opens at *Balanced* sampling, which keeps up with the mouse. The current sampling is written under **Save the view...**; **Change sampling...** picks the region and *Fast*, *Balanced* or *Fine*, and redraws from the full cube.



- **Colour.** *Apply to* sets the colours of **all slices** at once or of one orientation (the energy plane in one colormap, the dispersions in another): colormap (and *reversed*), levels (**Auto**, or **Each its own** for one scale per slice), gamma, **Opacity** and **Fade low values**, which makes the weak intensity see-through so the planes behind show.
- **Axes. Draw the axes, with ticks and values**. *Placement* is automatic — on the outer edges facing you, following the view as it turns — or chosen: for each axis, the edge of the cube it runs along and whether it counts **from min** or **from max**.
- **Camera**: azimuth, elevation, depth aspect; **Look into it** faces a chosen plane. **Outline the faces** and an **Orientation tripod** are optional.
- **Save the view...** exports the picture through the same export window as any panel (PNG, TIFF, JPEG at a chosen size and dpi). **To figure composer...** adds the view as a panel of a figure.

Stacked slices

Stacked slices... (tool panel → Advanced → 3D only) draws parallel slices of the cube stacked in 3-D: constant-energy maps one above another up the energy axis, or cuts one behind another along k_z (or the photon energy) — the usual picture of how a band evolves.




- **Layers** — the axis they are stacked along; **How many** spreads them evenly, or type the positions in **At** (comma-separated, in the axis's units); **Integrate** averages each layer over that width.
- **Frames** — an outline round every layer (grey, black or none).
- **Spread** stretches the box along the stacking axis, so that layers seen from an oblique view stand apart instead of covering one another: for a few cuts stacked along k_z, *Spread* 3 with the azimuth at about 40° shows each cut almost whole.
- **Fade low values** (*Colour*) starts at 35 % here: each layer's background is transparent, so the layers behind show through.
- **Mark a curve through the layers** — points in the data's own units (one per layer, say the crossing of two bands), joined by a red, black, blue… curve drawn over the stack, with an optional label at the first point.
- The axes of all 3-D views now fit the picture *and* its labels to the window or figure panel (no fixed margin), thin their ticks to the room each axis has, and write sub- and superscripts in the axis titles (`E - E_F`, `k_x`).

5.8 Fermi pocket (quasi-2D, under test)

Under test (new in 1.3.3): check every number against the picture, and please report what looks wrong.

Quasi-two-dimensional samples only. The area of a contour in a k-map is a property of the Fermi surface only when the bands do not disperse along k_z — a surface state, a single layer, a layered material whose Fermi surface is a cylinder. Then one map is the whole Fermi surface. For a three-dimensional Fermi surface the map is one curved sheet through it, at a k_z set by the photon energy and smeared by the escape depth: the contour is not an extremal orbit, and the numbers below mean nothing. The program cannot tell the two cases apart.

Select a map converted to momentum (a k-map, on E − E_F) and press tool panel → Advanced → **Fermi pocket (quasi-2D)...**.



1. **The plane.** The energy the contour is traced on (E_F to start with) and the half width it is averaged over.
2. **The pocket.** Drag the red target to a point inside the pocket (or type it), and set **Look between** so that the two dashed circles hold this pocket's band and no other. A ray goes out from the centre at each of **Rays** angles, and a peak fitted along it gives k_F there (yellow points; red crosses are rays dropped, and the **One ray** tab shows any ray with its fit). The contour (blue) is a Fourier series of the radius against the angle, up to **Harmonics**; **Symmetry** keeps only the harmonics an n-fold axis through the centre allows, which also bridges gaps in the data. **Centre on the contour** moves the centre to the contour's middle; the area does not depend on the centre.
3. **Counting.** *States per k* (2 for a spin-degenerate band, 1 when each spin has its own contour), the number of *equivalent pockets in the zone*, the *in-plane cell* a, b, γ (for carriers per cell), and whether this is an electron or a hole pocket.

What comes out, under the pictures:

- the **area** with its error, the range of k_F round the contour, and the number of rays kept;
- for a quasi-2D sample: the **carrier density** n = g N A/(2π)², the fraction of the Brillouin zone and the **carriers per cell** (what Luttinger's theorem counts), and the **quantum-oscillation frequency** F = (ħ/2πe) A;
- **Area against energy** traces the same pocket at a range of energies and fits a line: the **cyclotron mass** m_c = (ħ²/2π) dA/dE — positive for an electron pocket, which grows with energy, negative for a hole pocket — the area at E_F read off the line (free of the bias the Fermi cut-off gives a plane taken at E_F itself), the mean Fermi velocity, and the energy at which the line reaches zero area.

Keep this pocket adds it to a table that counts several pockets together, electrons minus holes. **Contour to list** adds k_F against angle (and the area against energy) to the main list as curves; **Save table...** writes everything as CSV.


The errors given are statistical (the scatter of the rays). The energy window, the momentum conversion (work function, where Γ is) and the resolution are not in them, and are usually larger.

Part 6 — The tool panel: Figure tab

The **Figure** tab holds the figure composer and what is worked out rather than measured: the crystal, its Brillouin zone in 3-D, tight-binding fits and calculated band structures. It ends with an example from loading data to a finished figure.

6.1 The figure composer

Tool panel → Figure → **Figure composer...** (the top of the tab) with **nothing selected** opens a blank page, like a figure of a manuscript: four empty panels (a), (b), (c), (d) at a journal's column width. With cuts (or curves) selected, each becomes a panel (so does a frozen slice's **Figure composer...** button; a stack plot or a 3-D view has its own **To figure composer** button).



- **Lay out the page.** Click a panel to select it; drag it to move it and drag its handles to resize it (Shift on a corner keeps its shape). Panels snap to each other's edges and to a 0.5 mm grid (**Snap**); the arrow keys nudge by 0.5 mm (Shift: 5 mm). *Arrange as grid* (figure tools, Panels tab) puts them back on rows × columns; a panel can take several cells (*Grid cells (rows / cols)* of the selected


panel — a schematic beside a row of data panels), and a picture keeps its own shape in them. The page height follows the panels when they are moved by hand. **Re-letter** names them (a), (b)… in reading order.

- **Fill a panel.** Double-click an empty panel, or use **Load from list...** / **Load picture...** on the left: a dataset from the main list, or a picture from a file (PNG, JPEG, TIFF… — a sketch or a figure made elsewhere; it keeps its shape and has no axes).
- **Insets. Zoom-in inset**: drag out a region of a panel — a small panel magnifying it appears in the corner and the region is outlined. **Panel** drawn inside another panel makes an inset to fill with another dataset. Insets take no letter and move with their panel.
- **Draw. Arrow**, **Line**, **Box**, **Ellipse**, **Text**: drag (or click, for text) on the page. A selected drawing can be moved, its ends or corners dragged, and its colour, width, line style, fill and text set above the figure tools. Double-click a text to edit it; Del removes the selection; right-click for more (bring to front, delete…).
- **Axes and fonts.** The figure tools beside the page act on the selected panel (or all of them): ranges, ticks, labels, which edges carry numbers, the panel's own font size, colour map, colour bar, reference lines. With *Tick labels on outer edges only*, *…but tick numbers on every panel* keeps the numbers on the inner panels and leaves only the axis names to the edges.
- **Undo / Redo** (Ctrl+Z / Ctrl+Y) cover every change. **PDF**, **PNG**, **SVG** export, **Copy** puts it on the clipboard; empty panels are never written. The composer's **Figure tools** are not a viewer's **Plot tools**, which draw guides on the live plot.

Arranging panels


Click a panel, then **Ctrl+click** (or Shift+click) the others to select several. The **Arrange** buttons on the left then:

Button	What it does
⇤ Left, Right ⇥, ⤒ Top, Bottom ⤓	line up their left / right / top / bottom edges (at the outermost one)
↔ Centres, ↕ Centres	put their centres on one vertical / horizontal line (the first-selected panel's)
Space ↔, Space ↕	equal gaps between them, left to right / top to bottom (three or more)
= Width, = Height	the first-selected panel's width / height for all



Letters and colour bars

- **Letters in line** (*Text* tab, on by default): the letters of panels side by side sit at one height and those of panels one above another at one left edge, whatever titles or axes each panel has. **Nudge (mm)** moves one panel's letter (clear of a long axis title, say); **Re-letter** names them (a), (b)... in reading order.
- **Colour bar** (*Colour* tab): **Ends** writes the levels, the words *High* / *Low*, or nothing; **Length (%)** of the panel's height or width; **Position** *right* (upright beside the panel) or *below* (lying under it, centred). A 3-D view's bar is sized to the cube as drawn, not to the whole frame round it.



Curves: lines, symbols and error bars

Overlays tab, **Curves drawn on the panel**: select curves in the list (or none, for all), then set their **colour**, **width**, **style** (solid, dashed, dotted…), **symbols** (circle, square, triangles, diamond, with a size) and whether they are **joined by a line**; **± σ as error bars** turns a curve's two dotted ±σ curves into error bars at its points. **Apply to the curves**. A curve with gaps (NaN) is drawn in pieces.

Saving a figure to edit later, with its data

Save / **Save as...** write the figure in the program's own format, `fig1.afig`: the page, its drawings and every panel with its data and settings — open it again with **Open...** (or pick it in **Load data...** in the main window) and go on editing exactly where you stopped. A 3-D view is kept as the picture it shows.


Beside it, **`data for fig1/`** gets one folder per panel (`a`, `b`, ...):

```
data for fig1/
  a/  processed/  what the panel shows: the image as a .nxs cut (opens in the
                  viewer again), its lines (calculated bands, contours,
                  curves) as lines.csv, a picture as .png
      original/   what it was made from: the first measurement file (a
                  k-converted, symmetrised, cut-out plane traces back to the
                  file it was first read from), the calculation with the
                  files it is read with (.win, POSCAR...), the picture file
                  or the CIF
      sources.txt which entry of the file, and the processing in between
  b/  ...
```

The original file is copied even when the panel shows something computed from it many steps later: every dataset remembers the file it began as. A figure opened again whose original files have moved reuses the copies in its own earlier data folder.

6.2 Crystal structure

Tool panel → Figure → **Crystal structure...** (needs nothing selected). Four steps (the Brillouin zone is the tool of its own **3D BZ...**, §6.2):



1. **The structure** — **Read a CIF file...** (the button at the top) fills the space group, cell and atoms from a file, applies its symmetry operations and redraws the crystal at once; everything stays editable. Or type it in, like the BZ overlap cell: the **space group first** (the cell parameters it fixes are greyed and follow the free ones), then the cell and the atoms of the basis (the centering copies are added). CIFs with several data blocks (FullProf's, which open on a block of journal fields) are read from the block that holds the structure.

2. **The look**

   - cells along a, b, c, the atoms' overall size, cell edges and bonds (in the atoms' colours, or *grey, thin*);
   - per element its **colour**, **size**, **transparency** and **gloss** (0 %: a matt ball, 100 %: a shiny one with a sharp highlight);
   - **Polyhedra around** an element: its coordination polyhedra (its bonded neighbours as corners) in a colour and transparency of their own — the $TiSe_6$ octahedra, the CuS_4 tetrahedra;
   - **Key of the elements** (a ball and its name for each), **Lattice constants on the cell edges** (`a = 3.52 Å`, `c = 8 Å`).


   Drag the picture to turn it, wheel to zoom; *View along* a, b, c or the plane normal.

3. **Cleavage plane** — tick *Draw a plane*, give (hkl), slide it, or double-click an **atomic layer** in the list to put it there; *Hide the atoms above* shows the termination; atoms in the plane are ringed red.

4. **Export** — the crystal: **Save picture...** (PNG at any size, drawn again at that size) or **To figure composer...**. A picture from a CIF names the CIF as its source, so the figure's data folder keeps it (§6.1).

6.3 3D BZ: the Brillouin zone in three dimensions

Tool panel → Figure → **3D BZ...** (needs nothing selected). It was step 4 of the crystal-structure window.



- **Crystal**: the **space group first**, then the cell — the parameters the space group fixes are greyed and follow the free ones, as in BZ overlap. **Read a CIF file...** fills them from a file. It starts from BZ overlap's last 3-D crystal.
- **Planes in the zone**: **Add a plane in 3D BZ** as often as you like. Each has its own normal (h k l), its height along it (in units of G(hkl): 0 through Γ, 0.5 at the zone top), colour and opacity, and ✕ to remove it.
- **Measured maps on the planes**: *any* plane can carry a k-map's constant-energy map — choose it in the plane's *map* list and give the energy (E − E_F). The list offers the k-maps selected when the window was opened and every k-map in the main list (**↻ Maps from the list** brings in ones added since); a map is read only when it is chosen. The map's kx, ky lie along the plane's own in-plane axes — k_a, k_b for a plane normal to k_c — turned by *Maps' azimuth*, averaged over *Integrate*, and cut to the zone.
- **Paths**: **Add path** as often as you like, each through the labelled points (`Γ-M-K-Γ`, `A-L-H-A`; `|` for a jump) in a colour and width of its own.
- **Display**: labels of the high-symmetry points, the axes, and *Label on the left* (those points labelled at their leftmost equivalent, clear of the paths and axes).
- **Axes**: the crystal's own, **k_a, k_b, k_c** (Cartesian axes of the cell: k_a along a, k_c normal to the a–b plane), by default; or **the sample's, as the data has them — k_x, k_y, k_z**: k_z along the normal of the *Cleavage plane (hkl)*, k_x along the maps' k_x (turned by *Maps' azimuth*). One symbol never names two directions. The *View along* buttons follow the frame shown.
- **Export**: **Save picture...** at any size, or **To figure composer...**. *Labels: panel width / text* sizes the labels for the width the picture will have in the figure (8 pt in a 30 mm panel), whatever its size in pixels; off, they scale with the picture as on screen.

6.4 Tight-binding fit

> **One band, or two hybridised bands — chosen in step 1 (*Bands*). One band** is a single band on a Bravais lattice (one orbital per site): E(k) = e0 + Σ t_n Σ cos(k·R). It cannot describe two bands, their crossing or a hybridisation gap; fit each band on its own and read its hoppings as that band's effective parameters, not as microscopic orbital-to-orbital hoppings.
>
> **Two bands, hybridised** fits two such bands, ε_a(k) and ε_b(k), and the coupling V(k) = v0 + Σ v_n S_n(k) between them at once; the measured bands are E± = (ε_a+ε_b)/2 ± √(((ε_a−ε_b)/2)² + V²). Use it for an anticrossing, a hybridisation gap, or a bilayer splitting (t_⊥). V has the lattice's full symmetry (two orbitals of the same parity); an odd coupling such as s–p is not this form.

Two bands, step by step. In step 1 set the shells of band a (*Shells of neighbours*), of band b (*Shells, band b*) and of the coupling beyond v0 (*Coupling shells*, 0 for a constant V). In step 2 trace both bands at two or more energies with *New points on* left at *either band*, then click a few points of each band with it set to *the lower band* or *the upper band* (blue / pink); a points file may carry a `branch` column (`lower` / `upper` / blank). In step 3 the fit — nonlinear, started from many models and refined — gives band a, band b and v0, v1… with errors, draws both bands (red, orange), says which band each point went to, and gives the **smallest gap** between the bands and where it is: 2|V| where the bare bands cross. *Model to list* holds both bands; *Save parameters* writes the three sets of parameters, their shells and the gap.

Shells are symmetry orbits. Each hopping t_n belongs to one set of neighbours that symmetry makes equivalent: the space group's point group (with inversion) for a 3-D crystal, the lattice's own symmetry for a 2-D layer. Two inequivalent neighbours at the same distance — an in-plane and an out-of-plane one, say — get a hopping each. Step 1 lists every shell with its count, distance and a representative vector in lattice coordinates (⟨1 0 0⟩), and **Save parameters...** writes all the vectors of each shell.

With a k-map selected (or nothing, to use a file of points):

1. **The lattice** -- a 2-D layer (a, b, γ) or a 3-D crystal (the **space group first**, then the cell parameters it leaves free -- the others are greyed and follow), or **Take the crystal from the Brillouin-zone tool**; the azimuth of a against kx; how many shells of neighbours.
2. **Band points** -- on **one band** only (a few stray points are set aside as outliers; many spoil the fit). Move to an energy and press **Trace this energy** (ridge detection), or tick *Click* and click on the band, or **Read points from a file**. Two or three energies are better than one: one contour fixes the band's shape but not its energy scale.
3. **Fit** -- the hoppings with their errors and the rms misfit; the model's contour is drawn in red on the plane of step 2. With one energy, hold t1; *Refine the azimuth* if the orientation is known only roughly. An orange note means the points cannot tell the shells apart: use fewer.
4. **Use the model** -- **Model to list** (its spectral function, as a map beside the data), **Save parameters...**, **Copy results**.

6.5 Calculated bands

Tool panel → Figure → **Calculated bands...** puts a band-structure calculation beside the measurement. Select what to compare it with — k-maps, kz maps in momentum and cuts in momentum — or nothing, to look at the calculation alone. Four steps.

Like every step-by-step window (Crystal structure, Tight-binding fit, Sum repeated scans, Detector corrections), it **asks before closing** — the last step's Close sits where Next was, so a quick double click no longer loses the work; the title bar's close and Esc ask too. **Enter in a field takes its value** (and redraws what depends on it) — in every window of the program it never presses Next, Close or any other button, whatever the value set going (even a computation with a progress bar); only a button that has the focus answers Enter. Where a window redraws only on a button — the Brillouin-zone tool's **Plot**, a viewer's selection-box **Refresh**, the core-level zoom's **Show** — Enter in its fields does that redraw, and nothing else. What you set is **kept**: the window opens as you left it (**Restore defaults** at the bottom left starts afresh).

1. The calculation. First say **what you want to see**:

- **E–k dispersion** — the bands along a path, or along your measured cut. Any calculation works.
- **Constant-energy contours** — to compare with a k-map (Fermi-surface map).
- **3D Fermi surface.**

The last two need the bands **everywhere in the zone** (a band grid or a Hamiltonian); a band structure along a path cannot give them, and the window says so rather than going on. The choice also sorts the file list of **Open calculation...**: its first filter shows only the kinds of file that can give what you want. Selected k-maps choose contours for you, selected cuts the dispersion. A file can also be dropped on the window; **Reopen …** opens last time's file again.

File	Written by	What it holds	Can show
`.bxsf` (XCrySDen band grid)	Wien2k, Quantum ESPRESSO, VASP, Wannier90	the bands everywhere in the zone, interpolated	all three
`_hr.dat` (+ `.win` beside it)	Wannier90, any tight-binding model	a Hamiltonian, diagonalised exactly at each k; orbital weights	all three
`wannier90_hr_fplo.dat` (+ `KPOINTS`, `wannier_name_center.txt`)	FPLO's Wannier Hamiltonian	as `_hr.dat`; weights per Wannier function, per shell ("Cr 3d") and per spin	all three
`band.dat` with rows `k1 k2 k3 E1 E2 …` (+ `KPOINTS`)	FPLO + Wannier tools	a 3-D band grid	all three
MATLAB `.mat` holding `Ek_3D` (+ `KPOINTS`)	the theory side's MATLAB, from that 3-D `band.dat`	a 3-D band grid	all three
`EIGENVAL` (+ `POSCAR`, `PROCAR`)	VASP	bands along a path or on a grid; atomic and orbital weights	a grid: all three
`_band.dat` (+ `labelinfo`)	Wannier90	bands along a path	dispersion
`.spaghetti_ene` (+ `.klist_band`)	Wien2k	bands along a path	dispersion
`band.dat`, `Eigenvalue.dat` (+ `KPOINTS`, `orbital.dat`)	FPLO + Wannier tools (`k_path.exe`, `H.exe`, `plot.exe`)	bands along a path (a third column is a weight)	dispersion

Files are recognised by their **content**, not their name: a standard file renamed on the way (`hamiltonian.txt` that is really an `_hr.dat`) opens all the same. The FPLO tools' `KPOINTS` (first line "segments points-per-segment", then the direct and reciprocal vectors, then each segment's ends with `! label`) gives the cell and the labels — keep it beside the band file; without one, the cell is taken from the

Brillouin-zone tool's crystal. Long reads (a 3-D `band.dat` of 101³ points and 136 bands is about 2 GB; a large `_hr.dat`) show a **progress bar** with Cancel; a big grid keeps only the bands near E_F (*Reading options* ▸ *Big grids*).

Which file? ... helps when you do not know which of a dozen files is the calculation: choose the folder the theory side sent, and every file in it is read and said in plain words — what it is, what it can show, what reading it lacks (the cell, the labels), whether it is a standard file under another name, or one file **cut into pieces** (`band.dat.1, band.dat.2`, `band_part1.dat …`, `xaa, xab` — as files are split to pass an upload limit). Green rows open for what you want to see; **Join the pieces, then open** writes the pieces back into one file beside them.

Reading options ▸ (usually nothing to change): *Set E_F myself* overrides the file's Fermi level; *bxsf k units* is for a grid written without 2π; *Big grids: keep bands from … to …* of E_F.

The crystal. The cell (a, b, c, α, β, γ) is read from the calculation and the **space group** that names the zone's points is guessed from its shape. Once read, both are **locked** — as are *From the Brillouin-zone tool* — so a stray click cannot change the calculation's lattice. Tick **Change the lattice parameters** to change them on purpose: typing a new cell (or taking the Brillouin-zone tool's) scales the calculation to it — its bands, held in fractional coordinates, stretch with the zone.


A calculation in another format. When the theory side's files are none of these, the safest route is to ask for (or convert to) one of the standard ones: a `.bxsf` for bands everywhere, `_hr.dat` + `.win` for a Hamiltonian, or a two-column `_band.dat` (distance, energy; a blank line between bands) with its `_band.labelinfo.dat` for a path. What to ask them: which columns, which order of k, the units of k (with or without 2π, fractional or Cartesian) and whether energies are already relative to E_F.

2. What it looks like — by what you chose in step 1:


- **Along a path** (dispersion). The calculation through the high-symmetry points (`Γ-M-K-Γ-A-L-H-A`; `G` for Γ, `|` for a jump), over the **measurement along the same path**, assembled from the selected maps: each in-plane segment from the map measured on its k_z plane (Γ-M-K-Γ from the Γ-plane map, A-L-H-A from the zone-top one), Γ-A from a kz map. Each map's k_z comes from its photon energy and the inner potential V0; correct it in the table if needed, untick a map to leave it out, and give the azimuth of the crystal's a axis on the map. **Highlight bands** draws chosen bands thick and in colour, the others grey — their numbers as the file counts them (`41-44`), or `EF` for every band crossing E_F (step 1 lists them).
- **Constant-energy contours.** The calculated contours at one energy on any plane of k-space, set as in the Brillouin-zone tool: its **normal (hkl)** (conventional reciprocal axes; (001) gives k_x-k_y), and **k⊥**, how far it sits from Γ along that normal — **Through point** puts it through a high-symmetry point (Γ K M at 0, A H L at π/c for (001)); **In-plane rotation** turns the two drawn axes about the normal (to match a measured map's azimuth, say). The **k⊥ integration window** sums the bands over a range of k⊥ about the plane — along the (hkl) normal, not the absolute k_z — as a map with a finite k⊥ resolution does; the integrated intensity is drawn grey under the contours of the middle plane. **Show the plane in the Brillouin zone...** opens a turnable 3-D view of the zone with the plane in it (red), the faces of its k⊥ window (light red) and the named points it holds; it follows the plane as you change it. The zones' outlines on the plane are dashed grey.
- **3D Fermi surface.** The surfaces where the bands cross the energy, inside the first zone, with the zone's edges and named points. Drag to turn, wheel to zoom; Enter in *Energy* redraws it; *Detail* trades speed for smoothness (a Hamiltonian is diagonalised on a grid first, with a progress bar). **Open in its own window** shows it large, with *Save picture*; the energy, detail and bands are still set here. With this goal there is nothing to compare, so the Compare step is left out.

Each band's **colour** (from the list, or *Other colour...*), and for a surface its **opacity**, and whether it is **shown**, are set in the band table. Several bands may share one colour — to group the electron pockets in one colour and the hole pockets in another, say — and a band keeps its colour from the contours to the 3-D view.

Colour by orbital weight draws fat bands along a path, or splits the contours where the chosen orbital's weight exceeds one half.




3. Compare. One measurement at a time, with the calculation drawn where it was really taken: a **cut** gets the bands along its direction — on a fixed k_z plane, or on the curved surface its photon energy reaches (k_z changes along the cut and with the energy); a **map** gets the calculated contours at the energy chosen. **Fit to the cut's bands** traces the measured bands (ridge detection) and finds **Z** — the band-width renormalisation, measured E = Z × calculated E + shift — and the **shift**, each point matched to its nearest band, robustly. Z and the shift apply in every step and every output. On the demo cut it finds Z = 0.798 and a shift of −49.8 meV, the values the demo was made with (0.8 and −50 meV).



4. Output. With no measurement selected, step 3 says so: press Next.


- **To figure composer...** makes the panels ticked — ticked for you by what you chose in step 1: the measurement along the path with the calculation over it, the calculation alone (the points' names on its axis), the compared cut or map with its calculation, the calculated contours alone at the energies listed (no map needed), the 3D Fermi surface as drawn in step 2, and — with **Constant-energy series of the compared map** — the measured maps at each energy with the zones dashed (top row) and the calculated contours (bottom row).
- **Save … to main panel** (beside it) puts the calculation in the list as data the main panel's viewers open, and what it saves follows step 1:
  - *dispersion* — a cut: the bands as a spectrum (Lorentzians of the width set) along the compared cut or along the path. A cut along a path keeps its high-symmetry points: the cut viewer shows their names along the top, with a dashed line at each (**High-symmetry points**, ticked; the k values stay on the bottom axis), and the figure composer puts them on the k axis.
  - *contours* — **Save calculated map to main panel**: a k-map of the calculated intensity on the plane of step 2 (its (hkl), k⊥, in-plane rotation and k⊥ window) at every energy of *Energies of the saved map*, to slice and compare like a measured map.
  - *3D Fermi surface* — greyed out: the viewers open cuts and maps, not a surface; the figure composer (or *Save picture*) takes it.



6.6 Worked example: from loading data to a figure

From the demo data (§1.3) to a figure of constant-energy maps with the Brillouin zone. This is the same path as the agent's example in §7.7, done by hand.

1. **Load. Quick add...** → `demo_bulk_bands.nxs`. The list shows the Γ-plane map `FS_map_hv59.3_Gamma_plane`, the cuts `cut_GM_LH`, `cut_GM_LV`, `cut_GK_LH` and the photon-energy scan.
2. **Fermi level.** Select the map → Basic → **Fermi edge fit...**. Fit on the raw data, in a window around the edge; note E_F (§4.2).
3. **To momentum.** Basic → **k conversion (map)**: Γ at normal emission, the fitted E_F as the energy reference. A new row `… [k]` appears (§4.8).
4. **The zone.** Select the k-map → Basic → **BZ overlap...**: space group 164 (P-3m1), a = 3.3 Å, c = 6 Å, plane (001) through Γ (§4.11).
5. **Slices.** Advanced → **Slice series figure...**: energies 0, −0.2, −0.4 eV, ±20 meV, three columns, the zone dashed (§5.6). The figure opens in the composer.
6. **Lay out and export.** In the composer set the page width, colour map and levels, letters (a), (b), (c), then **Export** a PNG and a PDF and **Save** an `.afig` to edit later (§6.1).




The next section builds two complete publication figures in the same way.

6.7 Worked example: two figures in the figure composer

The two figures below were made from the demo data (§1.3) with the program's windows and put together in the figure composer. `devtools/figure_tests.py` runs exactly these steps, so it is also a script to read alongside this section.

Figure 1: constant-energy contours




(a) The notched cube. Convert the Γ-plane map to momentum (§4.8); select the k-map → Advanced → **Notched cube...**. *Change sampling...* to k_x, k_y within ±1.25 Å⁻¹ and E up to E_F; put the notch at k_x = k_y = 0 down to the lowest energy, corner **+ − +**; colormap *blue*, reversed; azimuth −52°, elevation 24°. **To figure composer...**: a new figure. In the composer, *Colour* tab: **Colour bar** on, Ends *high-low*, Position *below*, Length 60 %.

(b) Measured and calculated contours. Select the Γ-plane k-map → Figure → **Calculated bands...**; open `demo_calc_hr.dat`; in step 2 choose the **Weight** `Se-pxy`; in step 3 choose the k-map, *Integrate* 0.050 eV, then a cut to **Fit to the cut's bands** (Z and the shift apply to the contours too); in step 4 tick **Constant-energy series at** `0, -0.3, -0.6, -0.9`, untick the others, **To figure composer...** → the figure of (a). Eight panels arrive: the measured maps with the zones dashed, and the calculated contours alone, red where the weight is below one half and green above. In each, set the colormap (*blue*, reversed), the ranges ±1.2 and drop the titles of the bottom row (*Text* tab); add the (i)…(viii) and Γ, M, K notes with the **Text** tool.


(c) Stacked contours. Select the k-map → Advanced → **Stacked slices...**; *Layers* along E − E_F at `0, -0.15, -0.3, -0.45, -0.6, -0.75, -0.9`, *Integrate* 0.04, *Fade low values* 45 %, z aspect 2.2, azimuth −45°, elevation 14°. **To figure composer...** → the same figure.

Arranging. Drag the panels roughly into place (the 2 × 4 contours in two rows, (a) left, (c) right), then select (a), the top row of (b) and (c) and press ↟ **Top**; select a row of contours and **Space ↔**, and **= Height** for each row. The letters line up by themselves; **Nudge** moved (b)'s 6 mm left, clear of its k_y title.



Only (a), (b) and (c) carry a letter: clear the others' *Letter* box. **Save as...** `example_figure_1.afig` (its data folder is written beside it), and **PNG** / **PDF** for the paper.

Figure 2: a band crossing followed through k_z



(a) The crystal structure. Figure → **Crystal structure...** → *Read a CIF file* `demo_tetragonal_crystal.cif`. Step 2: Hf teal, Si dark blue, S yellow, gloss 85 % each, atom size 0.52; *Grey, thin bonds*; *Lattice constants on the cell edges* (no key of the elements). Step 3: *Draw a plane* (001) at the middle of the cell, between the S layers, in grey. Turn it to azimuth −68°, elevation 14°. Step 5: **To figure composer...** → a new figure.

(b) The zone with the measured maps. Figure → **3D BZ...** → *Read a CIF file* `demo_crystal.cif`. **Add a plane in 3D BZ** once (the first plane is through Γ, the second at the zone top); the first plane's *map* → *Γ-plane map* at −0.65 eV, the second's → *A-plane map* at −0.55 eV (select the two k-maps first, or press ↻ **Maps from the list**). *Path* `K-H` (the line where the two bands cross); *Label on the left* `L, M`. **To figure composer...** → the figure of (a).

(c) The cuts stacked along k_z. Convert the photon-energy scan to momentum (§4.9), select it → Advanced → **Stacked slices...**: *Layers* along k_z at the four k_z of the cuts (8.0, 8.3, 8.6 and 9.0 π/c), *Fade* 30 %, **Spread** 3, azimuth 40°, elevation 12°. In **Mark a curve through the layers**, add the crossing on each cut (k_z, k_∥, E) — from (d) — in red. **To figure composer...**.

(d) The cuts, their MDCs and the crossing against k_z.

- (i)–(iv): in the k_z map's viewer, **Functions → Slice → Save slice to the main list** at each k_z; open each cut in the figure composer (**Add panel...**). The dashed guides along the two crossing bands are the calculation (Calculated bands, step 3, on the plane k_z = ...), shifted by the fitted Z and shift: in step 4, **To figure composer...** with only *The compared cut* ticked gives the cut with them; set their style to *dashed* in the *Overlays* tab. Draw the dashed box with the **Box** tool.
- (v): select the first cut → Advanced → **Stack plot (EDC / MDC)...** → MDCs, 40 curves of 3 rows each, over the box's energies; **Send to figure composer** → this figure. The guides through the MDCs are the same calculated bands, at each MDC's energy.

- (vi): the crossing energy at each k_z — from **MDC fit** on each cut and **Dispersion...**, where *Crosses band ... at k = ..., E = ... ± ...* gives it with its error — as points with error bars (*Overlays*: symbols *circle*, not joined, **± σ as error bars**), and the calculated crossing through k_z as the red line.

Arranging. (a), (b), (c) in the first row: select the three, **⤒ Top** and **= Height**; the six panels of (d) in the second row, **⤒ Top** and **= Height**. Letters: (a), (b), (c), (d) only. **Save as...** `example_figure_2.afig`.

Each panel of either figure can be changed afterwards — open the `.afig`, select the panel, and use the figure tools; the data folder keeps both the data as shown and the measurement it came from.

Part 7 — AI agents

An AI agent (Claude, or any app that can read and write files or call MCP tools) can drive the program on your screen, step by step, while you watch and can take over. This part explains how that works, how to start and watch an agent, and gives an example from set-up to figure.

7.1 How it works, and what leaves your computer


The program has no chat of its own. You talk to your AI app (the Claude desktop app, Claude Code, or another agent) in plain words, and the program is that agent's tool. The agent sends the program small steps: list the data, fit a Fermi edge, convert to momentum, make a figure. The program runs each step on your screen, so you see every result as a new row in the list or a new window, and you can pause the agent and work by hand at any time.

What stays on your computer, and what does not:

- Your raw data files stay where they are and are read and processed by the program, locally. The program does not upload anything.
- What the **agent reads** is sent to the AI provider as part of the conversation: the text a step prints (row names, fitted values, axis ranges), and any picture the agent opens to judge a result. Ask for compact outputs, and the conversation holds numbers and a few pictures, not your data arrays.
- Whether the provider may use conversation content for training depends on the provider and your account settings. Check them before you start.
- Keep private code, unpublished manuscripts and anything you do not want read out of the folders the agent can reach. Give it the data folder (read only) and the results folder only.


As with any analysis, check what an agent produced before you use it.

7.2 Architecture: operations, reference, routes




- **The operations `L`.** About fifty documented operations on the named rows of the main list (`arpes_viewer/ui/common/live.py`): `L.rows()`, `L.add_files(...)`, `L.fermi_edge_search(...)`, `L.fermi_edge(...)`, `L.map_to_k(...)`, `L.kz_to_k(...)`, `L.bz_overlay(...)`, `L.cut_arithmetic(...)`, `L.slice_series(...)`, `L.figure_render(...)` ... Each one adds new rows rather than changing old ones, never overwrites a file, and never waits for a click. A row can be named by its name, its number in `L.rows()` or the path of its file.
- **The reference `API.md`** (`arpes_viewer/agent/API.md`, inside the installed program) lists every operation, the tool-panel buttons, the MCP tools and the computations in `tools/`, with their parameters. It is generated from the program, so it is always current; the agent reads it instead of the source. `L.help()` prints the same list.
- **Three routes** to the same operations:
    1. **Command folder** (recommended): the agent writes one small Python file per step into `<results>/_agent/viewer_cmd/`; the program runs it and writes what it printed to `<results>/_agent/out/`. Any AI app that can read and write files works, and every step is kept as a file.
    2. **MCP**: the AI app calls the program through its MCP server (`arpes-viewer-mcp`); with the program started with the agent bridge, `viewer_api` calls the same operations.
    3. **Scripts without a screen**: the computations in `arpes_viewer/tools/` and the headless workspace, for a script to keep.
- **Windows.** A window an operation opens only to drive it (a conversion dialog, a temporary figure) never appears on screen; the windows still open when a step ends (a figure, a viewer, a tool waiting for you) appear on the screen of the main panel, not on the screen you are working on.

7.3 Starting from the AI assistant panel



Press **AI assistant...** at the top of the tool panel.



1. **Folders.** The **data** folder (the agent only reads it) and a **results** folder (everything the agent writes goes there; its commands go in `<results>/_agent`).

2. **What you want.** Tick what applies:

   - *Ask me before choosing a physical parameter*: Γ, an energy window, the inner potential, a threshold;
   - *Show me each step and wait for my go-ahead*;
   - *Record token / plan usage per step*: a usage log, one line per step;
   - *Hide the sample's real identity* in everything written;
   - *Write a report*, *Make slides*;
   - *Save every step as one Python script at the end* (on by default): the agent writes `agent_steps.py` in the results folder;
   - *Keep the list tidy*: offer to remove intermediate rows at the end.


   Then write your request in your own words: which data, which steps, which figures.

3. **Your AI app.** *Works in folders* (recommended; nothing to set up) or *Uses MCP tools* (the prompt says how to connect the app once).

4. Press **Copy the prompt and start**. The program starts listening and the prompt is on the clipboard. **Show the prompt** shows it: the folders, where `API.md` is, how to send steps, and the working rules (§7.6).

5. Paste the prompt into your AI app and send it. Allow the app to read the data folder and to read and write the results folder when it asks.

7.4 Watching and stepping in



- **The list of steps** (right): each step the agent ran, with its time and ✓, or ✗ in red if it failed. Click a step to see what it printed.
- **The status light** on the **AI assistant** button, also with the window closed: grey not running, green running, yellow paused, red a failed step or commands no longer being run. Closing the window does not stop the agent.
- **Pause the agent** holds its next commands (the light turns yellow), so you can work by hand; **Resume** lets them through. The agent is told to wait and ask you when its commands are held.
- **Your work goes on.** The agent's steps leave your selection in the list as it was, so you can look at data while it works, and windows it opens only to drive them never appear on your screens.
- **Save the steps as a script...** writes everything the agent ran, in order, as one Python file: each step's code, when it ran, whether it failed (those are kept as comments) and what it printed. It is the record of the whole processing, and it runs again: copy it into `<results>/_agent/viewer_cmd` of a program started on that results folder. Steps sent through MCP are kept in memory only, so save them before closing the program. Steps you did by hand are not in it; they are in each dataset's history (*Experiment info*).
- **Open results** opens the results folder: the agent's command files and logs in `_agent`, the pictures and figures it wrote.

7.5 Other ways to start

- **Claude Code or another MCP app.** In the AI assistant choose *Uses MCP tools*: the program turns its agent bridge on and the prompt holds the command to add the server, for Claude Code `claude mcp add arpes-viewer -- python -m arpes_viewer.agent`. If your app loads tool definitions on demand, have it load all the arpes-viewer tools at once.

- **By hand.** Start the program with the bridge on (`arpes-viewer --agent-bridge`), add `arpes-viewer-mcp` to the app's MCP servers, and point the agent to `API.md`.
- **The command folder without the panel.** `agentic/launch_viewer.py` starts the program listening on a folder of your choice; `agentic/README.md` is the step-by-step guide, with requests to copy in `agentic/PROMPTS.md` and runnable examples in `agentic/examples/`.
- **A script to keep.** The computations in `arpes_viewer/tools/` need no window; `devtools/figure_tests.py` builds two complete figures from the demo data that way.

The details of the MCP server, for reference:

ARPES viewer is also an **MCP server** (Model Context Protocol), so an AI agent of any model — Claude, GPT, Gemini, or a local model in an MCP-capable client (Claude Desktop / Claude Code, Cursor, VS Code, Cline, LM Studio…) — can call it as a set of tools. Everything stays on your machine: files are read and written locally; only what a tool returns (numbers, text, pictures) goes to the client.

Set it up. Installing the program installs the command `arpes-viewer-mcp` (from a checkout: `python -m arpes_viewer.agent`). Add it to the client's MCP servers, e.g. in a `claude_desktop_config.json`, `.mcp.json`, or the client's settings:

```
{
  "mcpServers": {
    "arpes-viewer": {"command": "arpes-viewer-mcp"}
  }
}
```

(With a checkout instead of `pip install`: `"command": "python", "args": ["-m", "arpes_viewer.agent"], "cwd": "<the ARPES-viewer folder>"`.) The server speaks MCP over stdin/stdout and needs nothing beyond the program's own requirements.

Headless tools — no window needed; they use the program's own readers and algorithms:

Tool	What it does
`find_files`, `list_loaders`	the data files in a folder that a reader recognises, and the readers
`open_dataset`, `list_datasets`, `describe`, `metadata`, `close_dataset`	open a dataset (gives an id, e.g. `d1`), its axes and metadata
`get_profile`	an EDC or MDC: values along one axis, averaged over ranges of the others (optionally saved as CSV)
`get_image`	a picture (PNG) of a cut, a constant-energy map or a dispersion, with colour map and levels (optionally saved as PNG / CSV)
`fit_fermi_edge`	E_F and the resolution, with errors
`shift_energy`, `crop`	a copy on E − E_F, a copy cut to ranges
`convert_cut_to_k`, `convert_map_to_k`	the k conversions, with the same choices as their windows (Γ, rotation; *energy offset* only for an axis that is not kinetic; *output_fermi_level_eV* for an E − E_F result)
`save_datasets`	`.nxs` (opens in the program), `.itx` / `.ibw` (Igor Pro)
`brillouin_zone`, `read_cif`	the zone's high-symmetry points for a space group and cell; a CIF's cell and sites

Axes are named by number, by slot (`x`, `y`, `k`, `z`) or by a word of their label (`energy`, `slit`, `deflector`, `kx`); ranges are `[lo, hi]` in the axis's own units, or one number for the nearest plane.

The program on screen — start it with the bridge on:

```
arpes-viewer --agent-bridge
```

(or `python -m arpes_viewer --agent-bridge`; or set `ARPES_VIEWER_AGENT_BRIDGE=1`). The status bar says *Agent bridge on 127.0.0.1:…*. The `viewer_*` tools then drive that window: `viewer_status`, `viewer_rows`, `viewer_add_files`, `viewer_select`, `viewer_run_tool` (any tool-panel button for the selection — `fermi`, `kcut`, `kmap`, `bz3d`, `figure`, `notch3d`, `combine`…), `viewer_windows`, `viewer_screenshot` (a picture of any of its windows, so the agent can check what it did), `viewer_api_help` and `viewer_api` (the documented operations above: list them, call one), `viewer_figure` and `viewer_render_figure` (a figure window in numbers — page, frames, titles, levels, text sizes — and written as the PNG it will print as), `viewer_close_window` and `viewer_python` (Python run inside the program, with `A` = the program's main module — for setting a dialog's fields and pressing its buttons). A headless result reaches the list with `save_datasets` to a `.nxs` and `viewer_add_files`.

Safety. The bridge is off unless asked for; it listens on 127.0.0.1 only (not on the network) and answers only requests carrying the random token it writes, at start, to `~/.arpes_viewer/agent_bridge.json` (readable by you alone); the file is removed when the program closes. `viewer_python` runs code in the program — let an agent use it as you would let it type in a Python console on your computer.

The command-folder route is described in more detail in docs/AGENTIC_WORKFLOW_en.md; the MCP server is the same idea without the folder.

7.6 The working rules the agent follows

The prompt gives the agent rules learnt from real sessions; `API.md` repeats them. You can add your own, or override one, in your request.

Rule	Why
After adding the data, compare the rows with the folder and report what was left out, not recognised or warned about	single spectra in a map's folder, and files no reader takes, must not pass unnoticed
Say which part of a row name comes from the file name and which from recorded metadata; mark guesses	names are what everyone reads afterwards
Name a processed row after its source plus one tag in square brackets per step, from the table of `L.naming()` (`Map80eV [norm] [E-E_F] [k]`), also for names of its own	the list sorts by what was done (§1.5)
Look for an operation (`L.help()`, `L.tools()`, `L.functions()`) before computing anything; never edit the program's internal tables; if an operation is missing, say which and ask	results stay reproducible, with their history
Fermi level: fit raw data, per row, on that row's own axis (`L.fermi_edge_search`), draw each fit; rows of the same photon and pass energy must agree; when the data cannot decide, ask once	the steepest drop is not always the edge; one window does not fit every axis
Chain steps in one call (`L.map_to_k(row, ef=…, normalise_axes=(1, 2))`) so only final rows are listed; remove rows only when you agree	a list you can still read

Rule	Why
Try figures in `check/`, publish one version per figure in `figures/FigureN/`, move superseded versions aside	one final file per figure
Signed quantities (dichroism, differences) get a diverging colour map with symmetric levels	a sign must be readable
Small outputs: `L.rows(compact=True)`, `L.profile(..., summary=True)`, arrays to files	fewer tokens, less sent to the provider
Never delete or overwrite; ask before each physical parameter (if ticked)	your data and your decisions stay yours

7.7 Worked example: an agent from set-up to figure

This example follows a real day of processing CASSIOPEE data with an agent (Fermi-surface maps and cuts in several polarisations, up to dichroism figures), redone here on the demo data so you can repeat it. The program changes that day's session asked for are in the CHANGELOG (1.3.2).

1. Set-up. AI assistant: data `demo_data`, results `results_demo`; *ask before a physical parameter*, *step by step*, *report* and *tidy list* ticked; the request: *"Process the Γ-plane map and the LH and LV cuts along Γ-M: fit E_F per row, convert to k (Γ at normal emission), draw the zone (P-3m1, a = 3.3, c = 6 Å), make constant-energy slices at E_F, −0.2 and −0.4 eV, and the linear dichroism of the two cuts."* → **Copy the prompt and start**, paste into the AI app.


2. Looking first. The agent's first command file:

```
print(L.add_files(DATA))           # added, left_out, unrecognised, warnings
print(L.rows(compact=True))        # one line per row
```

It reports what is in the folder and proposes a plan; with *step by step* it waits for your go-ahead.

3. The Fermi level, per row. For each row, on its own energy axis:

```
found = L.fermi_edge_search(row, temperature=20)   # the candidate edges
fit = L.fermi_edge(row, found["candidates"][0]["window"], temperature=20,
                   picture=os.path.join(HERE, "ef_" + row + ".png"))
```



`fermi_edge_search` lists every drop of the EDC that stands above the noise, highest energy first, fits each and says which is the Fermi edge. When two fit (a weak tail above a strong drop, as on the real pass-energy-20 data), it says so and the agent asks you once. Each fit is drawn: grey the window, red the fitted edge.


4. To momentum, one row each.

```
k = L.map_to_k(MAP, ef=EF[MAP], normalise_axes=(1, 2), new_name="map Gamma plane k")
L.cut_to_k("cut_GM_LH", ef=EF["cut_GM_LH"], new_name="cut GM LH k")
```

The shift to E − E_F, the normalisation of every cut of the map and the conversion are one call: only the final row is listed, and its history records the three steps.

5. The zone and the figure.

```
L.bz_overlay("map Gamma plane k", space_group=164, a=3.3, c=6.0, hkl=(0, 0, 1), offset=0.0)
L.slice_series("map Gamma plane k", values=[0, -0.2, -0.4], half_width=0.02, cols=3,
               colormap="blue", flip=True, shared=False, percentiles=(3, 99.7),
               high_factor=1.4, zone_style="dashed", zone_color="#B8D62020",
               title="Figure 1")
L.figure_render("Figure 1", os.path.join(HERE, "..", "figures", "Figure1.png"), dpi=150)
```



6. Dichroism.

```
L.cut_arithmetic("cut GM LH k", "cut GM LV k", operation="asymmetry", normalise="total")
```

The program's own cut arithmetic, the same as the Cut arithmetic window (§5.5): LV scaled to LH's total, (LH − LV)/(LH + LV), points of low intensity masked.

7. Watching. Meanwhile the AI assistant lists each step (§7.4); you can click one to read its output, pause to look at a row yourself, and resume. At the end the agent writes the report and, if you agree, removes intermediate rows; the results folder holds the figures, the fit pictures and every command file, which together record exactly what was done.

7.8 Limitations and good practice

- **Check the physics.** An agent can choose a plausible but wrong Fermi edge, Γ position or inner potential. Tick *Ask me before choosing a physical parameter*, and look at each fit picture.
- **Keep the record.** The command files in `<results>/_agent/` and the rows' histories show what was done; keep them with the results.
- **Usage.** The agent cannot see its own token use; if you want a usage log with numbers, give them to it.
- **Privacy.** Only what the agent reads leaves your computer (§7.1); keep anything private out of the folders it can reach.
- **Encoding.** Command files are UTF-8; the program warns when a step's code holds characters garbled by a wrong encoding ("âˆ’" for "−").

Part 8 — Housekeeping

Autosave and recovery, saving your work, error logs, versions, and what to do when something goes wrong.

8.1 Autosave, memory and recovery

- **Autosave.** Every computed dataset (a k-map, a processed cut, a fit result…) is written, uncompressed, to this session's folder in `~/.arpes_viewer/sessions/` the moment it exists. Real-space scans are not (they are the measurement itself, and large).

- **A normal close deletes the autosaved copies.** When you close the main window and confirm (everything you want is saved, or *Close anyway*), the open viewers are closed and the session folder is deleted straight away. A dataset's copy also goes as soon as you save it to a file of your own.
- **Recovery after a crash.** Only if the program did not close normally (a crash, a kill) is the session folder kept: the next start offers its datasets back, and it is deleted after three days.
- **Operations log.** `~/.arpes_viewer/sessions/operations.log`, one line per store / save / discard — how to find what was where.
- **Memory box** (bottom of the tool panel). This program's memory, the system's, how many viewers and HDF5 files are open, and how much computed data is held. **Free RAM** drops cached copies of computed data (they are re-read from their autosaved file when needed); **Close all** closes every window and then frees memory.
- **Autosaves** (in the Memory box) shows the session folders in the system's file browser, to delete old working copies by hand. The folder of the session now running (named in the status bar) is in use.
- **Long operations** (reading a big map, converting, de-gridding, assembling a folder) run off the GUI thread with a progress bar and a working Cancel.
- **Closing** with unsaved computed data asks first, and names the datasets: **Save to a file...**, **Close anyway** (the autosaved copies are deleted) or **Cancel** (nothing happens).

8.2 Saving and reopening work

- **Datasets.** Select rows → Datasets box → **Save**: one `.nxs` file in the program's own format (several datasets per file, with their metadata and processing history), which **Load data...** opens again; or Igor Pro text (`.itx`). A viewer's panel exports what it shows (§3.8).
- **Figures.** In the figure composer, **Save** writes an `.afig` file that opens again for editing, with the data of every panel beside it ("data for "), so it opens even where the original files are not. Leave that folder out of anything you share. **Export** writes PNG, PDF, SVG or TIFF.
- **The experiment log** and the **session log** record what was measured and what was done (§2.3).
- Nothing is overwritten without asking: a save to an existing file asks first.

8.3 Error logs and bug reports

When something goes wrong, the program **keeps running** and saves the error and its traceback in **`error_logs/errors_<date>_<time>.txt` in the program's folder** (in `~/.arpes_viewer/error_logs/` if that folder cannot be written), one file per session in which an error happened. A message says so.

To report a bug, open an issue at https://github.com/DingPei1995/ARPES-viewer/issues with:

- the error log: **upload the file** (drag it into the text box) **or paste its text**. The main panel's last line has **Copy the newest error log** and **Open the error logs**;
- the version, from the title bar;
- what you did just before, and if possible the kind of file (beamline, cut or map).

If the program does not start at all, the launcher's log `~/.arpes_viewer/launcher.log` holds the reason.

8.4 Versions and updates

The title bar and the main panel's last line show the version and its date (`ARPES viewer v1.3.3 (updated 2026-11-10)`). What changed in each version, and why, is in the CHANGELOG.

To update a pip installation:

```
pip install --upgrade arpes-viewer
```

For the latest unreleased version, `pip install git+https://github.com/DingPei1995/ARPES-viewer`; a downloaded copy is updated by downloading it again. Datasets and figures saved by an earlier version open in later ones.

8.5 Tips and troubleshooting

- **A greyed tool button** — hover over it: the tooltip says why (e.g. the MDC fit needs a cut already in Å⁻¹, cut arithmetic two cuts). Select the right rows in the list and it lights up.
- **A tool is not in a viewer's Functions menu** — it is in the tool panel (see *Where things are now* in §2.1); check all three tabs (Basic, Advanced, Figure).
- **A window is taller than the screen** — it opens no taller than the screen, and its contents scroll; the Apply / Close buttons stay at the bottom. Every window can be resized.
- **A k conversion is not offered** — the first axis of the map is not an angle (a photon energy, temperature…). Check *First axis of a map is* in the loader.
- **Cut k conversion of an E − E_F cut** — the energy offset is filled in for you from the Fermi fit; if you shifted the axis some other way, type the kinetic energy of E_F (photon energy − work function) into *Energy offset*.
- **A file is misread** — choose the reader explicitly in the loader, and see *Assumptions worth knowing about* in the reading-data reference (axis order in SOLEIL files).
- **Dragging the cursor on a big map is sluggish** — a map read lazily from its file re-slices in about 0.1 s per window, so the other windows wait for the mouse to pause. Once the map has been read into memory it follows live.
- **Typing numbers** — every number box takes a decimal point (`0.05`), whatever the system language; a comma is not accepted.
- **The machine is paging** — watch the Memory bar (amber past a third of the RAM, red past a half); use **Free RAM** or **Close all**.