ARCAdevsvc

Reference manual

By

ARCA Technologies s.r.l.
Via Statale, 17
10012 - Bollengo (TO)

Tel. +39-0125.235.611
Fax. +39-0125.235.623

Website: www.arca.com
E-mail: techsupp.it@arca.com

INTERNAL

Contents

1 Overview 4
1.1 Revisions 4
2 Project Description 5
3 Product Description 6
3.1 Technologies 6
3.2 Compatibility 6
3.3 Supported devices 6
3.4 Integration 7
4 Functions 8
4.1 ARCAInitializeSrv 8
4.2 ARCAUpdateVersion 9
4.3 ARCAexeCassetteAssing 11
4.4 ARCAexeDeviceErrorLog 13
4.5 ARCAsetDeviceLAN 15
4.6 ARCAgetDeviceLAN 17
4.7 ARCAexeRecoverySuspend 19
4.8 ARCAexeRecoveryContinue 21
4.9 ARCAexeJournalInit 23
4.10 ARCAgetDevicePhoto 25
4.11 ARCAgetDevicePhotoNovus 28
4.12 ARCAsetDevicePhoto 33
4.13 ARCAsetDevicePhotoNovus 35
~~4.14 ARCAexeFileTransfer~~ 38
4.15 ARCAgetDispenseSecurityLimit 41
4.16 ARCAgetCommunicationLAN 43
4.17 ARCAsetCommunicationLAN 46
4.18 ARCAsetCassette 49
4.19 ARCAsetCassetteChangheKey 51
4.20 ARCAsetCassetteDenomination 53
4.21 ARCAsetReaderSettings 55

INTERNAL

4.22 ARCAsetDeviceIdentification 58
4.23 ARCAsetDeviceSettings 60
4.24 ARCAgetShiftCenterSettings 63
4.25 ARCAsetShiftCenterSettings 65
4.26 ARCAsetDeviceProtocolType 67
4.27 ARCAsetDeviceSerialNumber 69
4.28 ARCAsetAudioSettings 71
4.29 ARCAgetOperatingHours 73
4.30 ARCAsetOperatingHours 76
4.31 ARCAsetReaderThreshold 79
4.32 ARCAgetTimeZone 81
4.33 ARCAsetTimeZone 83
4.34 ARCAsetCommunicationUsb 85
4.35 ARCAgetCommunicationUsb 87
4.36 ARCAsetCommunicationSerial 89
4.37 ARCAgetCommunicationSerial 91
4.38 ARCAgetDeviceLife 94
4.39 ARCAsetModuleSerialNumber 96
4.40 ARCAsetMacAddress 99
4.41 ARCAexeCassetteAcceptAssign 101
4.42 ARCAexeTestMotorRTC 104
4.43 ARCAexeTestMotorSafe 106
4.44 ARCAexeTestMotorCassette 108
4.45 ARCAexePhotoSensorCassette 110
4.46 ARCAexeRtcSensorStatus 112
4.47 ARCAexeSafeSensorStatus 118
4.48 ARCAexeSensorStatus 121
4.49 ARCAexeSensorStatusAudit 126

INTERNAL

1 Overview

Project Name	*ARCAdevsvc*
Project Owner	*Loggia Davide*

1.1 Revisions

Date	Editor	Description	Version
04/04/22	Loggia Davide	First Draft	
07/04/22	Davide Loggia	fix TraceFunction in case of NULL buffer Rename file from NOVUS-errror.json to status.json Fix option One config issue Modified to five minute the timeout to upgrade FW from suite .zip file	0.8.4.0
21/04/22	Davide Loggia	Move ARCAsetDelays to ARCAdevint Remove parameter log to ARCAexeFileTransfer Move ARCAexeCassetteInit to ARCAdevint Move ARCAgetPocketOutput to ARCAdevint Move ARCAsetPocketOutput to ARCAdevint Remove ARCAgetInputSetting	0.9.0.0
03/05/22	Davide Loggia	Add ARCAexeInject for test by supplier	0.9.1.0
10/05/22	Davide Loggia	*Add ipv6 in ARCAgetCommunicationLAN ,* *Add ipv6 in ARCAsetCommunicationLAN* *Add ARCAsetModuleSerialNumber* *Add* ARCAsetMacAddress	0.9.2.0
30/05/22	Davide Loggia	*Move* ARCAgetCoinCashData Move ARCACoinInventory to ARCAdevint Move ARCACoinDispense to ARCAdevint Move ARCAgetCoinConfiguration to ARCAdevint	0.9.3.0
13/06/22	Davide Loggia	ARCAgetDevicePhotoNovus Report Lower photosensors with drawer information(ex A-outL)	0.9.4.0
15/07/22	Davide Loggia	A*dd ARCAexeCassetteAcceptAssign*	0.9.5.0
29/08/2022	Davide Loggia	ARCAsetDeviceSettings: must accept for the Set Option Once config both parameter to reduce changes for application already implemented: donotremovecassettejamifspecialcleanON doNotRemoveCassetteJamIfSpecialCleanON	0.9.6.0
26/09/2002	Davide Loggia	ARCAsetModuleSerialNumber add parameter to set the snNumber of Cassette	0.9.7.0

INTERNAL

		Add ARCAsetDevicePhotoNovus Add ARCAexeTestMotorRTC *Add ARCAexeTestMotorCassette* *Add ARCAexeTestMotorSafe* *Add* `ARCAexePhotoSensorCassette`	
25/10/2022	Davide Loggia	All Function : add 201 or 1792 in case of invalid parameter or not correct json in input	0.9.8.0
04/11/2022	Davide Loggia	Internal Release	0.9.9.0
22/11/2022	Davide Loggia	Add ARCAexeRtcSensorStatus Add ARCAexeRtcSensorStatus	0.9.10.0
02/12/2022	*Davide Loggia*	*Add ARCAexeSensorStatus*	0.9.11.0
12/12/2022	*Davide Loggia*	*Fix download cdf (CM18 machine)*	0.9.12.0
20/12/2022	*Davide Loggia*	*Add option to* `ARCAexeTestMotorRTC`	0.9.13.0
23/01/2023	*Davide Loggia*	ARCAexeSensorStatus add test switch	0.9.14.0
26/01/2023	*Davide Loggia*	`ARCAsetDeviceProtocolType correct bug after protocol change`	0.9.15.0
20/02/2023	*Davide Loggia*	`ARCAexeRtcSensorStatus bug fixing on CAT2Box presence` `Add spdlog for linux branch`	0.9.16.0

2 Project Description

INTERNAL

3 Product Description

3.1 Technologies

C++ developed libraries

3.2 Compatibility

Windows 10 64bit , Windows11 64bit

Ubuntu Linux 32/64bit

3.3 Supported devices

CM18x, CM18Solo, CM18B (TBD), OM61, Novus

INTERNAL

3.4 Integration

All functions are exported in C-Language compatible application programming interface (API).

The API is independent from the physical connection technology, whether it be TCP/IP, USB or RS232 used to connect the recycler to the host system.

To start an application program that uses this service it is necessary to install, in the application directory, the files listed below:

- ARCAdevsvc.dll
- ARCAdevlnk.dll
- ARCAliblog.dll

3.4.1 Example code

The parameters of all the functions are in JSON format, they are typically the parameters in input and in output of the functions.

If the file status.json is present in the same folder as where all the DLLs are located, then the output JSON structure will include the error code description as in the below Example

OutputData:

```
{
  "reply":
 {
    "replyCode": "0",
    "replyCodeDescription": "OK"
  }
}
```

If ARCAliblog.dll is present in the same folder as where ARCAdevsvc.dll is located, a tracefile for ARCAdevsvc and another one for ARCAdevlnk will be automatically produced.

To avoid the tracefiles to be created simply remove ARCAliblog.dll

ARCAdevsvc architecture supports multiple devices from the same instance returning a connection handle called hConn

INTERNAL

4 Functions

4.1 ARCAInitializeSrv

Result API ARCAInitializeSrv (**float** *versioning* , **char** **inData*);

Description

First function that the application MUST call for open the communication with the device.

Parameters

versioning (I)

The value must be set to **LIBRARY_VERSION_1_0**.

Less than 1.0 for alpha and beta versions.

inData (I)

JSON input data structure:

{

“pathtrace” : “xxxx”

}

Pathtrace = path where the trace file is stored

Return Value

AR_OKAY if successful.

AR_LIBRARY_INVALID_INITIALIZATION

INTERNAL

4.2 ARCAUpdateVersion

Result API ARCAUpdateVersion (**int** *hConnect,*
string * *inData,*
int lloutData*,*
string **outData)*;

hConnect (I)

Handle returned by ARCAConnect.
.

inData (I)
JSON output data structure:
{
"cmdMode": "xxx",
"updateMode ":"xxx"
"updateType":"xxx",
"FileName" : "xxx" ,
"FileSize" : "xxx" ,
"FilePath" : "xxx" ,
}

Accepted values for :
cmdMode = deposit mode execution, "SYNC" or "ASYNC".
updateMode: init , activate , check
updateType: Suite , Reference, SSLprivatekey , SSLcertificate

in case of init you must compile the other 3 parameter :
FileName = name of the file will be transferred on the device
FileSize = is the number of byte to transfer
FilePath= is the complete path of the file
in case of activate you must compile the other parameter :
FileName = name of the file will be transferred on the device
In case of check no parameter needed (to be implemented)

lloutData (I)
Specifies the size of the outData parameter.

OutData(O)

```
reply: {
"replyCode": "xxxx" ,
"replyCodeDescription": "xxxx"
}
```

INTERNAL

Description

This function is used to transfer and download a suite / cdf from pc to the machine

Return Value

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

AR_KO

AR_WAIT_DOWNLOAD_TIME_ELAPSED

Refer to status.json for the full list and description of return codes.

Comment : **to perform the download , in case of LAN connection you must connect to the port 8101 before the start of download**

INTERNAL

4.3 ARCAexeCassetteAssing

Result API ARCAexeCassetteAssign (**int** *hConnect,* **string** ** inData,* **int** lloutData**,** **string** **outData)*;
hConnect (I) *Handle returned by ARCAConnect.* .
inData (I) No input data , the argument must point to an empty string
lloutData (I) *Specifies the size of the outData parameter.*

OutData(O)
JSON output data structure:
{
content : {"message":"xx"}
reply : {"replyCode":"0","replyCodeDescription":"OK"}
}

Description

This command initializes the cassette logical address according to the physical positions. Use this command when a cassette is replaced or moved from one position to another.

Return Value

message*:* 0 = OK
1÷16 = cassette A÷"num_cas" not empty

17÷33 = cassette A÷"num_cas" hardware problem , check the hardware and retry

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

AR_KO

INTERNAL

Refer to status.json for the full list and description of return codes.

Comments

INTERNAL

4.4 ARCAexeDeviceErrorLog

Result API ARCAexeDeviceErrorLog (**int** *hConnect,*
string * *inData,*
int lloutData**,**
string **outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

JSON input data structure:

{

"operationType" : "xxxx" ,

}

Accepted values for operationType : :

Init = This command is used to erase all data stored

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

reply: {

"replyCode": "xxxx" ,

"replyCodeDescription": "xxxx"

}

INTERNAL

Return value :

Return Value

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

AR_KO

Refer to status.json for the full list and description of return codes.

INTERNAL

4.5 ARCAsetDeviceLAN

Result API ARCAsetDeviceLAN (**int** *hConnect,*

string * *inData,*

int lloutData**,**

string **outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

JSON input data structure:

{

*"*lanEncryption *" : "xxxx"*

}

Accepted values for lanEncryption*:*

"0" for Simplified

"1" for SSL/TLS

"2" for IPSEC

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

reply: {

"replyCode": "xxxx" ,

"replyCodeDescription": "xxxx"

}

INTERNAL

Return value :

Return Value

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

AR_KO

Refer to status.json for the full list and description of return codes.

INTERNAL

4.6 ARCAgetDeviceLAN

Result API `ARCAgetDeviceLAN` (**int** *hConnect,*

string * *inData,*

int lloutData**,**

string **outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

{

*"*configType*" : "xxxx" ,*

}

Accepted values for configType*:* "lanEncryption"

lanEncryption = get the type of LAN communication protocol

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

{

reply: {

"replyCode": "xxxx" ,

"replyCodeDescription": "xxxx"

}

"content": {

INTERNAL

“lanEncryption”: “xxx”

}

}

lanCommunicationProtocol = “0” -> Simplified

“1” -> SSL/TLS

“2” -> IPSEC

“4” -> 802.1x

“5” -> SSL/TLS+802.1x

Return Value

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

Refer to status.json for the full list and description of return codes.

INTERNAL

4.7 ARCAexeRecoverySuspend

Result API ARCAexeRecoverySuspend (**int** *hConnect,*

string * *inData,*

int lloutData**,**

string **outData)*;

Description

This command suspends the recovery cycle. In case of jam the recovery cycle isn' t performed after the removal of the jam by the operator. The "re-activate recovery" command must be executed in order to perform the recovery cycle

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

No input data , the argument must point to an empty stringfunctions

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

reply: {

"replyCode": "xxxx" ,

"replyCodeDescription": "xxxx"

}

Return value :

INTERNAL

Return Value

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

AR_KO

Refer to status.json for the full list and description of return codes.

INTERNAL

4.8 ARCAexeRecoveryContinue

Result API ARCAexeRecoveryContinue (**int** *hConnect,*

string * *inData,*

int lloutData**,**

string **outData)*;

Description

This command resumes the recovery cycle suspended with the **ARCAexeRecoverySuspend** command

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

No input data , the argument must point to an empty stringfunctions

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

reply: {

"replyCode": "xxxx" ,

"replyCodeDescription": "xxxx"

}

.

Return value :

Return Value

INTERNAL

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

AR_KO

Refer to status.json for the full list and description of return codes.

INTERNAL

4.9 ARCAexeJournalInit

Result API ARCAexeJournalInit (**int** *hConnect,*

string * *inData,*

int lloutData**,**

string **outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

No input data , the argument must point to an empty stringfunctions

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

reply: {

"replyCode": "xxxx" ,

"replyCodeDescription": "xxxx"

}

Return value :

Return Value

INTERNAL

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

AR_KO

Refer to status.json for the full list and description of return codes.

INTERNAL

4.10 ARCAgetDevicePhoto

Result API ARCAgetDevicePhoto (**int** *hConnect,*
string ** inData,*
int lloutData**,**
string **outData)*;

hConnect (I)

Handle returned by ARCAConnect.
.

inData (I)
No input data , the argument must point to an empty stringfunctions

lloutData (I)
Specifies the size of the outData parameter.

OutData(O)

```
{
  "content":{
    "ph_c1":"xx",
    "ph_c3":"xx",
    "ph_c4a":"xx",
    "ph_c4b":"xx",
    "ph_cashleft":"xx",
    "ph_cashright":"xx",
    "ph_count":"xx",
    "ph_feed":"xx",
    "ph_hmax":"xx",
    "ph_in_box":"xx",
    "ph_incenter":"xx",
    "ph_inleft":"xx",
    "ph_inq":"xx",
    "ph_out":"xx",
    "ph_rej":"xx",
    "ph_shift":"xx"
  },"reply":{
    "replyCode":"xx",
    "replyCodeDescription":"xx"
  }
}
```

Description

This command is used to get the values of most of all the photo sensors. **(only for CMXX)**

Return Value

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

AR_KO

Refer to status.json for the full list and description of return codes.

Example

No InputData

outData


```
{
  "content":{
    "ph_c1":"41",
    "ph_c3":"75",
    "ph_c4a":"30",
    "ph_c4b":"38",
    "ph_cashleft":"28",
    "ph_cashright":"46",
    "ph_count":"60",
    "ph_feed":"30",
    "ph_hmax":"15",
    "ph_in_box":"0",
    "ph_incenter":"45",
```


INTERNAL

```
    "ph_inleft":"45",
    "ph_inq":"26",
    "ph_out":"30",
    "ph_rej":"26",
    "ph_shift":"29"
  },"reply":{
    "replyCode":"0",
    "replyCodeDescription":"OK"
  }
}
```


INTERNAL

4.11 ARCAgetDevicePhotoNovus

Result API ARCAgetDevicePhotoNovus (**int** *hConnect,*
string ** inData,*
int lloutData**,**
string **outData)*;

hConnect (I)

Handle returned by ARCAConnect.
.

inData (I)
JSON output data structure:
{
"targetModule *" : "xxxx"* ,
"phId" : "xxx"
}

targetModule parameter **:** all
"
phId" in case of all

- "upper" for upper part sensor , no bins
- **"**lower" for lower part sensor
- "bins" for all bins sensor

lloutData (I)
Specifies the size of the outData parameter.

OutData(O)

reply: {
"replyCode": "xxxx" ,
"replyCodeDescription": "xxxx"
}
content :
{
"0":{
"agc":"xxx",
"current":"xxx",
"phId":"xxx",
"resultCode":"xxx",
"resultDescription":"xxx",
"threshold":"xxx"
},
"1":{
"agc":"xxx",
"current":"xxx",
"phId":"xxx",

INTERNAL

```
                                    "resultCode":"xxx",
                                    "resultDescription":"xxx",
                                    "threshold":"xxx"
                                  },
                                “xx”:{
                                  }
                        }
```


Description

This command is used to get the values of most of all the photo sensors**. (only for Novus)**

Return Value

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

Refer to status.json for the full list and description of return codes

Example :

inData

{

phId : "upper"

targetModule : "all"

}

outData

{

content :

{"0":{"agc":"0","current":"22","phId":"syncTrvR","resultCode":"0","resultDescription":"success","threshold":"0"},"1":{"agc":"0","current":"28","phId":"syncTrvL","resultCode":"0","resultDescription":"success","threshold":"0"},"10":{"agc":"0","current":"396","phId":"stackRejR1","resultCode":"0","resultDescription":"success","threshold":"12"},"11":{"agc":"0","current":"222","phId":"stackRejR2","resultCode":"0","resultDescription":"success","threshold":"12"},"12":{"agc":"0","current":"369","phId":"stackRejL1","resultCode":"0","resultDescription":"success","threshold":"12"},"13":{"agc":"0","current":"504","phId":"stackRejL2","resultCode":"0","resultDescription":"success","threshold":"12"},"14":{"agc":"0","current":"16","phId":"binFeed1","resultCode":"0","resultDescription":"success","threshold":"0"},"15":{"agc":"0","current":"19","phId":"binFeed2","resultCode":"0","resultDescription":"success","threshold":"0"},"16":{"agc":"0","current":"12","phId":"binFeed3","resultCode":"0","resultDescription":"success","threshold":"0"},"17":{"agc":"0","current":"13","phId":"binFeed4","resultCode":"0","resultDescription":"

INTERNAL

success","threshold":"0"},"18":{"agc":"0","current":"441","phId":"stackOutR1","resultCode":"0","resultDescription":"success","threshold":"12"},"19":{"agc":"0","current":"327","phId":"stackOutR2","resultCode":"0","resultDescription":"success","threshold":"12"},"2":{"agc":"0","current":"26","phId":"cashR","resultCode":"0","resultDescription":"success","threshold":"0"},"20":{"agc":"0","current":"384","phId":"stackOutL1","resultCode":"0","resultDescription":"success","threshold":"12"},"21":{"agc":"0","current":"507","phId":"stackOutL2","resultCode":"0","resultDescription":"success","threshold":"12"},"3":{"agc":"0","current":"14","phId":"cashL","resultCode":"0","resultDescription":"success","threshold":"0"},"4":{"agc":"0","current":"786","phId":"syncOutR","resultCode":"0","resultDescription":"success","threshold":"12"},"5":{"agc":"0","current":"642","phId":"syncOutC","resultCode":"0","resultDescription":"success","threshold":"12"},"6":{"agc":"0","current":"339","phId":"syncOutL","resultCode":"0","resultDescription":"success","threshold":"12"},"7":{"agc":"0","current":"339","phId":"binRejR","resultCode":"0","resultDescription":"success","threshold":"12"},"8":{"agc":"0","current":"387","phId":"binRejC","resultCode":"0","resultDescription":"success","threshold":"12"},"9":{"agc":"0","current":"453","phId":"binRejL","resultCode":"0","resultDescription":"success","threshold":"12"}}

reply : {"replyCode":"0","replyCodeDescription":"OK"}

}

inData

```
{
  phId : "bins"
  targetModule : "all"
}
```

ourData


```
{
  "content":{
    "0":{
      "agc":"0",
      "current":"1008",
      "phId":"binOutR",
      "resultCode":"0",
      "resultDescription":"success",
      "threshold":"2"
    },
    "1":{
      "agc":"0",
      "current":"957",
```


INTERNAL

"phId":"binOutC",
"resultCode":"0",
"resultDescription":"success",
"threshold":"2"
},
"2":{
"**agc**":"0",
"**current**":"1006",
"**phId**":"binOutL",
"**resultCode**":"0",
"**resultDescription**":"success",
"**threshold**":"3"
},
"3":{
"agc":"0",
"current":"999",
"phId":"rejR",
"resultCode":"0",
"resultDescription":"success",
"threshold":"6"
},
"4":{
"agc":"0",
"current":"966",
"phId":"rejC",
"resultCode":"0",
"resultDescription":"success",
"threshold":"1"
},
"5":{
"agc":"0",

INTERNAL

```
        "current":"979",
        "phId":"rejL",
        "resultCode":"0",
        "resultDescription":"success",
        "threshold":"1"
      },
      "6":{
        "agc":"1",
        "current":"619",
        "phId":"binIn",
        "resultCode":"0",
        "resultDescription":"success",
        "threshold":"9"
      }
    }"reply":{
      "replyCode":"0",
      "replyCodeDescription":"OK"
    }
}
```


INTERNAL

4.12 ARCAsetDevicePhoto

Result API ARCAsetDevicePhoto (**int** *hConnect,*
string ** inData,*
int lloutData**,**
string **outData)*;

hConnect (I)

Handle returned by ARCAConnect.
.

inData (I)
JSON output data structure:
{
"ph_id": "xxxx" ,
}

"ph_all" = all photo sensor (CMxx && Novus)
"ph_upper" = only photo sensor upper part (CMxx && Novus)
"ph_lower" = only photo sensor lower part (CMxx && Novus)
"bins" = only photo sensors of the bins (**only Novus**)

"ph_inleft" "(**only CM**)
"ph_incenter"(**only CM**)
"ph_feed""(**only CM**)
"ph_c1""(**only CM**)
"ph_shift""(**only CM**)
"ph_inq""(**only CM**)
"ph_count""(**only CM**)
"ph_out""(**only CM**)
"ph_c3""(**only CM**)
"ph_c4a""(**only CM**)
"ph_c4b""(**only CM**)
"ph_rej""(**only CM**)
"ph_in_box""(**only CM**)
"ph_cashleft""(**only CM**)
"ph_cashright""(**only CM**)
"ph_hmax""(**only CM**)

lloutData (I)
Specifies the size of the outData parameter.

OutData(O)

reply: {
"replyCode": "xxxx" ,
"replyCodeDescription": "xxxx"
}

INTERNAL

Description

This command is used to calibrate the values of most of the sensors (**CM && Novus**)

Return Value

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

Refer to status.json for the full list and description of return codes.

INTERNAL

4.13 ARCAsetDevicePhotoNovus

Result API ARCAsetDevicePhotoNovus (**int** *hConnect,*
string ** inData,*
int lloutData**,**
string **outData)*;

hConnect (I)

Handle returned by ARCAConnect.
.

inData (I)
JSON output data structure:
{
“binModulePhase” : "xxx"
“phId” : "xxx"
“targetModule” : "xxx"
“agc: "xxx"
“current” : “xxx”
“threshold” : “xxx”

}

targetModule = “bins” or “singlePhoto”
in case of bins

binModulePhase = “phase1” or “phase2”
phId = “binOutput” , “binReject” , “binInput”

in case of singlePhoto

agc : "value of agc"
current : "value of current"
threshold : "value of threshold"
phid = “binOutR” , “binOutC” , “binOutL” ,” binRejR” , “binRejC” , “binRejL” , “binIn”

lloutData (I)
Specifies the size of the outData parameter.

OutData(O)

reply: {
"replyCode": "xxxx" ,
"replyCodeDescription": "xxxx"
}

INTERNAL

Description

This command is used to calibrate the values of **photo bin (only for Novus)**

Return Value

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

Refer to status.json for the full list and description of return codes.

Example

inData

```
{
  agc : "1"
  current : "773"
  phId : "binIn"
  targetModule : "singlePhoto"
  threshold : "14"
}
```

outData

```
{
  reply : {"replyCode":"0","replyCodeDescription":"OK"}
}
```

inData

```
{
  binModulePhase : "phase1"
  phId : "binOutput"
  targetModule : "bins"
}
```

INTERNAL

outData

{
reply : {"replyCode":"0","replyCodeDescription":"OK"}
}

INTERNAL

4.14 ARCAexeFileTransfer

Result API ARCAexeFileTransfer(**int***hConnect,*

string * *inData,*

int lloutData**,**

string **outData)*;*

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

JSON input data structure:

{

“transferType“ : “xxxx” ,

“transferMode” : “xxxx” ,

“transferFile” : “xxxx”

}

Accepted values for transferType: :

Download

Upload

Accepted values for transferMode:

Init

Transfer

End

Abort

Service

Accepted values for transferFile

Suite

Module:

INTERNAL

~~lloutData (I)~~

~~Specifies the size of the outData parameter.~~

~~OutData(O)~~

~~reply: {~~

~~"replyCode": "xxxx" ,~~

~~"replyCodeDescription": "xxxx"~~

~~}~~

~~Return value :~~

~~Return Value~~

~~AR_OKAY~~

~~AR_UNIT_ALREADY_RESERVED~~

~~AR_UNIT_BUSY~~

~~Refer to status.json for the full list and description of return codes.~~

INTERNAL

INTERNAL

4.15 ARCAgetDispenseSecurityLimit

Result API ARCAgetDispenseSecurityLimit (**int** *hConnect,*

string * *inData,*

int lloutData**,**

string **outData)*;

Description

With this command it is possible to get the increase time control dispense amount

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

No input data , the argument must point to an empty stringfunctions

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

reply: {

"replyCode": "xxxx" ,

"replyCodeDescription": "xxxx"

}

Return value :

Return Value

AR_OKAY

INTERNAL

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

AR_KO

Refer to status.json for the full list and description of return codes.

INTERNAL

4.16 ARCAgetCommunicationLAN

Result API ARCAgetCommunicationLAN (int*hConnect,*
char **inData*,
int *lloutData,*
char **outData);*

hConnect (I)
Handle returned by ARCAConnect.

inData (I)
{
"lanParam" :"xxxx"
Or
"lanPort" : "xxxx"
}

lanParam value accepted :
"1"=DHCP
"2"=IP address
"3"=Subnet mask "
4"=Gateway
"5"=Device name "
6"=Device description
"7"=Primary DNS
"8"=Secondary DNS
"9"=Primary WINS
"10"=Secondary WINS
"11"= Use NetBios name
"12"= Username 802.1x
"13"= Password 802.1x
"14"= IPv6 enabled (only for Novus)

"lanPort" value accepted :
"1" = LAN 1
"2" = LAN 2
"3" = LAN 3
"4"= LAN 4
"5"= LAN 5
"6"= LAN 6
"7"= LAN 7
"8"= LAN 8
"9"= LAN 9
"10"= LAN 10
"11"= LAN Service

lloutData (I)

INTERNAL

Specifies *outData* size.

outData (O)
{
reply:
{
"replyCode": "xxxx" ,
"replyCodeDescription": "xxxx"
}
"content":
{
“lanParamValue” :”xxxx”
}
}.

Description

With this command it is possible to get the LAN configuration parameters.

Return Value

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

AR_KO

Refer to status.json for the full list and description of return codes.

Example

inData

{

lanParam : "3"

}

outData

{

content : {"lanParamValue":"255.255.0.0"}

reply : {"replyCode":"0","replyCodeDescription":"OK"}

}

INTERNAL

inData

{

lanParam : "2"

}

outData

{

content : {"lanParamValue":"172.19.12.45"}

reply : {"replyCode":"0","replyCodeDescription":"OK"}

}

inData

{

lanPort : "1"

}

outData

{

content : {"lanPortStatus":"enable","lanPortValue":"8000"}

reply : {"replyCode":"0","replyCodeDescription":"OK"}

}

INTERNAL

4.17 ARCAsetCommunicationLAN

Result API ARCAsetCommunicationLAN (int*hConnect*,
char **inData*,
int *lloutData*,
char **outData);*

hConnect (I)
Handle returned by ARCAConnect.

inData (I)
{
"lanParam" :"xxxx"
"lanParamValue" : "xxxx"

Or

lanPort : "xxx"
lanPortStatus : "xxxx"
lanPortValue : "xxxx"

}

lanParam value accepted :

- *"1"=DHCP(0 disable 1 enable)*
- *"2"=IP address (0.0.0.0 max 15 char)*
- *"3"=Subnet mask "mask (0.0.0.0 max 15 char)*
- *4"=Gateway (0.0.0.0 max 15 char)*
- *"5"=Device name "(max 15 char)*
- *6"=Device description(max 50 char)*
- *"7"=Primary DNS (0.0.0.0 max 15 char)*
- *"8"=Secondary DNS(0.0.0.0 max 15 char)*
- *"9"=Primary WINS (0.0.0.0 max 15 char)*
- *"10"=Secondary WINS (0.0.0.0 max 15 char)*
- *"11"= Use NetBios name (max 32 char)*
- *"12"= Username 802.1x*
- *"13"= Password 802.1x (max 32 char)*
- *"14"= IPv6 enabled(0 disable 1 enable**) (only for Novus)***

lanPort value accepted : "1" to "11" "11" is = "LAN Service"
lanPortStatus : "enable / disable"
lanPortValue : ex "8000" "8001" "8009"

lloutData (I)
Specifies *outData* size.

INTERNAL

outData (O)

```
{
      reply:
      {
           "replyCode": "xxxx" ,
           "replyCodeDescription": "xxxx"
       }
}.
```

Description

With this command it is possible to set the LAN configuration parameters.

Return Value

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

AR_KO

Refer to status.json for the full list and description of return codes.

Example

inData

```
{
  lanParam : "2"
  lanParamValue : "172.19.12.41"
}
```

outData

```
{
reply : {"replyCode":"0","replyCodeDescription":"OK"}
}
```

inData

```
{
  lanParam : "3"
```


INTERNAL

lanParamValue : "255.255.0.0"

}

outData

{

reply : {"replyCode":"0","replyCodeDescription":"OK"}

}

inData

{

lanPort : "1"

lanPortStatus : "disable"

lanPortValue : "8000"

}

outData

{

reply : {"replyCode":"0","replyCodeDescription":"OK"}

}

INTERNAL

4.18 ARCAsetCassette

Result API ARCAsetCassette(**int** *hConnect,*

string * *inData,*

int lloutData**,**

string **outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

JSON input data structure:

{

*"*configType *" : "xxxx"*

*"*cassetteNumber" : "xxx"

}

Accepted values for configType*:*

"**cassetteNumber**" = With this command it is possible to get the number of the configured cassettes of the device.

"**protocolCassetteNumber**" = With this command it is possible to set the number of the cassettes used by communication protocol.

"**serviceProtocolCassetteNumber**"= With this command it is possible to set the number of the cassettes used by service communication protocol

INTERNAL

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

reply: {

"replyCode": "xxxx" ,

"replyCodeDescription": "xxxx"

}

Return Value

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

Refer to status.json for the full list and description of return codes.

Comments

INTERNAL

4.19 ARCAsetCassetteChangheKey

Result API ARCAsetCassetteChangeKey(**int** *hConnect,*

string * *inData,*

int lloutData**,**

string **outData)*;

Description

The default code is '123456' any customer can change this code using the following command

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

JSON input data structure:

{

"cassette" : “xxxx”

"oldCode" : “xxxx” ,

newCode": “xxxx” ,

}

target-cassette = A÷”num_cas”

old-code = old key-code (6 ASCII-chars 0x20-0x7f)
new-code = new key-code (6 ASCII-chars 0x20-0x7f)

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

reply: {

"replyCode": "xxxx" ,

INTERNAL

"replyCodeDescription": "xxxx"

}

Return Value

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

Refer to status.json for the full list and description of return codes.

Comments

INTERNAL

4.20 ARCAsetCassetteDenomination

Result API ARCAsetCassetteDenomination(**int** *hConnect,*

string * *inData,*

int lloutData**,**

string **outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

{

“cas_id”: Cassette id ‘A’- ‘num_cas' ,
“NrDenominationElements” : “xxx”,
“NrDenomination”: [

{ “denominationID”: “xxxx},

{ “denominationID”: “xxxx” },

{ “denominationID”: “xxxx”, },

….

}

cas_id= (4 ASCII-chars)
denominationID : Denomination (ex: EUCA) – Max 128

lloutData (I)

Specifies the size of the outData parameter.

INTERNAL

OutData(O)

reply: {

"replyCode": "xxxx" ,

"replyCodeDescription": "xxxx"

}

Return value :

Return Value

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

AR_KO

Refer to status.json for the full list and description of return codes.

INTERNAL

4.21 ARCAsetReaderSettings

Result API ARCAsetReaderSettings(**int** *hConnect,*
string * *inData,*
int lloutData**,**
string **outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

{

"type"= "xxxx"

"bank_num" = "xxxx"
or
"bank_to_act" = "xxxx"
or
"enable_ref1" = "xxxx" ,
"enable_ref2" = "xxxx" ,
"enable_ref3" = "xxxx" ,
"enable_ref4" = "xxxx" ,
or
"slot" = "xxxx" ,
"bankId" , "xxxx"

}

Possible value for type : numBanks , activeBanks

numBanks = This command is used to select the bank of note identifier with which you want to work
parameter : "bank_num" = "Number of bank (0 or 15)

INTERNAL

activeBanks = This command is used to select the number of active banks of note identifier that will work concurrently (if you want to work in SINGLE CURRENCY bank_to_act must be equal to zero (0) or more than 4 and if you want to work in MULTICURRENCY bank_to_act must be from 1 to 4).

Parameter : *"bank_to_act " = Number of bank that you want to activate*

references = This command is used to temporary enable/disable references

parameter :

enable_ref1 = Reference n° 1 1: enabled / 0: disabled
enable_ref1 = Reference n° 2 1: enabled / 0: disabled
enable_ref1 = Reference n° 3 1: enabled / 0: disabled
enable_ref1 = Reference n° 4 1: enabled / 0: disabled

slot = This command is used to select the references that will be stored on the reader

parameter :

slot : destination of reader memory (0-3)

bankId = Reference bank number (0-16)

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

reply: {

"replyCode": "xxxx" ,

"replyCodeDescription": "xxxx"

}

Return value :

INTERNAL

Return Value

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

AR_KO

Refer to status.json for the full list and description of return codes.

INTERNAL

4.22 ARCAsetDeviceIdentification

Result API ARCAsetDeviceIdentification(**int***hConnect,*

string * *inData,*

int lloutData**,**

string **outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

{

*"*CMxxx" : "xxxx"

}

Possible values are:

- CM20
- CM18
- CM18T
- CM18E
- CM20E

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

reply: {

"replyCode": "xxxx" ,

"replyCodeDescription": "xxxx"

INTERNAL

```
}
```

Return value :

Return Value

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

Refer to status.json for the full list and description of return codes.

INTERNAL

4.23 ARCAsetDeviceSettings

Result API ARCAsetDeviceSettings (**int** *hConnect,*
string * *inData,*
int lloutData**,**
string **outData)*;

Description

With this command it is possible to set some functionality parameters

Before settings the parameters it is necessary to read the configuration with ARCAgetDeviceSettings (ARCADevInt) and pass the same structure with the values changed

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

{

"content": {

"Config": {

"viewDateTimeOnDisplay": "true/false",

"balancedCassetteHandling": "true/false",

"alarm1Handling": "true/false",

"delayClassDispensing": "true/false",

"viewDateTimeOnDisplayInFormatAMandPM": "true/false",

"useUnfitinSafe": "true/false",

"enableJournallog": "true/false"

},

"OptionConfig": {

"specialCleanWithoutControl": "true/false",

"specialAlarmMode": "true/false",

INTERNAL

```
"simplifiedProtocol": "true/false",
"executeCloseCommandAlsoInJam": "true/false"
},
"OptionOneConfig": {
"forceRecoveryWithTestCommand": "true/false",
"doNotRemoveCassetteJamIfSpecialCleanON": "true/false",
"lanTimeout": "true/false",
"timeControlDispenseamount": "true/false",
"enableBookingExternalButton": "true/false"
},
"OptionTwoConfig": {
"safeCen40Bit": "true/false",
"bvuSynchronousHandling": "true/false",
"faceOrientationHandling": "true/false",
"specialCleanUsingDisplay": "true/false",
"cat2BoxHandling": "true/false",
"evoLedHandling": "true/false",
"separateCat2andCat3": "true/false",
"feedBanknoteswithInputBinFree": "true/false",
"differentCenterAUDbn": "true/false",
"disableMessageonDisplay": "true/false",
"alarm2OutputHandling": "true/false",
"remapFeederJamtoMissfeeding": "true/false",
"virtualDestkopEnvironment": "true/false",
"handlingNewLedSide": "true/false",
"disableCM18evoLedPulse": "true/false"
}
}
}
```


INTERNAL

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

reply: {

"replyCode": "xxxx" ,

"replyCodeDescription": "xxxx"

}

Return value :

Return Value

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

Refer to status.json for the full list and description of return codes.

INTERNAL

4.24 ARCAgetShiftCenterSettings

Result API ARCAgetShiftCenterSettings(**int** *hConnect,*

string * *inData,*

int lloutData**,**

string **outData)*;

Description

With this command it is possible to get the centering value of the bankonote on output slot

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

No input data , the argument must point to an empty string

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

{

reply: {

"replyCode": "xxxx" ,

"replyCodeDescription": "xxxx"

}

"content": {

“*centeringValue*”: “xxx”

}

INTERNAL

}

Return value :

Return Value

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

Refer to status.json for the full list and description of return codes.

INTERNAL

4.25 ARCAsetShiftCenterSettings

Result API ARCAsetShiftCenterSettings(**int** *hConnect,*

string * *inData,*

int lloutData**,**

string **outData)*;

Description

With this command it is possible to get the centering value of the bankonote on output slot

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

{

“*centeringValue*”: “xxx”

}

centeringValue =centering value between the range 55 -78 (default 65)

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

{

reply: {

"replyCode": "xxxx" ,

"replyCodeDescription": "xxxx"

}

INTERNAL

```
                }
        }
```

Return Value

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

Refer to status.json for the full list and description of return codes

INTERNAL

4.26 ARCAsetDeviceProtocolType

Result API ARCAsetDeviceProtocolType(**int** *hConnect,*

string * *inData,*

int lloutData**,**

string **outData)*;

Description

Using this command it is possible to switch USB\RS232 protocol from standard to simplified or vice versa and return to previous protocol state without reset the unit.

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

{

" “protocolSet" : "xxxx"

}

protocolSet accetped value : STANDARD / SIMPLIFIED

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

reply: {

"replyCode": "xxxx" ,

"replyCodeDescription": "xxxx"

}

INTERNAL

Return value :

Return Value

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

Refer to status.json for the full list and description of return codes.

INTERNAL

4.27 ARCAsetDeviceSerialNumber

Result API `ARCAsetDeviceSerialNumber` (**int** *hConnect,*
string * *inData,*
int lloutData**,**
string **outData)*;

Description

This command is used to fill the serial number to the machine stored in controller

Parameters

hConnect (I)

Handle returned by ARCAConnect.

{

*“*serialNumber *” : “*xxxx*” ,*

}

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

{

reply: {

"replyCode": "xxxx" ,

"replyCodeDescription": "xxxx"

}

}

}

INTERNAL

Return Value

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

Refer to status.json for the full list and description of return codes.

INTERNAL

4.28 ARCAsetAudioSettings

Result API ARCAsetAudioSettings(**int** *hConnect,*
string * *inData,*
int lloutData**,**
string **outData)*;

Description

This command is used to fill the audio configuration parameters

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

JSON input data structure:

{

*“*audioValue *“ : “xxxx”*

}

audioValue (0-65535)

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

reply: {
"replyCode": "xxxx" ,
"replyCodeDescription": "xxxx"
}

INTERNAL

Return value :

Return Value

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

AR_KO

Refer to status.json for the full list and description of return codes.

INTERNAL

4.29 ARCAgetOperatingHours

Result API `ARCAgetOperatingHours` (**int** *hConnect,*
string * *inData,*
int lloutData**,**
string **outData)*;

Description

With this command is possible to get the Periodic operating hour filled

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

{

*"*operatingHoursType" = "xxxx" ,

"weekDay *" : "xxxx"* ,

Or

"day : "xxx"

*"*month" : "xxxx" ,

"year" : "xxxx"

}

operatingHoursType = **periodic** , **aperiodic**

in case of **periodic** :

weekDay = Week day setted, (Monday, Tuesday, …).

INTERNAL

*in case of **aperiodic** :*

day = Day of month (1-31)
month = (1-12)
year = es: 2003 == 03

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

{

In case of Periodic

{

content :
{"day":"XX","lunchBreakOff":"xx:xx","lunchBreakOn":"xx:xx","switchOff":"xx:xx","switchOn":"xx:xx"}

reply : {"replyCode":"0","replyCodeDescription":"OK"}

}

In case of Aperiodic

{

content :
{"day":"xx","lunchBreakOff":"xx:xx","lunchBreakOn":"xx:xx","month":"xx","switchOff":"xx:xx","switchOn":"xx:xx","year":"xx"}

reply : {"replyCode":"0","replyCodeDescription":"OK"}

}

}

INTERNAL

Return Value

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

Refer to status.json for the full list and description of return codes.

INTERNAL

4.30 ARCAsetOperatingHours

Result API `ARCAsetOperatingHours` (**int** *hConnect,*

string * *inData,*

int lloutData**,**

string **outData)*;

Description

With this command is possible to get the Periodic operating hour filled

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

{

*In case of **periodic***

`weekDay` *: "xx" ,*

lunchBreakOff : "xx:xx" ,

lunchBreakOn : "xx:xx" ,

operatingHoursType : "periodic" ,

switchOff : "xx:xx" ,

switchOn : "xx:xx"

*in case of **aperiodic***

day : "xx"

lunchBreakOff : "xx:xx",

lunchBreakOn : "xx:x"

month : "xx"

operatingHoursType : "aperiodic"

switchOff : "xx:xx"

INTERNAL

switchOn : "xx:xx"

year : "xx"

}

in case of periodic :

weekDay = Week day setted, (Monday, Tuesday, …).

in case of aperiodic :

day = Day of month (1-31)
month = (1-12)
year = es: 2003 == 03

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

{

content :

reply : {"replyCode":"0","replyCodeDescription":"OK"}}

Return Value

AR_OKAY

INTERNAL

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

Refer to status.json for the full list and description of return codes.

INTERNAL

4.31 ARCAsetReaderThreshold

Result API `ARCAsetReaderThreshold` (**int** *hConnect,*
string * *inData,*
int lloutData**,**
string **outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

{

“configType “ *: “xxxx”* ,

“bankId” : “xxx”

“fitFlag” : “xxxx”

“fitThresholdFitness” : “xxxx”

}

“bankId” = Reference bank number (0-15)

configType accetpted parameter : **fitConfiguration** , **fitThreshold**

in case of fitConfiguration the parameter **fitFlag** is Fit Handling Flag (0= Fitness Enabled , 1= Always FIT)

in case of fitThreshold the parameter **fitThresholdFitness** is the Threshold Fitness ID (0-2)

INTERNAL

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

```
                    {
            reply: {
            "replyCode": "xxxx" ,
            "replyCodeDescription": "xxxx"
            }
            }
    }
```

Return Value

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

Refer to status.json for the full list and description of return codes.

INTERNAL

4.32 ARCAgetTimeZone

Result API ARCAgetTimeZone (**int** *hConnect,*

string * *inData,*

int lloutData**,**

string **outData)*;

Description

With this command it is possible to get the Time Zone Time configuration parameters

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

NO imput data , set to NULL

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

content : {"timeZoneIndex":"xxx"}

reply : {"replyCode":"xxxx","replyCodeDescription":"xxx"}

timeZoneIndex = refer to file arca_timezone.json to get the value

Return value :

INTERNAL

Return Value

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

Refer to status.json for the full list and description of return codes.

INTERNAL

4.33 ARCAsetTimeZone

Result API ARCAsetTimeZone (**int** *hConnect,*

string * *inData,*

int lloutData**,**

string **outData)*;

Description

This command is used to fill the Time Zone Time parameters

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

{

"timeZoneIndex": "14"

}

timeZoneIndex = refer to file arca_timezone.json to get the value

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

reply : {"replyCode":"xxxx","replyCodeDescription":"xxx"}

Return value :

INTERNAL

Return Value

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

Refer to status.json for the full list and description of return codes.

INTERNAL

4.34 ARCAsetCommunicationUsb

Result API ARCAsetCommunicationUsb (**int** *hConnect,*

string * *inData,*

int lloutData**,**

string **outData)*;

Description

With this command is possible to enable/disable the USB ports.

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

{

portUsb : "xxx"

statusUsb : "enable/disable"

}

portUsb = It identifies the port USB number 1 = USB Host 1 2 = USB Host 2 3 = USB Host 3 (Service) Possible value are : 1 - CM18Solo 1 or 2 - C6060 1,2 or 3 - Others unit type

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

reply : {"replyCode":"xxxx","replyCodeDescription":"xxx"}

Return value :

INTERNAL

Return Value

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

Refer to status.json for the full list and description of return codes.

INTERNAL

4.35 ARCAgetCommunicationUsb

Result API ARCAgetCommunicationUsb (**int** *hConnect,*

string * *inData,*

int lloutData**,**

string **outData)*;

Description

: With this command it is possible to get the USB status (enable or disable)

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

{

portUsb : "xxx"

}

portUsb = It identifies the port USB number 1 = USB Host 1 2 = USB Host 2 3 = USB Host 3 (Service) Possible value are : 1 - CM18Solo 1 or 2 - C6060 1,2 or 3 - Others unit type

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

{
{"content":{"statusUsb":"xxxx"},"reply":{"replyCode":"xxxx","replyCodeDescription":"xxxx"}}}

Return value :

INTERNAL

Return Value

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

Refer to status.json for the full list and description of return codes.

INTERNAL

4.36 ARCAsetCommunicationSerial

Result API ARCAsetCommunicationSerial (**int** *hConnect,*

string * *inData,*

int lloutData**,**

string **outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

{

portSerial: "xxx"

statusSerial: "enable/disable"

}

portSerial : Possible values:

- *“A” – Serial port A*
  “B” – Serial port B

statusSerial : Possible values:

“off” , “peripheral” , “host”

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

reply : {"replyCode":"xxxx","replyCodeDescription":"xxx"}

INTERNAL

Return value :

Return Value

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

Refer to status.json for the full list and description of return codes

INTERNAL

4.37 ARCAgetCommunicationSerial

Result API ARCAgetCommunicationSerial (**int** *hConnect,*

string * *inData,*

int lloutData**,**

string **outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

{

portSerial: "xxx"

}

portSerial : Possible values:

- *“A” – Serial port A*
  “B” – Serial port B

statusSerial : Possible values:

“off” , “peripheral” , “host”

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

{"content":{" *statusSerial* ":"xxxx"},
"reply":{"replyCode":"xxxx","replyCodeDe scription":"xxxx"}}}

INTERNAL

statusSerial = : Possible values:

“off” , “peripheral” , “host”

Return value :

Return Value

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

Refer to status.json for the full list and description of return codes

INTERNAL

INTERNAL

4.38 ARCAgetDeviceLife

Result API `ARCAgetDeviceLife` (**int** *hConnect,*

string * *inData,*

int lloutData**,**

string **outData)*;

Description

With this command it is possible to get the UnitLife of the device

Parameters

hConnect (I)

No input data , the argument must point to an empty string

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

{

reply: {

"replyCode": "xxxx" ,

"replyCodeDescription": "xxxx"

}

"content": {

“totalNotesLifeProcessed”: “xxx”

}

}

INTERNAL

Return Value

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

Refer to status.json for the full list and description of return codes.

INTERNAL

4.39 ARCAsetModuleSerialNumber

Result API `ARCAsetModuleSerialNumber` (**int** *hConnect*, **string** * *inData*, **int** lloutData, **string** **outData*);
hConnect (I) *Handle returned by ARCAConnect.* .
inData (I) *{* *"moduleName" : "RTC"* *"serialNumber" : "xxxxxxxxx"* "cassetteNumber" : "xxx" *}* *moduleName" possibile value "**RTC**" , , **cassetteSerialNumber*** .
lloutData (I) *Specifies the size of the outData parameter.*

OutData(O)
JSON output data structure:
{
reply : {"replyCode":"0","replyCodeDescription":"OK"}
}

Description

This command is used to fill serial number of various module

Return Value

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

AR_KO

INTERNAL

Refer to status.json for the full list and description of return codes.

Comments

Example

inData

```
{
  moduleName : "RTC"
  serialNumber : "R136600148101477"
}
```

outData

```
{
reply : {"replyCode":"0","replyCodeDescription":"OK"}
}
```

Example

inData

```
{
  cassetteNumber : "A"
  moduleName : "cassetteSerialNumber"
  serialNumber : "0000E0006354"
}
```

outData

```
{
reply : {"replyCode":"0","replyCodeDescription":"OK"}
}
```

INTERNAL

INTERNAL

4.40 ARCAsetMacAddress

Result API ARCAsetMacAddress(**int** *hConnect,* **char** **inData*, **int** *lloutData,* **char** **outData);*
hConnect (I) Handle returned by ARCAConnect.
inData (I) { *"MacAddress" = "xxxx"* }.
lloutData (I) Specifies *outData* size.

outData (O)
{
"reply":
{
"replyCode": "xxxx" ,
"replyCodeDescription": "xxxx"
}
}.

Description

This command is used to fill the Mac Address.

Return Value

AR_OKAY if successful

Refer to status.json for the full list and description of return codes.

Example

INTERNAL

```
inData
{
   MacAddress : "000E72821234"
}
```

Outdata

```
{
  reply : {"replyCode":"0","replyCodeDescription":"OK"}
}
```

INTERNAL

4.41 ARCAexeCassetteAcceptAssign

Result API ARCAexeCassetteAcceptAssign (**int** *hConnect,*
char **inData*,
int *lloutData,*
char **outData);*

hConnect (I)
Handle returned by ARCAConnect.

No input data , the argument must point to an empty string

lloutData (I)
Specifies *outData* size.

outData (O)

```
{
 {
   "content":{
      "message":"xx",
      "noteReport":[
         {
            "capacity":"xxx",
            "cassetteID":"xxx",
            "noteID":"xxxx",
            "numberNote":"xx",
            "switch":"enabled"
         },
         {
            "capacity":"xxx",
            "cassetteID":"xxx",
            "noteID":"xxxx",
            "numberNote":"xxx",
            "switch":"enabled"
         }
      ],
      "noteReportElements":"xxx",
      "totalNotes":"xxx"
   }"reply":{
      "replyCode":"xxx",
      "replyCodeDescription":"xxx"
   }
}
```

Description

INTERNAL

This command is used to import a cassette full from another device. Use this command when a cassette is replaced or moved from one position to another.

Return Value

AR_OKAY if successful

Refer to status.json for the full list and description of return codes.

Example

outData

```
{
   "content":{
      "message":"xx",
      "noteReport":[
         {
            "capacity":"xxx",
            "cassetteID":"A",
            "noteID":"xxxx",
            "numberNote":"xx",
            "switch":"enabled"
         },
         {
            "capacity":"xxx",
            "cassetteID":"xxx",
            "noteID":"xxxx",
            "numberNote":"xxx",
            "switch":"enabled"
         }
      ],
      "noteReportElements":"xxx",
      "totalNotes":"xxx"
```

INTERNAL

```
   }"reply":{
      "replyCode":"xxx",
      "replyCodeDescription":"xxx"
   }
}
```


INTERNAL

4.42 ARCAexeTestMotorRTC

Result API ARCAexeTestMotorRTC (**int** *hConnect,*
char **inData*,
int *lloutData,*
char **outData);*

hConnect (I)
Handle returned by ARCAConnect.

inData (I)
{
"motorId" = *"xxxx"*
}.

*motorId value for CM18: "*mso" , "msvInput" , "msvOutput" , "presFo" , "sfo" , "align" , "elmShift", "mde" , "pressor" , "pusher" , "cat2BoxSorter"

motorId value for novus : "feederInput" , "feederOutput" , "traspH" , "enterInput" , "enterOutput" , "traspVInput" , "traspVOutput"

lloutData (I)
Specifies *outData* size.

outData (O)
{

```
   }"reply":{
      "replyCode":"xxx",
      "replyCodeDescription":"xxx"
   }
}
```

Description

This command is used to test the functionality of the RTC motors

Return Value

AR_OKAY if successful

Refer to status.json for the full list and description of return codes.

INTERNAL

Example

inData

```
{
   motorId : "align"
}
```

outData

```
{
  reply : {"replyCode":"0","replyCodeDescription":"OK"}
}
```

INTERNAL

4.43 ARCAexeTestMotorSafe

Result API ARCAexeTestMotorSafe (**int** *hConnect,* **char** **inData*, **int** *lloutData,* **char** **outData);*
hConnect (I) Handle returned by ARCAConnect.
inData (I) { *"motorId" = "xxxx"* }. *motorId value : "*`mivInput" , "mivOutput" , "elmDoor" , "doorSolenoid" , "cassetteASorter" ,"..." "cassetteLSorter" , "safeTrv"`
lloutData (I) Specifies *outData* size.

outData (O)
{
`}"reply":{`
`"replyCode":"xxx",`
`"replyCodeDescription":"xxx"`
`}`
}

Description

This command is used to test the functionality of the Safe motors

Return Value

AR_OKAY if successful

Refer to status.json for the full list and description of return codes.

Example

INTERNAL

inData

```
{
   motorId : "align"
}
```

outData

```
{
  reply : {"replyCode":"0","replyCodeDescription":"OK"}
}
```

INTERNAL

4.44 ARCAexeTestMotorCassette

Result API ARCAexeTestMotorCassette (**int** *hConnect,*
char **inData*,
int *lloutData,*
char **outData);*

hConnect (I)
Handle returned by ARCAConnect.

inData (I)
{
"motorId" = "xxxx"
"cassetteId" = "xxxx"
}.

motorId value for cm18: "preset" , "pinchRoller"

motorId value for novus: "preset", "pinchRoller" , "preset"

cassetteId : "cassetteA" ….." cassetteL"

lloutData (I)
Specifies *outData* size.

outData (O)
{

```
   }"reply":{
      "replyCode":"xxx",
      "replyCodeDescription":"xxx"
   }
}
```

Description

This command is used to test the functionality of the Cassette Motors

Return Value

AR_OKAY if successful

Refer to status.json for the full list and description of return codes.

INTERNAL

Example

inData

```
{
   cassetteId : "cassetteA"
   motorId : "preset"
}
```

outData

```
{
  reply : {"replyCode":"0","replyCodeDescription":"OK"}
}
```

INTERNAL

4.45 ARCAexePhotoSensorCassette

Result API ARCAexePhotoSensorCassette (**int** *hConnect,*
char **inData*,
int *lloutData,*
char **outData);*

hConnect (I)
Handle returned by ARCAConnect.

inData (I)
{
"operationType" = *"xxxx"*
"cassetteId" = "xxxx"

phId : "xxx"
}.

operationTypevalue : "read" , "write"
cassetteId : "cassetteA" ….." cassetteL"

in case of write :
phId possible value "ph_all" , "phFotin" , "phFotout"

lloutData (I)
Specifies *outData* size.

outData (O)
{

```
   }"reply":{
      "replyCode":"xxx",
      "replyCodeDescription":"xxx"
   }
}
```

Description

This command is used to read / write the functionality of the cassette photo sensor

Return Value

AR_OKAY if successful

INTERNAL

Refer to status.json for the full list and description of return codes.

Example

inData

```
{
   cassetteId : "cassetteA"
   operationType : "write"
   phId : "ph_all"
}
```

Outdata

```
{
  reply : {"replyCode":"0","replyCodeDescription":"OK "}
}
```

inData

```
{
  cassetteId : "cassetteA"
  operationType : "read"
}
```

Outdata

```
{
  content : {"phFotin":"14","phFotout":"16"}
  reply : {"replyCode":"0","replyCodeDescription":"OK"}
}
```

INTERNAL

4.46 ARCAexeRtcSensorStatus

Result API `ARCAexeRtcSensorStatus` (**int** *hConnect,*
char **inData*,
int *lloutData*,
char **outData);*

hConnect (I)
Handle returned by ARCAConnect.

No input data , the argument must point to an empty string

lloutData (I)
Specifies *outData* size.

outData (O)

```
{
  "content":{
    "ph_c1":{
      "phDescription":"xxx",
      "phValue":" xxx "
    },
    "ph_c3":{
      "phDescription":" xxx ",
      "phValue":" xxx "
    },
    "ph_c4a":{
      "phDescription":" xxx ",
      "phValue":" xxx "
    },
    "ph_c4b":{
      "phDescription":" xxx ",
      "phValue":" xxx "
    },
    "ph_count":{
      "phDescription":" xxx ",
      "phValue":" xxx "
    },
    "ph_cover":{
      "phValue":" xxx "
    },
    "ph_coverLeft":{
      "phDescription":" xxx ",
      "phValue":" xxx "
    },
```

INTERNAL

```
"ph_fPocket":{
  "phDescription":" xxx ",
  "phValue":" xxx "
},
"ph_fPress":{
  "phDescription":" xxx ",
  "phValue":" xxx "
},
"ph_feed":{
  "phDescription":" xxx ",
  "phValue":" xxx "
},
"ph_hmax":{
  "phDescription":" xxx ",
  "phValue":" xxx "
},
"ph_inPocket":{
  "phDescription":" xxx ",
  "phValue":" xxx "
},
"ph_incenter":{
  "phDescription":" xxx ",
  "phValue":" xxx "
},
"ph_inleft":{
  "phDescription":" xxx ",
  "phValue":" xxx "
},
"ph_inq":{
  "phDescription":" xxx ",
  "phValue":" xxx "
},
"ph_out":{
  "phDescription":" xxx ",
  "phValue":" xxx "
},
"ph_press":{
  "phDescription":" xxx ",
  "phValue":" xxx "
},
"ph_push":{
  "phDescription":" xxx ",
  "phValue":" xxx "
},
"ph_rej":{
  "phDescription":" xxx ",
  "phValue":" xxx "
```


INTERNAL

```
    },
    "ph_shake":{
      "phDescription":" xxx ",
      "phValue":" xxx "
    },
    "ph_shift":{
      "phDescription":" xxx ",
      "phValue":" xxx "
    }
  }"reply":{
    "replyCode":"0",
    "replyCodeDescription":"OK"
  }
}
```

Description

This command is used to the status of single RTC photo

Return Value

AR_OKAY if successful

Refer to status.json for the full list and description of return codes.

Example

inData

No input data , the argument must point to an empty string

Outdata

```
{
  "content":{
    "ph_c1":{
      "phDescription":"free", or "covered"
      "phValue":"1" or "0"
    },
    "ph_c3":{
```

INTERNAL

INTERNAL

```
  "phDescription":"free", or "covered"
  "phValue":"1" or "0"
},
"ph_c4a":{
  "phDescription":"free", or "covered"
  "phValue":"1" or "0"
},
"ph_c4b":{
  "phDescription":"free", or "covered"
  "phValue":"1" or "0"
},
"ph_count":{
  "phDescription":"free", or "covered"
  "phValue":"1" or "0"
},
"ph_cover":{
  "phDescription":"open",or "close"
  "phValue":"1" or "0"
},
"ph_coverLeft":{
  "phDescription":"free", or "covered"
  "phValue":"1" or "0"
},
"ph_fPocket":{
  "phDescription":"free", or "covered"
  "phValue":"1" or "0"
},
"ph_fPress":{
```

"phDescription":"free", or “covered”

"phValue":"1" or “0”

},

"ph_feed":{

"phDescription":"free", or “covered”

"phValue":"1" or “0”

},

"ph_hmax":{

"phDescription":"free", or “covered”

"phValue":"1" or “0”

},

"ph_inPocket":{

"phDescription":"free", or “covered”

"phValue":"1" or “0”

},

"ph_incenter":{

"phDescription":"free", or “covered”

"phValue":"1" or “0”

},

"ph_inleft":{

"phDescription":"free", or “covered”

"phValue":"1" or “0”

},

"ph_inq":{

"phDescription":"free", or “covered”

"phValue":"1" or “0”

},

"ph_out":{

INTERNAL

```
    "phDescription":"free", or “covered”
    "phValue":"1" or “0”
  },
  "ph_press":{
    "phDescription":"free", or “covered”
    "phValue":"1" or “0”
  },
  "ph_push":{
    "phDescription":"free", or “covered”
    "phValue":"1" or “0”
  },
  "ph_rej":{
    "phDescription":"free", or “covered”
    "phValue":"1" or “0”
  },
  "ph_shake":{
    "phDescription":"free", or “covered”
    "phValue":"1" or “0”
  },
  "ph_shift":{
    "phDescription":"free",  or “covered”
    "phValue":"1" or “0”
  }
 }"reply":{
  "replyCode":"0",
  "replyCodeDescription":"OK"
 }
}
```


INTERNAL

4.47 ARCAexeSafeSensorStatus

Result API `ARCAexeSafeSensorStatus` (**int** *hConnect,*
char **inData*,
int *lloutData*,
char **outData);*

hConnect (I)
Handle returned by ARCAConnect.

No input data , the argument must point to an empty string

lloutData (I)
Specifies *outData* size.

outData (O)

```
{
  "content":{
    "ph_alarm3":{
      "phDescription":"xxx",
      "phValue":" xxx "
    },
    "ph_alarm4":{
      "phDescription":" xxx ",
      "phValue":" xxx"
    },
    "ph_cashleft":{
      "phDescription":" xxx ",
      "phValue":" xxx "
    },
    "ph_cashright":{
      "phDescription":" xxx ",
      "phValue":" xxx "
    },
    "ph_safeOpen":{
      "phDescription":" xxx ",
      "phValue":" xxx "
    }
  }"reply":{
    "replyCode":"0",
    "replyCodeDescription":"OK"
  }
}
```

INTERNAL

Description

This command is used to the status of single SAFE photo

Return Value

AR_OKAY if successful

Refer to status.json for the full list and description of return codes.

Example

inData

```
no input data
```

Outdata

```
{
  "content":{
    "ph_alarm3":{
      "phDescription":"alarmClose",    or “alarmOpen”
      "phValue":"1" or “0”
    },
    "ph_alarm4":{
      "phDescription":"alarmClose", or “alarmOpen
      "phValue":"1" or “0”
    },
    "ph_cashleft":{
      "phDescription":"close", or “open”
      "phValue":"1" or “0”
    },
    "ph_cashright":{
      "phDescription":"close", or “open”
      "phValue":"1" or “0”
```

INTERNAL

```
    },
    "ph_safeOpen":{
      "phDescription":"close", or “open”
      "phValue":"1" or “0”
    }
  }"reply":{
    "replyCode":"0",
    "replyCodeDescription":"OK"
  }
}
```

INTERNAL

4.48 ARCAexeSensorStatus

Result API `ARCAexeSensorStatus` (**int** *hConnect,*
char **inData*,
int *lloutData,*
char **outData);*

hConnect (I)
Handle returned by ARCAConnect.

inData()
{
phId : "xxxx"
}

phId value : “lower” , “bins” , “upper” , “switch”

lloutData (I)
Specifies *outData* size.

outData (O)
{
"content":{
See example …
}
}"reply":{
"replyCode":"0",
"replyCodeDescription":"OK"
}
}

***The value of single photo must be “*covered” or “free” or “notResponse”**
***The value of single switch must be “*open” or “close” or “not_open_not_close”**

Description

This command is used to the status of single photo (upper , lower ,bins ,”switch”) **ONLY FOR NOVUS**

Return Value

AR_OKAY if successful

Refer to status.json for the full list and description of return codes.

INTERNAL

Example

inData

```
{
    phId : "upper"
}
```

Outdata

```
      "phDescription":"free",
      "phValue":"1"
    },
    "syncOutL":{
      "phDescription":"free",
      "phValue":"1"
    },
    "syncOutR":{
      "phDescription":"free",
      "phValue":"1"
    },
    "syncTrvL1":{
      "phDescription":"free",
      "phValue":"1"
    },
    "syncTrvL2":{
      "phDescription":"free",
      "phValue":"1"
    },
    "syncTrvR1":{
      "phDescription":"free",
      "phValue":"1"
    },
    "syncTrvR2":{
      "phDescription":"free",
      "phValue":"1"
    },
    "trackOpen":{
      "phDescription":"free",
      "phValue":"1"
    }
  }"reply":{

    "replyCode":"0",
    "replyCodeDescription":"OK"
```

```
  }
}
```

inData

```
{
  phId : "bins"
}
```

outData

```
{
  "content":{
    "binIn":{
      "phDescription":"covered",
      "phValue":"0"
    },
    "binOutC":{
      "phDescription":"free",
      "phValue":"1"
    },
    "binOutL":{
      "phDescription":"free",
      "phValue":"1"
    },
    "binOutR":{
      "phDescription":"free",
      "phValue":"1"
    },
    "binRejC":{
      "phDescription":"free",
      "phValue":"1"
    },
    "binRejL":{
      "phDescription":"free",
      "phValue":"1"
    },
    "binRejR":{
      "phDescription":"free",
      "phValue":"1"
    }
  }"reply":{
    "replyCode":"0",
    "replyCodeDescription":"OK"
  }
}
```

inData

{

phId : "lower"

}

outData


```
{
  "outR":{
    "phDescription":"free",
    "phValue":"1"
  },
  "sorter":{
    "phDescription":"free",
    "phValue":"1"
  },
  "track":{
    "phDescription":"free",
    "phValue":"1"
  }
 },
 "9":{
  "cassetteDescription":"cassette1",
  "end":{
    "phDescription":"free",
    "phValue":"1"
  },
  "outL":{
    "phDescription":"free",
    "phValue":"1"
  },
  "outR":{
    "phDescription":"free",
    "phValue":"1"
  },
  "sorter":{
    "phDescription":"free",
    "phValue":"1"
  },
  "track":{
    "phDescription":"free",
    "phValue":"1"
  }
 }
```

}"reply":{

"replyCode":"0",
"replyCodeDescription":"OK"
}
}

inData

{
phId : "switch"
}

outData

{
content :
{"switchCage":{"phDescription":"open","phValue":"1"},"},"switchDoor":{"phDescription":"close","phValue":"0"},"switchUpper":{"phDescription":"close","phValue":"0"}}
reply : {"replyCode":"xx","replyCodeDescription":"xxx"}
}

INTER

4.49 ARCAexeSensorStatusAudit

Result API `ARCAexeSensorStatusAudit` (**int** *hConnect,*
char **inData*,
int *lloutData,*
char **outData);*

hConnect (I)
Handle returned by ARCAConnect.

inData()
{
phId : "xxxx"
}

phId value : “lower” , “bins” , “upper”

lloutData (I)
Specifies *outData* size.

outData (O)
{
"content":{
See example …
}
}"reply":{
"replyCode":"0",
"replyCodeDescription":"OK"
}
}

Description

This command is used to get the Audit of single photo(upper , lower ,bins) **ONLY FOR NOVUS**

Return Value

AR_OKAY if successful

Refer to status.json for the full list and description of return codes.

INTERNAL

Example

phStatus":"0" or "4" not execute

"2" warning

"3" fault

"1" ok

inData

```
{
  phId : "bins"
}
```

outData

```
{
   "content":{
      "binIn":{
         "phId":"36",
         "phPercentile":"0",
         "phStatus":"0"
      },
      "binOutC":{
         "phId":"21",
         "phPercentile":"0",
         "phStatus":"0"
      },
      "binOutL":{
         "phId":"22",
         "phPercentile":"0",
         "phStatus":"0"
      },
      "binOutR":{
         "phId":"20",
         "phPercentile":"0",
         "phStatus":"0"
      },
      "binRejC":{
         "phId":"24",
         "phPercentile":"0",
         "phStatus":"0"
      },
      "binRejL":{
         "phId":"25",
         "phPercentile":"0",
         "phStatus":"0"
      },
      "binRejR":{
```

```
            "phId":"23",
            "phPercentile":"0",
            "phStatus":"0"
         }
      }"reply":{
         "replyCode":"0",
         "replyCodeDescription":"OK"
      }
}
```

inData

```
{
   phId : "lower"
}
```

outData

tbd

inData

```
{
   phId : "upper"
}
```

outData

tbd