
Schematic Example




Don't forget to connect power and ground on your physical circuit!

SILLY CIRCUIT
PAUL CHOW
SEPT 11,2014


Equipment




Pin Headers + Ribbon Cables




Breadboard Neatness



Overkill for Lab 1



Well planned, Easily debugged



Lab Nightmare...

OK for Lab 1