### **CEMENT**

- •A cement is a binding material used in construction industry, that sets, hardens, and adheres to other materials to bind them together.
- •Cement is the most widely used binding material in construction industry



1

#### **CEMENT**

### Chemical composition:

Lime (CaO)	62-67%
Silica (SiO2)	17-25%
Alumina (Al2O3)	3-8%
Calcium Sulphate (CaSO4)	3-4%
Iron Oxide (Fe2O3)	3-4%
Magnesia (MgO)	0-3%
Sulphur (S)	1-3%
Alkalies	0-1%

### **Uses of Cement**

- 1. Used for the preparation of cement mortar, concrete
- 2. Cement mortar is used for binding of brick & stone masonry
- 3. Cement mortar is used to cover the masonry surface
- 4. Cement mortar is used for pointing of brick & stone masonry
- 5. Cement mortar is used for different type of floors & floor finishes
- 6. Decorative & Aesthetic works
- 7. Manufacturing of pipes & posts
- 8. Manufacturing of RCC roof slab, columns, raft foundations, water tanks, bridges, dams, pile foundations, railway sleepers etc.

2

# **Effects of ingredients**

- **►Lime** 62-67%
- Makes cement sound and strong
- ■Excess lime causes expansion & disintegration
- •Deficiency causes decrease in strength and early setting
- ➤ Silica 17-25%
- •when mixed with water, Di calcium silicate and Tri calcium silicate are formed, which gives strength
- •Excess silica increase the strength but prolongs setting time

### **Effects of ingredients**

- ➤ Alumina 3-8%
- ■Impart quick setting property
- Lowers clinkering temperature during manufacture of cement
- ■Excess alumina weakens cement
- **➤ Calcium sulphate** 3-4%
- Added in the form of Gypsum
- Prolongs initial setting time

5

### Good qualities of cement

- 1.Provides strength to masonry
- 2. Stiffens or hardens early
- 3. Should have good plasticity when mixed with water
- 4. Easily workable
- 5. Good moisture-resistance
- 6. High resistance to atmospheric and chemical agencies
- 7. Initial setting time should not be less than 30 minutes and final setting should be around 10 hrs
- 8. Compressive strength should be high
- 9. Tensile strength should be high

### **Effects of ingredients**

- ►Iron oxide 3-4%
- Imparts colour, hardness and strength to cement
- ➤ Magnesia 0-3%
- Imparts colour and hardness to cement

Excess amount makes the cement unsound

- ➤ Sulphur 1-3%
- Very small amount of sulphur makes cement sound In excess makes unsound
- ➤ Alkalies 0-1%
- Present in excess causes efflorescence in cement

6

#### **Field Tests for Cement**

- 1. When a hand is introduced into a bag of cement, the cement should be cool to feel.
- 2. A small sample of cement when rubbed between fingers should feel smooth.
- 3. A handful of cement thrown into a bucket of water should gradually sink.
- 4. No lumps should be present in the cement. Presence of lumps indicate that the cement is already set.
- 5. Cement should have uniform greenish grey colour.

### **Types of Cement**

#### **Ordinary Portland Cement**

#### ≥33 grade cement

■ Compressive strength of cement mortar cube at the end of 28 days should be more than 33 N/mm<sup>2</sup>

#### **≥**43 grade cement

■ Compressive strength of cement mortar cube at the end of 28 days should be more than 43 N/mm²

#### ≥53 grade cement

■ Compressive strength of cement mortar cube at the end of 28 days should be more than 53 N/mm<sup>2</sup>

9

## **Types of Cement**

#### **≻**Portland Pozzolona cement

- Made by inter grinding Portland cement & pozzolona (10-30%)
- Pozzolona may be volcanic ash or fly ash
- Greater resistance to chemical attack
- Used for marine structures, hydraulic structures etc.

#### > Portland Slag cement

- Made by grinding Portland cement clinker with granulated furnace slag
- Reduces heat of hydration, permeability etc.
- Increases resistance to corrosion, chemical attack etc.
- Suitable in marine environment

# **Types of Cement**

#### **≻**Rapid hardening cement

- Develops strength rapidly
- 3 day strength is same as that of 7 day strength of OPC
- Due to higher fineness of grinding Due to high C3S and low C2S
- Used in pre fabricated construction, road repair work, places where form work has to be removed immediately, for cold weather concrete

#### **≻**Low heat Portland cement

- Heat evolution is much lesser as compared to that of OPC
- Used in massive construction like abutments, dams, retaining wall etc.

10

# **Types of Cement**

#### **≻**Coloured cement

- Obtained by adding pigment with OPC
- Amount of pigment added varies from 5% to 10%
- ✓ Chromium oxide-Green
- ✓ Iron oxide-Brown, Black, Red, Yellow
- ✓ Carbon pigment-Black
- Used for decorative works

#### >Hydrophobic cement/water repellent

- Cement clinker is ground with a water repelling film forming agent
- Calcium oleates, pentachlorophenol, oleic acid or stearic acid Used where water tight conditions are predominant

# Types of Cement

#### **≻**Expansive cement

- OPC shrinks during setting & drying
- Expansive cement when mixed with water, forms a paste that tends to increase in volume
- This expansion compensates for the shrinkage losses Used in machine foundation, concrete repair works

#### **≻**Acid resisting cement

- It resist acid attack
- Quartz & sodium silicates are added to OPC
- Used for the construction of acid resisting cement floors in factories

13

Sulphate resisting cement
 OPC is easily attacked by sulphates and causes cracks
 most severe in case of marine structures
 C3A% is made less than 5
 Marine structures
 Sewage treatment structures

### **Types of Cement**

#### **➤**Quick setting cement

- It sets quickly
- Setting starts within 5 minutes & hardens within an hour
- % gypsum is reduced

For under water construction

#### **≻White cement**

■ Free from colouring agents like oxides of iron, manganese & chromium

14

- High alumina cement
- Air entraining cement
- Oil well cement
- Super sulphate cement
- Low heat Portland cement

### Tests for cement

#### **Compressive Strength**

- Cement mortar cubes are prepared and immersed in water for curing
- Samples are taken out and tested in CTM at the end of 3 days and 7 days
- 3 day strength -11.5 N/mm2
- 7 day strength 17.5 N/mm2

17

# Vicat apparatus



# Consistency

- to determine the % of water required to prepare cement paste
- Vicat apparatus
- Cement paste is filled in the mould of the apparatus
- Plunger is gently lowered on the paste
- Note the settlement of the plunger
- Penetration of plunger is 5mm-7mm from bottom, water added is correct, otherwise repeat with different % of water till desired penetration is obtained

18

# Setting time

- To detect deterioration of cement due to storage
- Vicat apparatus
- Cement paste is filled in the mould of the apparatus
- Note the time when water is added to the cement to prepare the paste
- Square needle of 1mmx1mm is quickly released to penetrate the cement paste
- Needle penetrates completely at first
- Repeat till the needle doesn't penetrate completely ie about 5mm from bottom
- Initial setting time = time from when water added to prepare the paste till the time when the needle stops penetrating completely
- 30 min

# Final setting time

- Cement paste is filled in the mould of the apparatus
- A needle with annular collar is gently released on top of the paste
- Time at which the needle makes an impression on the test block and the collar fails to do so is noted
- Difference between the above time and the time at which water is added to the cement gives the final setting time
- 10 hrs

21

# Le Chatelier apparatus



### Soundness

- To determine the presence of uncombined lime
- Le Chatelier apparatus
- Brass mould of diameter 30mm and ht 30mm is placed on a glass plate and is filled by cement paste
- Cover with another glass plate
- A small wt is placed at top
- Immersed in water for 24 hrs @ 24-35°C

22

### Soundness

- · Distance between pts of indicator is noted
- Mould is again placed in water and heat is applied such that water boils in 30 min. continue boiling for 1-3 hr
- Mould is removed from water and is allowed to cool
- Distance between pts of indicator is noted
- The difference indicated expansion of cement
- < 10mm