Aquaflow X200 Industrial Pump - Service Manual (extract)

Document ID: AQF-SM-X200, revision C. This extract covers specifications, installation, approved fluids, maintenance, failure classification, error codes and warranty notes for the X200.

1. Specifications

The X200 industrial pump has a rated pressure of 10 bar, a maximum flow rate of 42 m3/h, a 5.5 kW 400 V three-phase motor and a maximum fluid temperature of 80 C. It weighs 64 kg. The full specification is in the table below.

Parameter	X200
Rated pressure	10 bar
Motor	5.5 kW, 400 V, 3-phase
Max flow	42 m3/h
Max fluid temperature	80 C
Weight	64 kg
Seal service interval	8,000 h
Bearing service interval	4,000 h (regrease)

2. Installation requirements

The X200 must be installed by an Aquaflow Certified Installer on a level concrete base, with an isolation valve on each side, a non-return valve on the outlet and a dry-run protection switch. The motor must be protected by a motor protection circuit breaker set to the nameplate current.

3. Approved fluids

Clean water and water-glycol mixtures with at most 30% glycol. Seawater, oils, solvents and fluids containing abrasive solids are not approved and will damage the seals and impeller.

4. Maintenance schedule

Interval	Task
Weekly	Check for leaks and unusual noise
Monthly	Check vibration and motor temperature
Every 4,000 h	Regrease bearings
Every 8,000 h	Replace mechanical seal
Annually	Inspection by an authorised agent

Record every task in the maintenance log with the date, operating hours and the name of the person who carried it out. The log is required for warranty claims on the X200.

5. Failure versus normal wear

A failure is a loss of function caused by a defect. Motor seizure, motor winding failure and cracking of the pump housing at or below the rated pressure are classed as failures.

Normal wear covers the gradual degradation of consumable parts: mechanical seals, impeller wear rings and bearings with more than 8,000 operating hours. Normal wear is not a failure.

6. Error codes

Code	Meaning	Action
E01	Dry run detected	Stop; check suction supply
E02	Overpressure	Check outlet valves
E03	Motor over-temperature	Check ventilation and load
E04	Pressure sensor fault	Call service agent
E05	Phase loss	Check supply

Repeated E01 or E02 events are stored in the controller and are reviewed during warranty assessment, because damage from dry running or overpressure is excluded from the warranty.

7. Warranty

Warranty terms for the X200 are governed by the Aquaflow Limited Warranty Policy and any amendment in force at the date of purchase. This manual does not record purchase dates; the purchase date must be taken from the sales receipt.