

## **Distribution Guide**

FDx SDK Pro for Windows, v3.7

#### 1. Runtime Files

| Item            | File                          | Destination Directory  | Description                               |
|-----------------|-------------------------------|------------------------|---|
| Common Library  | sgfplib.dll<br>sgfpamx.dll    | WINSYSDIR<br>WINSYSDIR | Main module  Extraction & matching module |
| .NET Library    | SecuGen.FDxSDKPro.Windows.dll | Application Path       | Library for .NET application              |
| ActiveX control | sgfplibx.ocx                  | Application Path       | COM server                                |

Note: The DLL files sgfplib.dll and sgfpamx.dll should be installed in the Windows system directory or the application execution path for all application types including .NET applications.

# 2. SecuGen Fingerprint Device Drivers<sup>1</sup>

SecuGen device drivers for Windows are available for download from SecuGen's website at <a href="https://www.secugen.com/download">www.secugen.com/download</a>. You may direct your users to access the drivers from SecuGen's website, as they are updated periodically. Otherwise you may include the device drivers as part of your application setup for their convenience.

When a user plugs in the SecuGen reader, the operating system will ask for the *inf* file location. Place the following USB driver files into the respective directories. They will be automatically copied by the operating system when the user indicates its directory location.

Alternatively, if all required files are already copied into the SYSTEM directory BEFORE a SecuGen USB reader is connected, a user could simply click on **Next** in the **Found New Hardware Wizard** with the option "Install the software automatically (Recommended)" selected.

#### • FDU02-based USB devices

| USB Driver Files   | Directory  | Description   |  |  |
|--|--|---|--|--|
| x86  |  |   |  |  |
| fpusb.inf<br>venus.dll<br>venusdrv.sys<br>fdu02.cat                          | Determined by OS<br>Determined by OS<br>Determined by OS<br>Determined by OS         | USB inf file<br>USB driver<br>USB kernel driver<br>MS signed catalog file               |  |  |
| x64  |  |   |  |  |
| fpusbx64.inf<br>venus.dll<br>venusx64.dll<br>venusdrvx64.sys<br>fdu02x64.cat | Determined by OS | USB inf file<br>USB driver<br>USB driver<br>USB kernel driver<br>MS signed catalog file |  |  |

<sup>&</sup>lt;sup>1</sup> Legacy Drivers (not Windows Biometric Framework (WBF) drivers)

### FDU03 and SDU03-based USB devices

| USB Driver Files   | Directory   | Description   |  |  |
|--|---|---|--|--|
| x86  |   |   |  |  |
| sgfpusb.inf<br>sgfu03m.dll<br>sgfu03d.sys<br>fdu03.cat                           | Determined by OS<br>Determined by OS<br>Determined by OS<br>Determined by OS                          | USB inf file<br>USB driver<br>USB kernel driver<br>MS signed catalog file               |  |  |
| x64  |   |   |  |  |
| sgfu03x64.inf<br>sgfu03m.dll<br>sgfu03x64.dll<br>sgfu03x64.sys<br>sgfdu03x64.cat | Determined by OS | USB inf file<br>USB driver<br>USB driver<br>USB kernel driver<br>MS signed catalog file |  |  |

### • FDU04 and SDU04-based USB devices

| USB Driver Files   | Directory   | Description   |  |  |
|--|---|---|--|--|
| x86  |   |   |  |  |
| Sgfdu04.inf<br>sgfdu04m.dll<br>sgfdu04d.sys<br>sgfdu04.cat                           | Determined by OS<br>Determined by OS<br>Determined by OS<br>Determined by OS                          | USB inf file<br>USB driver<br>USB kernel driver<br>MS signed catalog file               |  |  |
| x64  |   |   |  |  |
| Sgfdu04x64.inf<br>sgfdu04m.dll<br>sgfdu04x64.dll<br>sgfdu04x64.sys<br>sgfdu04x64.cat | Determined by OS | USB inf file<br>USB driver<br>USB driver<br>USB kernel driver<br>MS signed catalog file |  |  |

## • FDU05 (U20)-based USB devices

| USB Driver Files   | Directory   | Description   |  |  |
|--|---|---|--|--|
| x86  |   |   |  |  |
| Sgfdu05.inf<br>sgfdu05m.dll<br>sgfdu05d.sys<br>sgfdu05.cat                           | Determined by OS<br>Determined by OS<br>Determined by OS<br>Determined by OS                          | USB inf file<br>USB driver<br>USB kernel driver<br>MS signed catalog file               |  |  |
| x64  |   |   |  |  |
| Sgfdu05x64.inf<br>sgfdu05m.dll<br>sgfdu05x64.dll<br>sgfdu05x64.sys<br>sgfdu05x64.cat | Determined by OS | USB inf file<br>USB driver<br>USB driver<br>USB kernel driver<br>MS signed catalog file |  |  |