



-AUTOMATIC STOP If the bag is full or the door is open with red warning light flashing (I).
 - ENERGY SMART SYSTEM which automatically reduces power consumption when on STAND-BY and when 12 seconds have passed since the last automatic shred cycle.

CARE AND MAINTENANCE

The Kobra AF.1 and KOBRA AF+1 I are high quality shredders, designed for automatic and manual shredding.

The cutting knives of the Kobra AF1 C4 and Kobra AF+1 C4 do not need to be lubricated with oil. However to maintain your shredder in optimum condition, you must use it responsibly and periodic maintenance is recommended.

The Kobra AF.1 C2 is fitted with a special integrated oiling system, the "AUTOMATIC OILER" which eliminates the need for oiling the cutting knives manually so it is advisable to periodically check the level of the oil in the container inside the cabinet.

It is not normally necessary to operate the machine at maximum capacity every time it is used.

It is always recommended to use the machine at less than maximum capacity.

This will mean you need less frequent maintenance and will prolong the life of mechanical parts.

ATTENTION!

In case of slippage or failure to pull the paper through the machine, the 8 inlet belts in the feeder tray should be cleaned regularly with a soft damp cloth.

AUTOMATIC OILER (FIG.2)

(only for the model Kobra AF.1 C2)

The Kobra AF.1 C2 is fitted with a special integrated oiling system, the "AUTOMATIC OILER" which eliminates the need for oiling the cutting knives, Kobra AF.1 C2 models come fitted with an oil container with a capacity of 1 litre.

INSTALLATION (FIG.2)

Once you have taken the machine out of its packaging, position the head of the machine (A) on the cabinet (B) and insert the end of the hose (M) into the connector (N).

Take the container of oil which came with the machine, unscrew the cap seal and dispose of it, insert the tube of oil (O) and screw the cap back on properly.

OPERATION:

When you have plugged the machine in, turn the knob (H) to the position "I". The light (G) will come on for a few seconds and the machine will start a shredding cycle.

During the first few minutes of operation, the cutting knives might NOT be properly oiled since the oil feeder is not yet completely full. In order to make it fill up more quickly, trigger the photo cells inside the mouth so that the shredder runs empty for 8/10 minutes straight.

Now your shredder is ready for operation and the cutting knives are oiled.

REPLACING THE OIL CONTAINER

Open the door.

Take out the empty oil container (P) out of its housing, unscrew the cap on the top (Q) and extract the oil tube (O). Get a new oil container, remove the seal cap and dispose of it, insert the oil tube (O) and screw the cap on tightly.

Put the new oil container back in its housing and close the door.

Now your shredder is ready for operation.

Attention!

During the first few minutes of operation, the cutting knives might NOT be properly oiled since the oil feeder is not yet completely full. In order to make it fill up more quickly, trigger the photo cells inside the mouth so that the shredder runs empty for 8/10 minutes straight.

Now your shredder is ready for operation and the cutting knives are oiled.



Fire hazard

NEVER use synthetic oil, benzene based products or aerosol lubricants of any kind inside or in the vicinity of the machine

ACCESSORIES

COMBINATION SAFETY LOCK

only for model Kobra AF.1 (Fig.4)

On request the Kobra AF.1 can be fitted with a combination safety lock for the top cover of the feeder tray to ensure safety of documents during shredding.


COVER BLOCK FUNCTION:

Open the top cover of the paper feeder tray as shown in figure 3.

Insert the documents to be shredded into the paper feeder tray.

Close the top cover of the paper feeder tray and the machine automatically starts shredding.

Key in the four-digit PIN number on the keyboard (B), for example:



and the cover blocks automatically.

The top cover of the shredder unblocks automatically when:

- the four-digit PIN number is entered.
- The shred cycle has been completed.

Important: If you forget the PIN number, the top cover will unblock automatically 20 minutes after it goes on stand-by.



TROUBLE-SHOOTING



If you have any problems with your shredder, check the symptoms and remedies described below.

If you are unable to solve the problem this way, contact your nearest Kobra dealer.

Do not open the head of the shredder to attempt to repair it yourself. You could get a serious electric shock and invalidate your warranty

PROBLEM	SIGNS	CAUSE	ACTION
The shredder fails to start	- The light (G) does not come on - Red light (I) comes on - Light (G) comes on	- Switch position (H) - Power cable not properly connected - No power - Door (C) not closed properly - Bag full - Motor in heat protection mode	- Turn switch to the position (I) - Check that the cable is plugged in properly - Check that socket is switched on. - Close the door properly - Empty bag - Wait 15 minutes for motor to cool down
The shredder never stops	- Light (G) on and cutters in operation	- Material and/or dirt deposited on or between the photocells	- Remove the deposit from or free the photocells - Clean the photocells with a brush
Significant reduction of shredding capacity	- Capacity is less than the declared capacity	- Cutters dirty or adhesive on blades	- Carry out maintenance by inserting a sheet of paper sprinkled with lubricant
Documents are not drawn in and shredded	- Documents remain in the paper feeder tray	- Dirty belts covered in paper dust	- Turn the belts manually and clean them carefully with a damp cloth

DECLARATION OF COMPLIANCE WITH EC STANDARDS

Compliant with

- directive LVD 2014/35/EU
- directive 2011/65/EU RoHS
- directive 2004/108/EC EMC

The manufacturer ELCOMAN SRL
VIA GORIZIA,9 20813 BOVISIO MASCIAGO (MI) – ITALY-

hereby declares that the KOBRA shredders listed below are compliant with the standards of directive LVD 2014/35/EU
- Kobra series: Kobra AF.1 , Kobra AF+1

Standards applied are :

EN 60950-1:2006 / A11:2009 / A1:2010 / A12:2011 / A 2:2013
EN 55014-1 :2006+A1 :2009+A2 :2011
EN 55014-2 :1997+A1 :2001+A2 :2008

EN 61000-3-2 :2014
EN 61000-3-3 :2013

Bovisio Masciago, 30.03.2017

A.DE ROSA
TECHNICAL OFFICE

