



## ANOMALIE



Se avete problemi col vostro distruggi documenti, controllate i sintomi ed i rimedi qui di seguito descritti.

Se non riuscite a risolvere il problema in questo modo, contattare il rivenditore Kobra a Voi più vicino.

**Non aprite la testata del distruggi documenti** per tentare di ripararlo. Potreste esporvi a gravi scariche elettriche e invalidare la vostra garanzia

| PROBLEMA                                       | COME SI MANIFESTA                                                                                                                                                                                        | CAUSA                                                                                                                                                                                                                                                                                                  | AZIONE                                                                                                                                                                                                                                                                                                                                                                                         |
|------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Il distruggi documenti non si avvia.           | <ul style="list-style-type: none"> <li>- Non si accende l'indicatore luminoso ( G )</li> <li>- Si accende l'indicatore luminoso rosso ( I )</li> <li>- Si accende l'indicatore luminoso ( G )</li> </ul> | <ul style="list-style-type: none"> <li>- Posizione pulsante ( H )</li> <li>- Cavo di alimentazione non correttamente collegato.</li> <li>- Assenza tensione di alimentazione.</li> <li>- Porta (C) non correttamente chiusa</li> <li>- Sacco pieno</li> <li>- Motore in protezione termica.</li> </ul> | <ul style="list-style-type: none"> <li>- Portare l'interruttore (H) in posizione (I)</li> <li>- Verificare se l'inserimento della spina nella presa di alimentazione è corretto.</li> <li>- Verificare se presente la tensione sulla presa.</li> <li>- Chiudere correttamente la porta</li> <li>- Vuotare il sacco</li> <li>- Attendere 15 minuti per il raffreddamento del motore.</li> </ul> |
| Il distruggi documenti non si ferma mai.       | Indicatore luminoso ( G ), acceso, gruppo in funzione                                                                                                                                                    | - Materiale e/o sporco depositato su fotocellule o tra le fotocellule                                                                                                                                                                                                                                  | <ul style="list-style-type: none"> <li>- Rimuovere il deposito dalle fotocellule o liberare le fotocellule.</li> <li>- Pulire le fotocellule con una spazzola</li> </ul>                                                                                                                                                                                                                       |
| Riduzione sensibile della capacità di taglio   | - Capacità ridotta rispetto alla capacità dichiarata.                                                                                                                                                    | - Gruppo di taglio sporco o con presenza di adesivo su lame.                                                                                                                                                                                                                                           | - Effettuare una manutenzione inserendo un foglio cosparso di lubrificante                                                                                                                                                                                                                                                                                                                     |
| I documenti non vengono trascinati e distrutti | I documenti rimangono nel vassoio alimentazione carta                                                                                                                                                    | Cinghie sporche e coperte da polvere di carta                                                                                                                                                                                                                                                          | Pulire accuratamente le cinghie con un panno bagnato ruotandole manualmente                                                                                                                                                                                                                                                                                                                    |

## DICHIARAZIONE DI CONFORMITÀ

**Conformemente: alla - direttiva LVD 2014/35/UE**  
**- direttiva 2011/65/EU RoHS**  
**- direttiva 2004/108/CE CEM**

Il costruttore ELCOMAN SRL  
 VIA GORIZIA,9 20813 BOVISIO MASCIAGO (MI) – ITALY-

dichiara con la presente che i distruttori di documenti Kobra sotto descritti sono conformi alle norme della direttiva LVD 2014/35/UE

- Kobra serie : Kobra AF.1 e Kobra AF+1

Le norme applicate sono :

EN 60950-1:2006 / A1:2009 / A1:2010 / A12:2011 / A 2:2013

EN 55014-1 :2006+A1 :2009+A2 :2011

EN 55014-2 :1997+A1 :2001+A2 :2008

EN 61000-3-2 :2014

EN 61000-3-3 :2013

Bovisio Masciago, 30.03.2017





## FEATURES

The Kobra AF.1 and Kobra AF+1 are shredders with automatic feeder technology.

For technical features see table on page 23

### INSTALLATION FIG.1

Make sure power socket is easily accessible and situated near to the machine. Take the machine out of its packaging, position the machine head (A) on the base (B). Open the door (C), slide the bag holder frame (D) from its tracks (E). Fit the plastic bag (F) which comes with the machine onto the bag holder frame (D) and slide it back onto its tracks (E). Push the frame right in and close the door again.

### OPERATING THE MACHINE FIG.2

Once the shredder has been plugged in, turn the switch (H) to the "I" position. The light (G) will come on for a few seconds and the machine will start a shred cycle.

If no documents to be shredded have been inserted into the machine it will automatically go on stand-by.

Now it is possible to shred documents at any time.

With the switch (H) in the "O" position, all functions are switched off.

By putting the button (H) in the "R" position at any time and with any kind of paper you can interrupt shredding and extract the document by putting the machine in reverse.

### MANUAL SHREDDING OF SINGLE SHEETS

Insert sheets in the throat (L) and the light indicator (G) comes on and the machine starts shredding automatically as two photocells inside the throat detect the presence of paper and automatically stop the shredding knives a few seconds after shredding has finished.

If you insert a greater quantity of paper than the shredding capacity, the machine will automatically go into reverse and eject the excess paper.

Take the excess paper out of the throat in order to free the photocells then insert a smaller amount of paper and the machine will automatically restart and finish shredding with a shred cycle.

It is advisable to limit jams caused by introducing too much paper and to operate the machine below maximum capacity in order to prolong the life of mechanical parts and the life of the machine itself.

### AUTOMATIC PAPER SHREDDING (FIG.3)

Open the top cover of the paper feeder tray as shown in figure 3.. Insert a maximum of 300 sheets of A4 paper in the feeder tray and in any case ensure they are not higher than the maximum load mark (A). Close the top cover, the machine automatically starts shredding and automatically stops when shredding is finished.

#### IMPORTANT:

The automatic function can be used for bound blocks up to a maximum of 25 sheets. Provided the type of staple used is no longer than 6 mm and the block is inserted with the points facing downwards.

#### IMPORTANT:

The automatic function can be used for bound blocks up to a maximum of 25 sheets. Provided the type of staple used is no longer than 6 mm and the block is inserted with the points facing downwards.



**WARNING:** The Kobra AF.1 and AF +1 shredders are NOT able to shred the following types of documents with:

|  |                                                                                 |  |                                                                            |
|--|---------------------------------------------------------------------------------|--|----------------------------------------------------------------------------|
|  | Staples with a shaft longer than 6mm                                            |  | Large paper clips                                                          |
|  | Bulldog clips                                                                   |  | Spiral bindings                                                            |
|  | Adhesive labels                                                                 |  | Magazines or other documents bounds with a number of stitchings or staples |
|  | Plastic sheets, laminated documents, plastic folders documents, plastic folders |  |                                                                            |

### PAPER JAMS

This is what to do if the shredder jams:

- Manually put the shredder into reverse once or more times by moving the switch (H) to the position "R".
- Open the top cover of the feeder tray.
- Remove the paper jam

Once you have freed the cutters of the paper jam, put some paper in the feeder tray, close the cover again and now your shredder is ready to go.

### AUTOMATIC FUNCTIONS

The Kobra AF.1 and Kobra AF+1 come with the following automatic functions:

-PHOTOCELLS to start the machine automatically  
 -AUTOMATIC RETURN anti-jamming function: if you accidentally insert more paper than the shredder's maximum capacity this function switches off the power to the electric motor and then sends it into reverse for a few seconds in order to free the cutters and puts the shredder on stand-by.  
 Remove the paper from the throat in order to resume shredding, free the photocells and then insert a smaller number of sheets of paper.

✓ -MOTOR PROTECTOR which automatically stops the machine