
GLOW SYSTEM [SKYACTIV-D 2.2]

id0113z7706000

Purpose, Function

- The SKYACTIV-D 2.2 has a comparatively low compression temperature because of its low compression. The glow system raises the compression temperature by preheating the inside of the combustion chamber to assure engine startability at low temperatures.
- The glow plugs are controlled by the glow control module.

System Diagram



ac5wzn00002197

Structure

• The glow control system consists of the following parts:

Part name	Reference
Glow plug	(See GLOW PLUG [SKYACTIV-D 2.2].)
Glow control module	(See GLOW CONTROL MODULE [SKYACTIV-D 2.2].)