FRONT WHEEL HUB BOLT REPLACEMENT

id031100800200

- 1. Remove the brake caliper component from the steering knuckle and suspend it out of the way using a cable.
- 2. Remove the disc plate.
- 3. Remove the wheel hub bolt using the **SST** as shown in the figure.
- 4. Place a new wheel hub bolt in the wheel hub.





