# **CLUTCH FLUID LEAKAGE INSPECTION [D66M-R, D66MX-R]**


id0510mf158400

### Caution

- Do not allow clutch fluid to get on a painted surface. Clutch fluid contains properties which can dissolve the paint. If clutch fluid gets on a painted surface, wash it off with water immediately and wipe the area off completely.

- Verify reserve tank cap is on tight.
  Pump the clutch pedal a few times.
  Inspect for the clutch fluid leakage at the points indicated in the figure.


### L.H.D.



### R.H.D.

## Note

- If there is clutch fluid leakage from the piston in the clutch release cylinder, there is clutch fluid in the boot of clutch release cylinder.
- If there is clutch fluid leakage, repair or replace the malfunctioning location.



ac5wzw00003430