CONTROL SYSTEM DEVICE AND CONTROL RELATIONSHIP CHART [SKYACTIV-D 2.2]

id0103g1800200

MAIN RELAY CONTROL IDLE SPEED CONTROL IDLE SPEED CONTROL TWO-STAGE TURBO CONTROL IDEVA*1 CONTROL IDEVA*1 CONTROL FUEL INJECTION AMOUNT CONTROL FUEL INJECTION TIMING CONTROL FUEL INJECTION TIMING CONTROL FUEL INJECTION TIMING CONTROL FUEL RATIO (A/F) SENSOR HEATER CONTROL GLOW CONTROL FUEL RATIO (A/F) SENSOR HEATER CONTROL GENERATOR CONTROL GENERATOR CONTROL STARTER CUT-OFF CONTROL STARTER CUT-OFF CONTROL GENERATOR CONTROL STARTER CUT-OFF CONTROL BLOW-BY HEATER CONTROL BLOW-BY HEATER CONTROL BLOW-BY HEATER CONTROL DC-DC CONVERTER CONTROL
MAIN RELA IDLE SPEEI TWO-STAGE TU IDEVA*1 INTAKE SHUTTER GLOW C GLOW C GLOW C GLOW C AIR FUEL RATIO (A/F) SE INTAKE SHUTTER INTAKE SHUTTER GLOW C GLOW C AIR FUEL RATIO (A/F) SE INTAKE SHUTTER INTAKE SHUTTE
Input device
Check connector x x
IG1 relay x x x x x x x
Brake switch (No.1 signal) × × ×
Brake switch (No.2 signal)
Glow control module
MAP sensor No.2
IAT sensor No.1
MAP sensor No.1
ECT sensor
Fuel temperature sensor
IAT sensor No.2 x x x x x x x x x x x x x x x x x x x
Boost air temperature sensor × × ×
APP sensor No.1, No.2
MAF sensor
Fuel pressure sensor
Intake shutter valve position sensor
EGR cooler bypass valve position sensor
EGR valve position sensor
Exhaust gas pressure sensor No.2
BARO sensor
Battery x x x x x x
Refrigerant pressure sensor*3
Exhaust gas pressure sensor No.1
Exhaust gas temperature sensor No.1
Exhaust gas temperature sensor No.2
Exhaust gas temperature sensor No.3
Engine oil temperature sensor × × × ×
Engine oil pressure sensor
Regulating valve position sensor × × × ×
Ambient temperature sensor*3
A/F sensor
Power brake unit vacuum sensor × × ×
CKP sensor x x x x x x x x x x x x x x x x x x x
CMP sensor

Item	MAIN RELAY CONTROL	IDLE SPEED CONTROL	TWO-STAGE TURBO CONTROL	IDEVA*1 CONTROL	FUEL INJECTION AMOUNT CONTROL	MULTIPLE FUEL INJECTION CONTROL	FUEL INJECTION TIMING CONTROL	FUEL PRESSURE CONTROL	INTAKE SHUTTER VALVE CONTROL	GLOW CONTROL	EGR CONTROL	AIR FUEL RATIO (A/F) SENSOR HEATER CONTROL	DIESEL PARTICULATE FILTER REGENERATION CONTROL	A/C CUT-OFF CONTROL	ELECTRICAL FAN CONTROL	STARTER CUT-OFF CONTROL	GENERATOR CONTROL	RUN DRY PREVENTION (RDP) CONTROL	BLOW-BY HEATER CONTROL	i-stop CONTROL	DC-DC CONVERTER CONTROL	ENGINE OIL CONTROL
Transaxle range sensor (ATX)		×			×	×	×		×				×			×				×		Н
Back-up light switch (MTX)		×			×	×	×		×				×			×				×		Н
Neutral switch No.1 (MTX)		×			×	×	×		×				×	×		×	×			×		П
CPP switch (MTX)		×			×	×	×		×				×			×	×			×		П
Starter interlock switch (MTX)																				×		П
Neutral switch No.2 (MTX)																				×		П
Clutch stroke sensor (MTX)																				×		
CAN*2		×	×		×	×	×		×	×	×		×	×	×	×	×	×		×	×	П
Output device																						
Intake shutter valve									×				×							×		П
EGR cooler bypass valve											×		×							×		
EGR valve											×		×							×		
Fuel pressure relief valve								×												×		
Main relay	×																					
Regulating solenoid valve			×										×							×		Ш
Wastegate solenoid valve			×										×							×		Ш
Compressor bypass solenoid valve			×										×							×		Ш
A/F sensor heater												×								×		Ш
Starter relay																×				×		Ш
Generator (Field coil)	_	×															×			×		Ш
A/C relay*3														×								
Cooling fan relay No.1															×							Ш
Cooling fan relay No.2															×							Ш
Engine oil solenoid valve				×									×									×
Suction control valve								×												×		Ш
Fuel injector No.1—No.4	_	×			×	×	×						×					×		×		Ш
Blow-by heater relay																			×			Ш
OCV	_			×									×									\vdash
DC-DC converter	_																×				×	\square
Glow plug No.1—No.4										×			×									Ш

^{*1 :} Intake stroke EGR using double exhaust valve actuation system
*2 : TCM (ATX), DSC HU/CM, front body control module (FBCM), rear body control module (RBCM), instrument cluster, start stop unit, EPS control module
*3 : With air conditioner