TCS OFF SWITCH REMOVAL/INSTALLATION

id041500803000

Note
- The TCS OFF switch is integrated with the cluster switch.
- Refer to SWITCH PANEL REMOVAL/INSTALLATION to remove the cluster switch.

1. Remove the cluster switch from the switch panel. (See SWITCH PANEL REMOVAL/INSTALLATION.)
2. Install in the reverse order of removal.