MIRROR BASE INSTALLATION

id091200005400


1. Cut away all of the original sealant using a razor.

Warning


- · Using a razor with bare hands can cause injury. Always wear gloves when using a razor.
- 2. Clean and degrease the ceramic coating on the glass and the base.

Caution

- Keep the area free of dirt and grease, and do not touch the surface. Otherwise, the primer may not properly bond to the surface of the glass.
- 3. Apply primer to the bonding area of the glass and the base.
- 4. Use only glass primer on the glass, and body primer on the base. Allow the primer to dry for approx. 30 min.
- 5. Apply 3.0 mm {0.12 in} layer of sealant to the base.



- 6. Center the base in the ceramic coating and press it onto the glass.
- Use isopropyl alcohol to remove any excess repair sealant.



ac5wzw00001353

Hardening time of sealant

Temperature	Surface hardening time	Time required until car can be put into service
5 °C {41 °F}	Approx. 1.5 h	Approx. 12 h
20 °C {68 °F}	Approx. 1 h	Approx. 4 h
35 °C {95 °F}	Approx. 10 min	Approx. 2 h

- 8. Install the rearview mirror. (without auto-dimming mirror) (See REARVIEW MIRROR REMOVAL/INSTALLATION.)
- 9. Install the auto-dimming mirror. (with auto-dimming mirror) (See AUTO-DIMMING MIRROR REMOVAL/INSTALLATION.)