ULTRASONIC SENSOR

Purpose

Detects obstructions.


Function

• The ultrasonic sensor emits ultrasonic waves from its head and receives the waves reflected off an obstruction.

Construction

Consist of a total of eight ultrasonic sensors; four on the front bumper and four on the rear bumper.

• A flat-type ultrasonic sensor of the same color as the body with no concavity has been adopted.



ac5jjn00001520

Operation

For details on the ultrasonic sensor operation, refer to PARKING SENSOR SYSTEM.

Fail-safe

· Function not equipped.