SYMPTOM TROUBLESHOOTING

id060300800400

• Verify the symptom, and perform troubleshooting according to the appropriate number.

No.	Symptom
1	Electric power steering (EPS) warning light does not illuminate with ignition switched ON.
2	Electric power steering (EPS) warning light/Master warning light does not go out even though engine has started.
3	Power assist differs between right and left turns.