# **PARKING SENSOR INDICATOR LIGHT**

id092200024500

# **Purpose**


• Illuminates/flashes based on the signal from the parking sensor control module.

## **Function**

• Illuminates when the parking sensor system is operating, and flashes if there is a malfunction in the ultrasonic sensor circuit.

## Construction

• The parking sensor indicator is built into the parking sensor switch.



ac5jjn00001525

# Operation

• For details on the parking sensor indicator operation/flashing, refer to PARKING SENSOR SYSTEM.

# Fail-safe

• Function not equipped.