Purpose

• The high-mount brake light signals vehicles to the rear that the vehicle is stopped.

Function


The high-mount brake light illuminates in conjunction with the operation of the brake light switch.

Construction

- · The high-mount brake light is positioned on the roof.
- · The high-mount brake light has adopted an LED.

Note

Fogging or condensation on the inside of the high-mount brake light may occur, however, it is a natural
phenomenon occurring as a result of a temperature difference between the interior and exterior of the highmount brake light and has no effect on the light performance. Fogging or condensation will dissipate when
the temperature inside the high-mount brake light rises after the high-mount brake light is illuminated and
a period of time has elapsed.




ac5uun00000571

Operation

Brake lights (with smart city brake support)

- 1. When the brake pedal is depressed, the brake light switch turns on.
- 2. When the brake light switch turns on, a brake light switch on signal is input to the rear body control module (RBCM).
- 3. When the rear body control module (RBCM) receives the high-mount brake light switch on signal, it illuminates the brake lights.




ac5wzn00001362

Brake lights (without smart city brake support)

1. When the brake pedal is depressed, the brake light switch turns on.

2. When the brake light switch turns on, the high-mount brake light illuminates.



ac5wzn00001363

Fail-safe

· Function not equipped.