
REAR DOOR CHECKER REMOVAL/INSTALLATION

id091100520700

- 1. Fully close the rear door glass.
- 2. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)

 3. Remove the rear door trim. (See REAR DOOR TRIM REMOVAL/INSTALLATION.)
- 4. Remove the rear door speaker. (See REAR DOOR SPEAKER REMOVAL/INSTALLATION.)
- 5. Remove bolt.



- 6. Remove nuts.
- Pull out the rear door checker from the rear speaker installation hole.
- Install in the reverse order of removal.

