CAMSHAFT INSPECTION id011000501500

- 1. Set the No.1 and No.5 journals of the camshaft on V-blocks.
- Measure the camshaft runout using the dial gauge.
  - If it exceeds the maximum specification, replace the camshaft.

Maximum camshaft runout 0.030 mm {0.0012 in}

- bpe2ue00000031
- 3. Measure the cam height using the micrometer as shown in the figure.
  - If it is less than the minimum specification, replace the camshaft.

Standard cam height [SKYACTIV-G 2.0]

IN: 41.57 mm {1.637 in} EX: 40.37 mm {1.589 in}

Standard cam height [SKYACTIV-G 2.5]

IN: 42.34 mm {1.667 in} EX: 40.37 mm {1.589 in}

Minimum cam height [SKYACTIV-G 2.0]

IN: 41.50 mm {1.634 in} EX: 40.30 mm {1.587 in}


Minimum cam height [SKYACTIV-G 2.5]

IN: 42.27 mm {1.664 in} EX: 40.30 mm {1.587 in}

- Measure the journal diameter using the micrometer. Measurement positions total four and are in the X and Y directions, at two points (A and B) as shown in the figure.
  - If it is less than the minimum specification, replace the camshaft.

Standard camshaft journal diameter 24.96—24.98 mm {0.9827—0.9834 in}

Minimum camshaft journal diameter 24.93 mm {0.9815 in}




bp31je00000172

bp31je00000171

- 5. Measure the camshaft journal oil clearance using the following procedure:
  - (1) Clean the camshaft journal and the journal receptacle part.
  - (2) Put the camshaft on the cylinder head with the rocker arm detached.
  - (3) Cut the plastigauge to the same length as the journal width and position it parallel to the camshaft.
  - (4) Install the camshaft caps. (See CYLINDER HEAD ASSEMBLY (II).)
  - (5) Remove the camshaft caps. (See CYLINDER HEAD DISASSEMBLY (I).)
  - (6) Measure the camshaft journal oil clearance.
    - If it exceeds the maximum specification, replace the cylinder head.

Standard camshaft journal oil clearance 0.035—0.080 mm {0.0014—0.0031 in}



## Maximum camshaft journal oil clearance 0.090 mm {0.0035 in}

- 6. Measure the camshaft end play using a dial gauge.
  - If it exceeds the maximum specification, replace the cylinder head or camshaft.

Standard camshaft end play 0.07—0.22 mm {0.003—0.008 in}

Maximum camshaft end play 0.23 mm {0.0091 in}

