## SUNROOF SWITCH REMOVAL/INSTALLATION

id091500800200

## Note

- The sunroof switch is together with the front map light.
- 1. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)
- 2. Remove the map light. (See MAP LIGHT REMOVAL/INSTALLATION.)
- 3. Install in the reverse order of removal.