
INNER GARNISH REMOVAL/INSTALLATION

id091700801000

1. Take the shaded area shown in the figure, and pull the inner garnish in the direction of the arrow (1) while detaching clips A.



2. Take the shaded area shown in the figure, and remove the inner garnish in the direction of the arrow (2) while detaching pins B.
Install in the reverse order of removal.