
HORN id092200021700

Purpose, Function

The horn sounds according to the horn switch operation.

Construction

Installed to the inside of the front grille.
The diaphragm is vibrated to apply vibration to the air and produce sound.



ac5wzn00001431

Operation

1. When the horn switch turns on (1), the horn relay turns on (2).

2. When the horn relay turns on, the horn sounds. HORN RELAY CLOCK SPRING **FBCM** HORN HORN (**SWITCH**

ac5wzn00001552

Fail-safe

· Function not equipped.