
## **AUTO-DIMMING MIRROR REMOVAL/INSTALLATION**


id091200099900

With Forward Sensing Camera Or Smart City Brake Support (SCBS)

- 1. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION [SKYACTIV-D 2.25].)
- 2. Remove the cover. (See FORWARD SENSING CAMERA (FSC) REMOVAL/INSTALLATION.)
- 3. Disconnect the auto-dimming mirror connector.




ac5wzw00001355



5. Remove the auto-dimming mirror in the direction of arrow (1) shown in the figure.


ac5wzw00001356



6. Install in the reverse order of removal.


Without Forward Sensing Camera Or Smart City Brake Support (SCBS)
Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION (SONNECTION (SONNECT DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)

2. Remove the screw B.




ac5wzw00002991


3. Remove the auto-dimming mirror in the direction of arrow (1) shown in the figure.




4. Detach tabs while push the cover No.2 in the direction of the arrow (2) shown in the figure, then remove the cover No.2 in the direction of the arrow (3).



5. Disconnect the auto-dimming mirror connector.



- 6. Remove the auto-dimming mirror in the direction of arrow (4) from the mirror base.7. Install in the reverse order of removal.



ac5wzw00002995