ROLLOVER VALVE [SKYACTIV-D 2.2]


id0116e1122900

Purpose, Function


• Prevents fuel from flowing into the evaporative gas passage during sudden cornering or vehicle rollover.

Construction


• The rollover valve is built into the fuel tank.



4WD



 The rollover valve consists of a float, O-ring and spring.



Operation
The rollover valve utilizes a combination of float weight, spring force, and buoyancy. When the float is immersed in the fuel, the float (valve) closes to block the sealing surface of the passage.

