PID/DATA MONITOR TABLE [IMMOBILIZER SYSTEM]

id0902e4028900

—: Not applicable

PID	Unit/ Operation	Data contents	Inspection item(s)
NUM_TRNS MIT	_	Displays the number of the remote transmitters programmed to the start stop unit.	Start stop unit