## **HIGH CLUTCH HUB INSPECTION**

id051700663200

# **Bush Inner Diameter Inspection**

1. Measure the inner diameter of the bush in two locations shown in the figure.

### Note

- When measuring, measure near the center of the bush avoiding the oil groove, and then calculate the average value of the X and Y directions as shown in the figure.
- Recommended measuring instrument: Cylinder gauge or caliper gauge

## Maximum:

# 18.038 mm {0.71015 in}

• If it is more than the maximum specification, replace the high clutch hub with a new one.

