CLUTCH FLUID INSPECTION [D66M-R, D66MX-R]

id0510mf156400

Note

- A common reserve tank is used for the clutch system and brake system.
- 1. Verify that the clutch fluid is between the MIN mark and the MAX mark.
 - If fluid level is lower than MIN mark, perform the following procedure:
 - 1. Verify that there is no fluid leakage. (See CLUTCH FLUID LEAKAGE INSPECTION [D66M-R, D66MX-R].)
 - 2. Add fluid to the level between MIN mark and the MAX mark.

Clutch fluid SAE J1703 or FMVSS116 DOT-3 or DOT-4

