


DOOR AND LIFTGATE LOCATION INDEX

id091100520000







ac5uuw00000835

	(See LIFTGATE HINGE REMOVAL/INSTALLATION.)
1	Liftgate hinge

- 2 Stay damper (See STAY DAMPER DISPOSAL.)
- Rear door checker
 (See REAR DOOR CHECKER REMOVAL/
 INSTALLATION.)
- 4 Front door checker (See FRONT DOOR CHECKER REMOVAL/ INSTALLATION.)
- 5 Front door module panel (See FRONT DOOR MODULE PANEL REMOVAL/ INSTALLATION.)
- 6 Front door (See FRONT DOOR REMOVAL/INSTALLATION.) (See DOOR ADJUSTMENT.)

		acoudwood
ĺ	7	Rear door
		(See REAR DOOR REMOVAL/INSTALLATION.)
		(See DOOR ADJUSTMENT.)
İ	8	Rear door module panel
		(See REAR DOOR MODULE PANEL REMOVAL/
		INSTALLATION.)
Ī	9	Front door hinge
		(See FRONT DOOR HINGE REMOVAL/
		INSTALLATION.)

- 10 Rear door hinge (See REAR DOOR HINGE REMOVAL/ INSTALLATION.)
- 11 Liftgate
 (See LIFTGATE REMOVAL/INSTALLATION.)
 (See LIFTGATE ADJUSTMENT.)