HEADLIGHT CLEANER ACTUATOR

id091900103500

Purpose


• The headlight cleaner actuator pushes the headlight cleaner nozzle outward from the front bumper.

Function

• The headlight cleaner actuator pushes the headlight cleaner nozzle outward from the front bumper using the washer pressure from the headlight cleaner hose.

Construction / Operation

- The headlight cleaner nozzle is held retracted by a spring within the headlight cleaner actuator.
- When fluid pressure rises due to the operation of the headlight cleaner motor, the piston in the headlight cleaner actuator is pushed, causing the nozzle to pop out of the front bumper and spray washer fluid.



am5ezn00001403

Fail-safe

Function not equipped.