

## LUBRICATION SYSTEM LOCATION INDEX [SKYACTIV-G 2.0, SKYACTIV-G 2.5]

id0111h5800100

## **SKYACTIV-G 2.0**



## **SKYACTIV-G 2.5**



1	Dipstick
	(See ENGINE OIL LEVEL INSPECTION
	[SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
	(See ENGINE OIL REPLACEMENT [SKYACTIV-G
	2.0, SKYACTIV-G 2.5].)
2	Oil pressure switch
	(See OIL PRESSURE INSPECTION [SKYACTIV-G
	2.0, SKYACTIV-G 2.5].)
3	Engine oil solenoid valve
	(See ENGINE OIL SOLENOID VALVE REMOVAL/
	INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G
	2.5].)
	(See ENGINE OIL SOLENOID VALVE
	INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G
	2.5].)
4	Oil pump component
	(See OIL PUMP REMOVAL/INSTALLATION
	[SKYACTIV-G 2.0, SKYACTIV-G 2.5].)

5	Oil strainer
	(See OIL PUMP REMOVAL/INSTALLATION
	[SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
6	Oil pan
	(See OIL PAN REMOVAL/INSTALLATION
	[SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
7	Oil filter
	(See OIL FILTER REPLACEMENT [SKYACTIV-G
	2.0, SKYACTIV-G 2.5].)
8	Oil cooler
	(See OIL COOLER REMOVAL/INSTALLATION
	[SKYACTIV-G 2.0].)