## **BLIND SPOT MONITORING (BSM) INDICATOR LIGHT INSPECTION**

id092200014400

## Note

- The BSM indicator lights are integrated into the outer mirror glass.
  For the BSM indicator light inspection, refer to the outer mirror glass inspection. (See OUTER MIRROR GLASS INSPECTION.)