**SEAT BELT** id081100500100

#### **Outline**

- · Three-point front seat belts with the following functions for front seat passengers adopted.
  - ELR (Emergency Locking Retractor: emergency locking mechanism)
  - Load limiter
  - Pre-tensioner seat belt (See PRE-TENSIONER SEAT BELT.)
- Three-point seat belts with the following functions for rear seat passengers adopted.


## European (L.H.D. U.K.), General (L.H.D.) specs. Israel

- ELR

### Australian, General (L.H.D. R.H.D.) specs. other than Israel

- ELR
- ALR (Automatic Locking Retractor: child-restraint seat locking mechanism) (left and right seats)

## **Structural View**



ac5wzn00000817

### **Purpose**

• The seat belt prevents the driver and the passenger from being thrown from the seat and injured due to an emergency vehicle stop or impact by being hit.

### **Function**

- The seat belts are belt type safety devices which restrain the driver and passengers in their seats.
- The specifications for each seat belt are as indicated in the table.

Furonean (L.H.D. U.K.), General (L.H.D.) specs, Israel

European (L.n.b. O.N.), General (L.n.b.) Specs. Israel				
Seat belt	Type	Function		
Front seat belt (Driver-side, passenger-side)	Three- point	Load limiter ELR (Emergency Locking Retractor) Pre-tensioner seat belt		
Rear seat belt (RH, LH)	Three- point	ELR (Emergency Locking Retractor))		
Rear center seat belt	Three- point	ELR (Emergency Locking Retractor)		


Australian, General (L.H.D. R.H.D.) specs, other than Israel

Addition, Control (Ent.D. Nation) Special Union than Island				
Seat belt	Type	Function		
Front seat belt (Driver-side, passenger-side)	Three- point	Load limiter		
		ELR (Emergency Locking Retractor)		
		Pre-tensioner seat belt		
Rear seat belt (RH, LH)	Three-	ELR (Emergency Locking Retractor)		
	point	ALR (Automatic Locking Retractor)		

Seat belt	Type	Function
Rear center seat belt	Three- point	ELR (Emergency Locking Retractor)

#### **Load limiter**

The load limiter adjusts the restraint force of the seat belt by slightly loosening the seat belt tightened by the pretensioner operation, preventing injury to the driver and passenger from seat belt pressure.



ac5wzn00000818

## **ELR (Emergency Locking Retractor)**

If a sudden force is applied to the seat belt such as by a collision or emergency braking, the ELR locks the seat belt so that it cannot be pulled out any more.

## **ALR (Automatic Locking Retractor)**


- When the seat belt is pulled out and fastened, the ALR locks the seat belt at that length and it cannot be pulled out any more.
- The ALR is mainly used for installing a child-restraint.

# Pre-tensioner seat belt

• Refer to PRE-TENSIONER SEAT BELT. (See PRE-TENSIONER SEAT BELT.)

### Construction

- · For the three-point seat belt, the seat belt is secured to the drum in the retractor and wrapped.
- The seat belt is pulled out or retrieved by the rotation of the drum to adjust the length of the seat belt.



ac5wzn00000819

#### Fail-safe

· Function not equipped.