

FRONT DRAIN HOSE REMOVAL/INSTALLATION

id091500443800

- Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)
- 2. Remove the following parts:
 - (1) Sunroof seaming welt (See SUNROOF UNIT REMOVAL/INSTALLATION.)
 - (2) A-pillar trim (See A-PILLAR TRIM REMOVAL/INSTALLATION.)
 - (3) Map light (See MAP LIGHT REMOVAL/INSTALLATION.)
 - (4) Sunvisor (See SUNVISOR REMOVAL/INSTALLATION.)
 - (5) Front scuff plate (See FRONT SCUFF PLATE REMOVAL/INSTALLATION.)
 - (6) Rear scuff plate (See REAR SCUFF PLATE REMOVAL/INSTALLATION.)
 - (7) B-pillar lower trim (See B-PILLAR LOWER TRIM REMOVAL/INSTALLATION.)
 - (8) Adjust anchor cover (See FRONT SEAT BELT REMOVAL/INSTALLATION.)
 - (9) Upper anchor installation bolt on the seat belt (See FRONT SEAT BELT REMOVAL/INSTALLATION.)
 - (10)B-pillar upper trim (See B-PILLAR UPPER TRIM REMOVAL/INSTALLATION.)
 - (11)Assist handle (See ASSIST HANDLE REMOVAL/INSTALLATION.)
 - (12)Trunk board (See TRUNK BOARD REMOVAL/INSTALLATION.)
 - (13)Trunk end trim (See TRUNK END TRIM REMOVAL/INSTALLATION.)
 - (14)Trunk side trim (See TRUNK SIDE TRIM REMOVAL/INSTALLATION.)
 - (15)D-pillar trim (See D-PILLAR TRIM REMOVAL/INSTALLATION.)
 - (16)C-pillar trim (See C-PILLAR TRIM REMOVAL/INSTALLATION.)
 - (17)Headliner (See HEADLINER REMOVAL/INSTALLATION.)
- 3. Disconnect the front drain hose from the sunroof frame.




4. Pull the front drain hose in the direction of the arrow in the order of (1), (2) and remove it while detaching hooks A.




ac5wzw00001720

- 5. Pull the front drain hose in the direction of the arrow in the order of (3), (4) and remove it while detaching hooks
- 6. Remove the car-navigation unit. (driver-side) (See CAR-NAVIGATION UNIT REMOVAL/INSTALLATION.)
- 7. Remove the glove compartment. (passenger-side) (See GLOVE COMPARTMENT REMOVAL/INSTALLATION.)
- While visually verifying from the car-navigation unit opening (driver-side) and glove component opening (passenger-side), partially peel back the dashboard lower insulator, insert a tape-wrapped flathead screwdriver into the position shown in the figure, then remove the grommet in the direction of the arrow.



9. Pull the front drain hose out from the A-pillar side.



10. Install in the reverse order of removal.