DIESEL PARTICULATE FILTER [SKYACTIV-D 2.2]

id0116e1707900

Purpose, Function


• The diesel particulate filter collects and removes particulate matter (PM) in the exhaust gas.

Construction

· DPF is built-in catalytic converter.

Operation

• Diesel particulate filter is a silicon carbide honey-comb type filter. The filter ends are blocked in sequence and small holes on the wall inside the filter collect PM, and the collected PM is burned and eliminated.



am6zzn00001164