DRIVE BELT [SKYACTIV-G 2.0, SKYACTIV-G 2.5]


id0110h3001100

Purpose, Function

• The drive belt transmits rotation force of the crankshaft pulley to the pulley for the auxiliary parts.


Construction

• The drive belt is installed to the front of the engine.



am3uun00001858

- · A V-ribbed belt has been adopted for the drive belt.
- The water pump drive belt is a stretch type.
- Drive belt vibration is suppressed by shortening the distance between each pulley.
- With the adoption of the oil pressure type drive belt auto tensioner, the change in tension by the oil pressure damper operation is absorbed. As a result, the sliding resistance has been reduced by lowering the drive belt tension setting.



am3uun00001859